



Avaya Solution & Interoperability Test Lab

Avaya Communication Manager Survivable SIP Gateway Solution using the AudioCodes MP-114 in a Centralized Trunking Configuration – Issue 1.1

Abstract

These Application Notes present a sample configuration of the Avaya Communication Manager Survivable SIP Gateway Solution using the AudioCodes MP-114 Media Gateway in a Centralized Trunking configuration.

The Avaya Communication Manager Survivable SIP Gateway Solution addresses the risk of service disruption for SIP endpoints deployed at remote branch locations if connectivity to the centralized Avaya SIP call control platform is lost. Connectivity loss can be caused by WAN access problems being experienced at the branch or network problems at the centralized site blocking access to the Avaya SIP call control platform.

The Avaya Communication Manager Survivable SIP Gateway Solution monitors the connectivity health from the remote branch to the centralized Avaya SIP call control platform. When connectivity loss is detected, Avaya one-X Deskphone SIP 9600 Series IP Telephones as well as the AudioCodes SIP Gateway dynamically switch to survivability mode, restoring telephony services to the branch for intra-branch and PSTN calling.

Testing was conducted via the DevConnect Program at the Avaya Solution and Interoperability Test Lab at the request of the Solutions and Marketing Team.

1. Introduction

These Application Notes present a sample configuration of the Avaya Communication Manager Survivable SIP Gateway Solution using the AudioCodes MP-114 Media Gateway in a Centralized Trunking scenario.

SIP endpoints deployed at remote branch locations risk a loss of service if a break in connectivity to the centralized SIP call control platform occurs. Connectivity loss can be caused by WAN access problems being experienced at the branch or network problems at the centralized site blocking access to the Avaya SIP call control platform. The Avaya Communication Manager Survivable SIP Gateway Solution monitors connectivity health from the remote branch to the centralized Avaya SIP call control platform. When connectivity loss is detected, SIP endpoint and SIP gateway components within the branch dynamically switch to survivability mode restoring basic telephony services to the branch. When connectivity from the branch to the centralized Avaya SIP call control platform is restored, SIP components dynamically switch back to normal operation.

The primary components of the Avaya Communication Manager Survivable SIP Gateway Solution are the Avaya one-X Deskphone SIP 9600 Series IP Telephones and the AudioCodes SIP Media Gateways models MP-114 and MP-118. The sample configuration presented in these Application Notes utilizes the AudioCodes SIP Media Gateway model MP-114. These configuration steps can also be applied to the AudioCodes SIP Media Gateway model MP-118 using the AudioCodes firmware version specified in **Table 1**.

2. Overview

2.1. AudioCodes SIP Media Gateway

The AudioCodes SIP Media Gateway, referred to as AudioCodes MP-114 throughout the remainder of this document, takes on various roles based on call flows and network conditions. The following lists these roles:

- SIP PSTN Media Gateway (FXO interfaces to PSTN)
- SIP Analog Terminal Adapter (FXS interfaces to analog endpoints)
- SIP Registrar and Proxy (Dynamically activated on detection of lost connectivity to Avaya SES)

Note: AudioCodes labels the Survivable SIP Registrar and Proxy functionality of the MP-114 as Stand-Alone Survivability (SAS). SAS will be used throughout these Application Notes.

2.2. Avaya one-X Deskphone SIP 9600 Series IP Telephone

The Avaya one-X Deskphone SIP 9600 Series IP Telephone, referred to as Avaya 9600 SIP Phone throughout the remainder of this document, is a key component of the Avaya Communication Manager Survivable SIP Gateway Solution. The 2.4 firmware release of the Avaya 9600 SIP Phone includes new feature capabilities specific to SIP survivability, enabling the phone to monitor connectivity to the Avaya SES and dynamically failover to the local AudioCodes MP-114 as an alternate or survivable SIP server. See reference [1] for additional information on the Avaya 9600 SIP Phone.

2.3. PSTN Trunking Configurations

The Avaya Communication Manager Survivable SIP Gateway Solution can interface with the PSTN in either a Centralized Trunking or a Distributed Trunking configuration. These trunking options determine how branch calls to and from the PSTN will be routed by Avaya Communication Manager over the corporate network.

Assuming an enterprise consisting of a main Headquarters/Datacenter location and multiple distributed branch locations all inter-connected over a corporate WAN, the following defines Centralized Trunking and Distributed Trunking as related to the Avaya Communication Manager Survivable SIP Gateway Solution:

Centralized Trunking: All PSTN calls, inbound to the enterprise and outbound from the enterprise, are routed to/from PSTN media gateways centrally located at the Headquarters/Datacenter location.

Distributed Trunking: PSTN call routing can be determined by the originating source location using Avaya Communication Manager Location Based Routing. Local calls from branch locations can be routed back to the same branch location and terminate on the FXO interface of the local AudioCodes MP-114 branch gateway. This has the potential benefits of saving bandwidth on the branch access network, off loading the WAN and centralized media gateway resources, avoiding Toll Charges, and reducing latency.

The sample configuration presented in these Application Notes implements a Centralized Trunking configuration. For a sample configuration of the Avaya Communication Manager Survivable SIP Gateway Solution in a Distributed Trunking configuration, see the Application Notes titled “Avaya Communication Manager Survivable SIP Gateway Solution using the AudioCodes MP-114 in a Distributed Trunking Configuration” [4]. Reference [4] includes an appendix illustrating an approach to using an AudioCodes Gateway FXO port for 911 calls dialed by branch users in normal mode.

2.4. Network Modes

PSTN call routing is further determined within each of the trunking configurations based on the network status of each branch.

Normal Mode: Branch has WAN connectivity to the main Headquarters/Datacenter location and the centralized Avaya SIP call control platform is being used for all branch calls.

Survivable Mode: A Branch has lost WAN connectivity to the Headquarters/Datacenter location. The local branch AudioCodes MP-114 SAS SIP call control is being used for all calls at that branch. Note: if the Avaya SES loses connectivity to the WAN, all branches will go into survivable mode simultaneously.

2.5. Call Flows

This section presents the primary call flows for the Avaya Communication Manager Survivable SIP Gateway Solution in a Centralized Trunking configuration for both Normal Mode and Survivability Mode. The components included in these call flows are based on the components used in the sample configuration presented in these Application Notes.

2.5.1. Centralized Trunking – Normal Mode

Overview:

- **SIP Call Control:** All SIP call control and call routing are provided by the centralized Avaya SES and Avaya Communication Manager.
- **Branch PSTN Outbound Local and Non-Local:** PSTN outbound calls from the branch to all PSTN numbers are routed to a centralized Avaya G650 Media Gateway.
- **Branch PSTN Inbound:** Calls from the PSTN to a branch Direct Inward Dialed (DID) number enter the enterprise network at the Headquarters Avaya G650 Media Gateway.
- **HQ PSTN Inbound:** Calls from the PSTN to a Headquarters DID number enter the enterprise network at the Headquarters Avaya G650 Media Gateway.
- **HQ PSTN Outbound:** Calls to the PSTN from headquarters users are routed out a centralized Avaya G650 Media Gateway.

Call Flows:**1. Avaya 9600 SIP Phone at branch to H.323 IP phone at HQ.**

Avaya 9600 SIP → SES → Avaya Communication Manager → H.323 IP phone

2. Avaya 9600 SIP Phone at branch to Digital/Analog phone at HQ.

Avaya 9600 SIP → SES → Avaya Communication Manager → Avaya Media Gateway → Digital/Analog phone

3. Avaya 9600 SIP Phone at branch to PSTN endpoint

Avaya 9600 SIP → SES → Avaya Communication Manager → Avaya Media Gateway → PSTN phone

4. Avaya 9600 SIP Phone at branch to Avaya 9600 SIP phone at same branch.

Avaya 9600 SIP → SES → Avaya Communication Manager → SES → Avaya 9600 SIP

5. PSTN phone to Branch User DID number assigned to Avaya 9600 SIP phone.

PSTN phone → Avaya G650 Media Gateway → Avaya Communication Manager → SES → Avaya 9600 SIP

Figure 1 presents a high level network view of the Centralized Trunking Normal Mode call flows.




Figure 1

2.5.2. Centralized Trunking – Survivability Mode

Overview:

- **SIP Call Control:** All SIP call control and call routing is provided by the local branch AudioCodes MP-114 SAS.
- **SIP Registration:** All branch Avaya 9600 SIP Phones are transitioned and registered to the AudioCodes MP-114 SAS.
- **All Branch PSTN Outbound:** Local and Non-Local: Routed to the AudioCodes MP-114 FXO interface.
- **Branch PSTN Inbound:** Not Supported

Call Flows:

1. Avaya 9600 SIP Phone at branch to PSTN endpoint – Local & Non-Local Numbers

Avaya 9600 SIP → AudioCodes MP-114 FXO → PSTN phone

2. Avaya 9600 SIP Phone at branch to Avaya 9600 SIP phone at same branch.

Avaya 9600 SIP → AudioCodes MP-114 → Avaya 9600 SIP

Figure 2 presents a high level network view of the Centralized Trunking Survivable Mode call flows.




Figure 2

2.6. Network Topology

The network implemented for the sample configuration shown in **Figure 3** is modeled after an enterprise consisting of a main Headquarters/Datacenter location and multiple distributed branch locations all inter-connected over a corporate WAN. While three branch locations have been included in the sample network, Branch 2 configurations are highlighted.

The Headquarters location hosts an Avaya SES and Avaya Communication Manager providing enterprise wide SIP call control and advanced feature capabilities. The Avaya SES consists of separate Home and Edge servers. Avaya Communication Manager is running on Avaya S8710 redundant servers. A flat network of 30.1.1.0/24 is implemented at Headquarters. The Headquarters network is mapped to IP Network Region 1 which is assigned to Location 1 within Avaya Communication Manager. The Headquarters location also hosts the following centralized components: an Avaya G650 Media Gateway with PSTN trunks, an Avaya Modular Messaging voice mail platform, and an Avaya IP Phone Configuration File Server. The configuration details of these components are considered out of scope of these Application Notes and therefore not included.

The Avaya IP Phone Configuration File Server contains the 46xxsettings.txt file used by Avaya IP phones to set the values of phone configuration parameters. **Section 7** includes the parameters of the 46xxsettings.txt file used by the Avaya 9600 SIP Phone for survivability. The Avaya Modular Messaging voice mail platform can be reached by dialing the internal extension configured as the voice mail access numbers or pilot number, or by dialing a PSTN number that also terminates to Modular Messaging. The internal or private extension is configured in the 46xxsettings.txt file as the default voice mail access number to dial when the Message button of the Avaya 9600 SIP Phone is pressed while the phone is in Normal Mode. The external PSTN number is configured in the 46xxsettings.txt file as an alternate voice mail access number to dial when the Message button of the Avaya 9600 SIP Phone is pressed while the phone is in Survivable Mode. This enables branch users to continue to access the centralized voice mail platform while in Survivable Mode via the PSTN using the Message button. Traditional Message Waiting Indication via the telephone is not available while the phone is in Survivable Mode. The messaging system, such as Avaya Modular Messaging, may enable other methods of notification that a message has been delivered.

The branch locations consist of several Avaya 9600 SIP Phones, an AudioCodes MP-114 Media Gateway with a PSTN Analog trunk on the FXO interface and two analog phones on the FXS interfaces. A flat network has been implemented at each branch. The branch IP network addressing, IP Network Region numbers and Location ID's all use a numbering scheme associated with the branch's number.




Figure 3 – Network Diagram

3. Equipment and Software Versions

The information in these Application Notes is based on the software and hardware versions listed in **Table 1**.

| Device Description | Version |
|--|--|
| Avaya Communication Manager - S8710 Servers | Release 5.1 (R015x.00.1.414.3) |
| Avaya SIP Enablement Services | Release 5.1.1 (5.1.1.415.1) |
| Avaya G650 Media Gateway - IPSI (TN2312BP) - CLAN 1 (TN799DP) - CLAN 2 (TN799DP) - MedPro (TN2302AP) | - HW10 FW042 - HW01 FW026 - HW01 FW024 - HW20 FW117 |
| Avaya one-X Deskphone SIP 9600 Series Models: 9620 and 9630 | R2.4.1.3 |
| AudioCodes MP-114 | 5.60A.010.005 |
| List of Layer 2 Switches Tested at Branch: | |
| Avaya C363T / C364T – PWR | SW 4.5.14 |
| CISCO Catalyst 3750 (or 3750G) PoE 24 | SW 12.2.25-SEB4 |
| CISCO Catalyst Express 500 | SW 12.2.25-SEG3 |
| D-Link DES-1526 PoE Switch (Discontinued. Replacement DES-1228P) | FW 1.00.04 |
| Extreme Networks Summit X450-24t | SW 11.5.1.4 |
| 3com Switch 4400 PWR / 3C17205 SuperStack 3 | SW 3.12 |
| H.323 Fax Adaptor - MultiTech MVP130-AV-FXS | - HW MVP130-AV-FXS-rev.A [B7b8] - FW 2.06.FQ |
| Fax Devices - OKI Okifax 5300 plus - Sharp UX510 - Brother IntelliFax 1360 - HP LaserJet 3050 - HP LaserJet 4345mfp (Avaya Building Facility) - Ricoh Aficio MP2000 | Model FX-050BVP (as is) (as is) FW 20060117 FW 09.131.1 FW 02.00.00 B2765522B |

Table 1 – Software/Hardware Version Information

3.1. Layer 2 Switch

In lab testing, the Avaya 96xx series SIP phones can not acquire the SIP services from the AudioCodes MP-114/118 SIP Gateway under the survivability mode when NETGEAR FS-116P or FS-108P switches are positioned at the branch for the physical connectivity of AudioCodes MP114/118, Avaya 96xx series SIP phones and interface to the enterprise WAN network. If the interface to the WAN network is disconnected or out of service, the address resolution to locate the IP address of the AudioCodes MP114/118 fails at the NETGEAR layer 2 switches. Avaya 96xx series SIP phones can not successfully establish IP connections to the AudioCodes MP114/118. So, the NETGEAR layer 2 switches – FS-116P and FS-108P should be avoided at the branch network setup.

The list of Layer 2 switches as documented in **Table 1** have been verified in the Avaya SIL lab. They provide the adequate functions for SIP Survivability Solutions.

4. Avaya SES

This section describes the configuration steps for the Avaya SES.

4.1. Survivable Call Processors

The Survivable Call Processors feature of the Avaya SES allows survivable SIP servers to be defined and then assigned to individual SES user accounts. The AudioCodes MP-114 at each branch is configured as a Survivable Call Processor within SES. Each individual SES user account is assigned to the AudioCodes MP-114 Survivable Call Processor that matches the branch office where the user is located. The 9600 SIP Phone will download the Survivable Call Processor information from Avaya SES when a user with an assigned Survivable Call Processor logs in.

The following screen illustrates the AudioCodes MP-114 for Branch 2 being added as a Survivable Call Processor. Note the Survivable Call Processor configuration for the AudioCodes MP-114 is set to use the TCP transport protocol on port 5060. The Avaya 9600 SIP Phone will use these same parameters when registering with the AudioCodes MP-114 in survivable mode.

AVAYA Integrated Management
SIP Server Management
Server: 30.1.1.36

Help Exit

Add Survivable Call Processor

Processor Name*: BR2_AC-MP114

IP Address*: 22.1.1.100

Protocols*: ☐ UDP Port 5060
☒ TCP Port 5060
☐ TLS Port 5061

Fields marked * are required.

Add

Top

- Users
 - Address Map Priorities
- Adjunct Systems
- Aggregator
- Certificate Management
- Conferences
- Core Router
 - Emergency Contacts
- Export/Import to ProVision
- Hosts
 - IM logs
- Communication Manager Servers
- Communication Manager Extensions
- Server Configuration
- SIP Phone Settings
- Survivable Call Processors**
 - Add
 - List

Local intranet

The following screen illustrates the list of Survivable Call Processors for the three branches in the sample configuration.

The screenshot shows a Microsoft Internet Explorer window titled "List Survivable Call Processors - Microsoft Internet Explorer". The address bar displays the URL: `https://30.1.1.36/cgi-bin/madmin/do/survivablecallprocessors/list`. The page header includes the Avaya logo and the text "Integrated Management SIP Server Management" with "Server: 30.1.1.36". A left-hand navigation menu lists various system management options, with "Survivable Call Processors" and its "List" sub-option highlighted with red boxes. The main content area, titled "List Survivable Call Processors", contains a table with three columns: "Commands", "Processor Name", and "IP Address". The table lists three processors: BR1_AC-MP114 (11.1.1.100), BR2_AC-MP114 (22.1.1.100), and BR3_AC-MP114 (33.1.1.100). Below the table is a button labeled "Add Another Survivable Call Processor".

| Commands | Processor Name | IP Address |
|-------------|----------------|------------|
| Edit Delete | BR1_AC-MP114 | 11.1.1.100 |
| Edit Delete | BR2_AC-MP114 | 22.1.1.100 |
| Edit Delete | BR3_AC-MP114 | 33.1.1.100 |

[Add Another Survivable Call Processor](#)

4.2. SIP User Accounts

4.2.1. Avaya 9600 SIP Phone Accounts

An account must be created for each Avaya 9600 SIP Phone user by selecting **User → Add** from the Avaya SES left navigation panel. The account must be configured with the Survivable Call Processor for the branch location where the user is located. Each user account must also be configured with a Communication Manager Extension. The screen below, left, illustrates the creation of a user account for Branch 2 of the sample configuration. Note that the BR2_AC-MP114 Survivable Call Processor was selected for this Branch 2 user.

After adding the user account, the Add Communication Manager Extension screen appears similar to the one shown below, right. Enter the appropriate extension, typically the same extension as the Primary Handle of the user account. This Communication Manager Extension must also be created on Avaya Communication Manager as described in **Section 5.1**.



Add User

Primary Handle*

User ID

Password*

Confirm Password*

Host* ▼

First Name*

Last Name*

Address 1

Address 2

Office

City

State

Country

Zip

Survivable Call Processor ▼

Add Communication Manager Extension ☒

Fields marked * are required.

Add



Add Communication Manager Extension

Add Communication Manager extension for user 2221011.

Extension

Communication Manager ▼

Server

Fields marked * are required.

Add

4.2.2. AudioCodes MP-114 SIP User Account

Each AudioCodes MP-114 is configured with a SIP user account on Avaya SES and Extension on Avaya Communication Manager. The following screens illustrate the creation of an SES user account with Communication Manager Extension for the Branch 2 AudioCodes MP-114 of the sample configuration. Note the AudioCodes MP-114 is itself a Survivable Call Processor for Branch 2 resulting in the selection of none for the Survivable Call Processor field. This Communication Manager Extension must also be created on Avaya Communication Manager as described in **Section 5.1**.

 **Add User**

Primary Handle*

2220000

User ID

Password*

••••••

Confirm Password*

••••••

Host*

30.1.1.35

First Name*

Branch 2 - MP114

Last Name*

MP114

Address 1

Branch 2

Address 2

Office

City

State

Country

Zip

Survivable Call Processor

none

Add Communication Manager Extension

☒

Fields marked * are required.

Add

 **Add Communication Manager Extension**

Add Communication Manager extension for user 2220000.

Extension

2220000

Communication Manager Server

C-LAN

Fields marked * are required.

Add

4.2.3. AudioCodes MP-114 FXS Analog Phone SIP User Account

Each AudioCodes MP-114 FXS Analog Phone must be configured with a SIP user account on Avaya SES and Extension on Avaya Communication Manager. The following screens illustrate the creation of an SES user account with Communication Manager Extension for one of the FXS Analog Phones on the Branch 2 AudioCodes MP-114 of the sample configuration. Note the AudioCodes MP-114 is itself a Survivable Call Processor for Branch 2 resulting in the selection of none for the Survivable Call Processor field. This Communication Manager Extension must also be created on Avaya Communication Manager as described in **Section 5.1**.

Add User

| | |
|-------------------------------------|---|
| Primary Handle* | <input type="text" value="2221020"/> |
| User ID | <input type="text"/> |
| Password* | <input type="password" value="•••••"/> |
| Confirm Password* | <input type="password" value="•••••"/> |
| Host* | <input type="text" value="30.1.1.35"/> ▼ |
| First Name* | <input type="text" value="Branch 2 - MP114 FXS"/> |
| Last Name* | <input type="text" value="MP114 FXS"/> |
| Address 1 | <input type="text" value="Branch 2"/> |
| Address 2 | <input type="text"/> |
| Office | <input type="text"/> |
| City | <input type="text"/> |
| State | <input type="text"/> |
| Country | <input type="text"/> |
| Zip | <input type="text"/> |
| Survivable Call Processor | <input type="text" value="none"/> ▼ |
| Add Communication Manager Extension | <input checked="" type="checkbox"/> |

Fields marked * are required.

Add

Add Communication Manager Extension

Add Communication Manager extension for user 2221020.

| | |
|------------------------------|--------------------------------------|
| Extension | <input type="text" value="2221020"/> |
| Communication Manager Server | <input type="text" value="C-LAN"/> ▼ |

Fields marked * are required.

Add

5. Avaya Communication Manager

This section shows the necessary steps to configure Avaya Communication Manager to support the Avaya Communication Manager Survivable SIP Gateway Solution in a Centralized Trunking scenario. It is assumed that the basic configuration on Avaya Communication Manager, the required licensing and the SIP Trunk to Avaya SES have already been administered. See [3] for additional information. All commands discussed in this section are executed on Avaya Communication Manager using the System Access Terminal (SAT).

5.1. Add Stations

A station must be created on Avaya Communication Manager for each SIP User account created in Avaya SES which includes a provisioned Communication Manager Extension. The extension assigned to the Avaya Communication Manager station must match the Communication Manager Extension assignment in Avaya SES.

Use the **add station** command to add a station to Avaya Communication Manager. The add station command for an Avaya 9630 SIP Phone located at Branch 2 using extension 222-1011 is shown below. Because this is a SIP station, only the **Type** and **Name** fields are required to be populated as highlighted in bold. All remaining fields can be left at default values. Of course, feature programming will vary.

| | | | | |
|---------------------------|-------------------------------|----------|------|---|
| add station 2221011 | | Page | 1 of | 6 |
| STATION | | | | |
| Extension: 222-1011 | Lock Messages? n | BCC: | 0 | |
| Type: 9600SIP | Security Code: | TN: | 1 | |
| Port: IP | Coverage Path 1: | COR: | 1 | |
| Name: Branch 2 - User 1 | Coverage Path 2: | COS: | 1 | |
| | Hunt-to Station: | | | |
| STATION OPTIONS | | | | |
| | Time of Day Lock Table: | | | |
| Loss Group: 19 | Personalized Ringing Pattern: | 1 | | |
| | Message Lamp Ext: | 222-1011 | | |
| Speakerphone: 2-way | Mute Button Enabled? | y | | |
| Display Language: english | Expansion Module: | n | | |
| Survivable GK Node Name: | Media Complex Ext: | | | |
| Survivable COR: internal | IP SoftPhone? | n | | |
| Survivable Trunk Dest? y | | | | |
| | IP Video? | n | | |
| | Customizable Labels? | Y | | |

Use the **add off-pbx-telephone station-mapping** command to designate the station created above as a SIP station. The **add off-pbx-telephone station-mapping** command for extension 222-1011 is shown below. Trunk Group 7 is the SIP Trunk to Avaya SES.

| | | | | | | | | |
|---|-------------|--------|----|--------------|-----------|--------|------|---|
| add off-pbx-telephone station-mapping | | | | | | Page | 1 of | 2 |
| STATIONS WITH OFF-PBX TELEPHONE INTEGRATION | | | | | | | | |
| Station | Application | Dial | CC | Phone Number | Trunk | Config | | |
| Extension | | Prefix | | | Selection | Set | | |
| 222-1011 | OPS | - | | 2221011 | 7 | 1 | | |

Repeat the addition of stations and off-pbx telephone station-mappings for each user account added to Avaya SES. The following list command output summarizes the configuration relevant to the sample configuration. Each Avaya SIP Telephone at the branch (e.g., 222-1010 and 222-1011), each analog device connected to an FXS port on the AudioCodes gateway (e.g., 222-1020 and 222-1021), and the station corresponding to the “gateway user” (e.g., 222-0000) can be observed. The corresponding registration of these users to the Avaya SES is shown in **Section 8.3**.

| list off-pbx-telephone station-mapping | | | | | | | Page 1 |
|---|------|----|--------------|------------|--------------|--------------|---------------|
| STATION TO OFF-PBX TELEPHONE MAPPING | | | | | | | |
| Station Extension | Appl | CC | Phone Number | Config Set | Trunk Select | Mapping Mode | Calls Allowed |
| 222-0000 | OPS | | 2220000 | 1 / | 7 | both | all |
| 222-1010 | OPS | | 2221010 | 1 / | 7 | both | all |
| 222-1011 | OPS | | 2221011 | 1 / | 7 | both | all |
| 222-1012 | OPS | | 2221012 | 1 / | 7 | both | all |
| 222-1020 | OPS | | 2221020 | 1 / | 7 | both | all |
| 222-1021 | OPS | | 2221021 | 1 / | 7 | both | all |

5.2. Network Regions

An IP address mapping can be used for network region assignment. The following screen illustrates a subset of the IP network map configuration used to verify these Application Notes. Branch 2 has IP Addresses in 22.1.1.0/24, assigned to network region 12. The Headquarters location has IP Addresses in 30.1.1.0/24, assigned to network region 1. Although not illustrated in these Application Notes, network region assignment can be used to vary behaviors within and between regions. IP devices originating calls also derive their “location” for location-based routing decisions from the network region configuration. Mapping of the branch users to a specific network region can be used to facilitate routing of branch originated calls to the AudioCodes FXO trunk ports in “distributed trunking” scenarios, as described in reference [4].

| display ip-network-map | | | | | | | Page 1 of 32 |
|-------------------------------|----------------|-----------------|--------|------|--------------------|-----------|--------------|
| IP ADDRESS MAPPING | | | | | | | |
| From IP Address | (To IP Address | Subnet or Mask) | Region | VLAN | Emergency Location | Extension | |
| 22 .1 .1 .0 | 22 .1 .1 .255 | 24 | 12 | n | | | |
| 30 .1 .1 .0 | 30 .1 .1 .255 | 24 | 1 | n | | | |

Although not unique to the AudioCodes equipped branch, the following screens illustrate relevant aspects of the network region configuration used to verify these Application Notes. The **Authoritative Domain** “retail.com” matches the SIP domain configured in the Avaya SES, as well as the AudioCodes gateway. The **Codec Set** for intra-region and inter-region calls is set to the default codec set 1, which specifies G.711MU. The “IP-IP Direct Audio” parameters retain the default “yes” allowing direct IP media paths both within the region, and between regions. For example, a call between two telephones at the branch will not consume bandwidth on the WAN, since the media path for a connected call will be local to the branch (i.e., directly between two SIP telephones, or from one SIP telephone to the AudioCodes gateway for a call involving an FXS station and a SIP telephone at the branch).

```
display ip-network-region 12                                     Page 1 of 19

IP NETWORK REGION

Region: 12
Location: 12      Authoritative Domain: retail.com
Name: Branch 2

MEDIA PARAMETERS                      Intra-region IP-IP Direct Audio: yes
Codec Set: 1                      Inter-region IP-IP Direct Audio: yes
UDP Port Min: 2048                      IP Audio Hairpinning? n
UDP Port Max: 3329

DIFFSERV/TOS PARAMETERS                      RTCP Reporting Enabled? y
Call Control PHB Value: 46          RTCP MONITOR SERVER PARAMETERS
Audio PHB Value: 46                      Use Default Server Parameters? y
Video PHB Value: 26

802.1P/Q PARAMETERS
Call Control 802.1p Priority: 6
Audio 802.1p Priority: 6
Video 802.1p Priority: 5          AUDIO RESOURCE RESERVATION PARAMETERS
H.323 IP ENDPOINTS                      RSVP Enabled? n
H.323 Link Bounce Recovery? y
Idle Traffic Interval (sec): 20
Keep-Alive Interval (sec): 5
Keep-Alive Count: 5
```

The following screen illustrates a portion of **Page 3** for network region 12. The connectivity between network regions is specified under the **Inter Network Region Connection Management** heading, beginning on **Page 3**. Codec set 1 is specified for connections between network region 12 and network region 1.

```
display ip-network-region 12                                     Page 3 of 19

Inter Network Region Connection Management

src dst codec direct  WAN-BW-limits  Video  Intervening  Dyn
rgn rgn set   WAN  Units    Total Norm  Prio Shr Regions  CAC IGAR AGL
12  1   1    y    NoLimit          Prio Shr
12  2
12  3
```

5.3. IP Codec Set

The voice codec to be used is defined in the IP Codec Set form. For the sample configuration, a single codec set is used with a single codec defined. The **change ip-codec-set** command is shown below to define Codec Set 1 where the G.711MU codec is entered.


| | | | |
|-----------------------|---------------------|----------------|-----------------|
| change ip-codec-set 1 | | Page 1 of 2 | |
| IP Codec Set | | | |
| Codec Set: 1 | | | |
| Audio Codec | Silence Suppression | Frames Per Pkt | Packet Size(ms) |
| 1: G.711MU | n | 2 | 20 |
| 2: | | | |
| Media Encryption | | | |
| 1: none | | | |
| 2: | | | |
| 3: | | | |

On **Page 2 of 2**, set the “FAX” Mode to “t.38-standard”. This is required for the T.38 fax interoperability testing where a group 3 (G3) or super group 3 (SG3) fax device is connected to the FXS port of AudioCodes MP-114/118 SIP Media Gateway at the branch.

| | | | |
|---|----------------------|-------------|--|
| change ip-codec-set 1 | | Page 2 of 2 | |
| IP Codec Set | | | |
| Allow Direct-IP Multimedia? y | | | |
| Maximum Call Rate for Direct-IP Multimedia: 5120:Kbits | | | |
| Maximum Call Rate for Priority Direct-IP Multimedia: 5120:Kbits | | | |
| | Mode | Redundancy | |
| FAX | t.38-standard | 0 | |
| Modem | off | 0 | |
| TDD/TTY | US | 3 | |
| Clear-channel | n | 0 | |

6. AudioCodes MP-114

This section shows the necessary steps to configure the AudioCodes MP-114 Gateway to support the Avaya Communication Manager Survivable SIP Gateway Solution in a Centralized Trunking scenario. It is assumed that the basic configuration of the AudioCodes MP-114 has already been administered. See [5] and [6] for additional information.

All parameters of the AudioCodes MP-114's used in the sample configuration were set to factory default values prior to configuration. This icon  on the AudioCodes MP-114 configuration screens indicates the corresponding parameter value has been changed. All parameters with this icon shown in the following screens are relevant to the Avaya Communication Manager Survivable SIP Gateway Solution. In some cases, the parameter values used are specific to the sample configuration and may not apply to all environments.

6.1. MP-114 Access

From a web browser, enter the AudioCodes MP-114 IP address in the URL. A pop-up window similar to the one shown below will appear. Enter the appropriate User Name and Password.



The image shows a Windows-style dialog box titled "Enter Network Password". It has a blue title bar with a close button (X) in the top right corner. The main area is light beige. At the top left is a yellow key icon. To its right, the text reads: "This secure Web Site (at 22.1.1.200) requires you to log on." Below this, it says: "Please type the User Name and Password that you use for Realm1." There are two input fields: "User Name" with a dropdown menu showing "Admin", and "Password" with masked characters "XXXXXXXX". Below the password field is a checked checkbox labeled "Save this password in your password list". At the bottom right are two buttons: "OK" and "Cancel".


Once logged in, select the **Full** radio button and **Configuration** from the left navigation panel. The example screen below was captured when two calls were up. Each call was between an Avaya 9600-Series SIP Telephone at the branch and an analog FXS port. This is the reason that ports 1 and 2 show green for “RTP Active”. The FXO line on port 3 was idle. The FXO line on port 4 was not configured.

The screenshot displays the MP-114 FXS_FXO Home Page. On the left, a navigation pane shows the 'Full' configuration mode selected under the 'Configuration' tab. The main area features a status bar with four ports (1, 2, 3, 4) and four indicators: Uplink, Fail, Ready, and Power. Below this, a 'General Information' table lists system details, and a 'Color-Code Key' explains the status indicators.

| General Information | |
|-------------------------|---------------|
| IP Address | 22.1.1.100 |
| Subnet Mask | 255.255.255.0 |
| Default Gateway Address | 22.1.1.254 |
| Firmware Version | 5.60A.010.005 |
| Protocol Type | SIP |
| Analog Ports Number | 4 |

| Color-Code Key | |
|----------------|-----------------|
| ● | Not Connected |
| ○ | Inactive |
| ● | Handset Offhook |
| ● | RTP Active |

6.2. SIP General Parameters

From the left navigation panel, navigate to the SIP General Parameters screen by selecting **Protocol Configuration → Protocol Definition → SIP General Parameters**. The values of the fields with an adjacent  icon have changed from the default.

These key parameter values on this screen instruct the AudioCodes MP-114, when functioning as a media gateway, to use TCP as the transport and listen on port 5070 for SIP messages.

The parameter “Fax Signaling Method” should have the value “T.38 Relay” for the T.38 fax interoperability operations between the fax device connected to the FXS port of AudioCodes MP-114 and another fax device connected to either the Avaya Communication Manager port network and Avaya Media Gateway of the enterprise network or the PSTN line. AudioCodes MP-114 supports the T.38 fax relay over IP using the SIP Re-INVITE message to negotiate the T.38 capabilities.


Once the “T.38 Relay” is set, the default values of parameters at another page “Fax/Modem/CID Settings” should be used for the T.38 Fax over IP. No additional configurations are needed.

SIP General Parameters

Basic Parameter List ▲

▼ SIP General

| | | | |
|-----------------------------------|---------------------------|---|---|
| PRACK Mode | Supported | ▼ | |
| Channel Select Mode | By Dest Phone Number | ▼ | |
| Enable Early Media | Enable | ▼ | ✎ |
| 183 Message Behavior | Alert | ▼ | |
| Session-Expires Time | 0 | | |
| Minimum Session-Expires | 90 | | |
| Session Expires Method | Re-INVITE | ▼ | |
| Asserted Identity Mode | Disabled | ▼ | |
| Fax Signaling Method | T.38 Relay | ▼ | |
| Detect Fax on Answer Tone | Initiate T.38 on Preamble | ▼ | |
| SIP Transport Type | TCP | ▼ | ✎ |
| SIP UDP Local Port | 5070 | | ✎ |
| SIP TCP Local Port | 5070 | | ✎ |
| SIP TLS Local Port | 5071 | | |
| Enable SIPS | Disable | ▼ | |
| Enable TCP Connection Reuse | Enable | ▼ | |
| TCP Timeout | 0 | | |
| SIP Destination Port | 5060 | | |
| Use user=phone in SIP URL | No | ▼ | ✎ |
| Use user=phone in From Header | No | ▼ | |
| Use Tel URI for Asserted Identity | Disable | ▼ | |



Submit

The remaining fields of the SIP General Parameters screens maintain the default values. The continuation of the screens with default values are shown below as a reference.

SIP General Parameters

Basic Parameter List ▲

| | | |
|--|-------------------------------|---|
| Tel to IP No Answer Timeout | 180 | |
| Enable Remote Party ID | Disable | ▼ |
| Add Number Plan and Type to RPI Header | Yes | ▼ |
| Enable History-Info Header | Disable | ▼ |
| Use Source Number as Display Name | No | ▼ |
| Use Display Name as Source Number | No | ▼ |
| Enable Contact Restriction | Disable | ▼ |
| Play Ringback Tone to IP | Don't Play | ▼ |
| Play Ringback Tone to Tel | Play According to Early Media | ▼ |
| Use Tgrp information | Disable | ▼ |
| Enable GRUU | Disable | ▼ |
| User-Agent Information | | |
| SDP Session Owner | AudiocodesGW/ | |
| Subject | | |
| Multiple Packetization Time Format | None | ▼ |
| Enable Semi-Attended Transfer | Disable | ▼ |
| 3xx Behavior | Forward | ▼ |
| Enable P-Charging Vector | Disable | ▼ |
| Enable VoiceMail URI | Disable | ▼ |
| Retry-After Time | 0 | |
| Enable P-Associated-URI Header | Disable | ▼ |
| Enable Reason Header | Enable | ▼ |


Submit

▼ Retransmission Parameters


| | |
|------------------------------------|------|
| SIP T1 Retransmission Timer [msec] | 500 |
| SIP T2 Retransmission Timer [msec] | 4000 |
| SIP Maximum RTX | 7 |













Submit

6.3. Proxy & Registration

From the left navigation panel, navigate to the Proxy & Registration screen by selecting **Protocol Configuration → Protocol Definition → Proxy & Registration**. The values of the fields with an adjacent  icon have changed from the default.

The value of “retail.com” used throughout this form is the SIP Domain name used in the sample configuration and matches the SIP Domain name configured on Avaya SES and Avaya Communication Manager. These parameter values instruct the AudioCodes MP-114 to use the Avaya SES (30.1.1.35) as a SIP Proxy server and a SIP Registrar. The AudioCodes MP-114 should register each FXS station with Avaya SES using TCP transport, refreshing every 3600 seconds.



| Basic Parameter List | | |
|---|---|---|
| Use Default Proxy | Yes | |
| Proxy Set Table |  | |
| Proxy Name | retail.com |  |
| Redundancy Mode | Homing |  |
| Proxy IP List Refresh Time | 60 | |
| Enable Fallback to Routing Table | Disable | |
| Prefer Routing Table | No | |
| Use Routing Table for Host Names and Profiles | Disable | |
| Always Use Proxy | Enable |  |
| Redundant Routing Mode | Proxy |  |
| SIP ReRouting Mode | Send to Proxy |  |
| Enable Registration | Enable |  |
| Registrar Name | | |
| Registrar IP Address | 30.1.1.35 |  |
| Registrar Transport Type | TCP |  |
| Registration Time | 3600 |  |
| Re-registration Timing [%] | 50 | |
| Registration Retry Time | 30 | |
| Registration Time Threshold | 0 | |
| Re-register On INVITE Failure | Disable | |
| ReRegister On Connection Failure | Disable |  |
| Gateway Name | retail.com |  |

The “User Name” and “Password” parameters must match the AudioCodes MP-114 user account created on the Avaya SES in **Section 4.2.2**.

| | | |
|--|----------------|---|
| Gateway Registration Name | | |
| DNS Query Type | A-Record | ▼ |
| Proxy DNS Query Type | A-Record | ▼ |
| Subscription Mode | Per Endpoint | ▼ |
| Number of RTX Before Hot-Swap | 3 | |
| Use Gateway Name for OPTIONS | No | ▼ |
| User Name | 2220000 | ▼ |
| Password | 123456 | ▼ |
| Cnonce | Default_Cnonce | |
| Authentication Mode | Per Endpoint | ▼ |
| Set Out-Of-Service On Registration Failure | Disable | ▼ |
| Challenge Caching Mode | None | ▼ |
| Mutual Authentication Mode | Optional | ▼ |

6.3.1. Changes Required on Proxy & Registration with AudioCodes Version 5.6

Starting with AudioCodes version 5.6, the SAS (stand-alone survivability) application has been enhanced at AudioCodes MP-114 and the following fields should be set to:


| Name | Value |
|------------------------|---------------|
| Redundancy Mode | Homing |
| Redundant Routing Mode | Proxy |

When the AudioCodes MP-114 is in survivability mode of the SAS application, the AudioCodes MP-114 Media Gateway serves as the SIP Proxy as defined in the “Proxy Sets Table”.

The Avaya SES defined as the “home” in the “Proxy Sets Table” takes over the SIP Proxy role once the SAS application of AudioCodes MP-114 detects the restore of the home proxy (Avaya SES Server) and changes back to the normal mode.

The “Proxy Sets Table” referred to by the SAS application should have the Avaya SES Server as its 1st SIP Proxy (home) followed by the AudioCodes MP-114 itself.

6.4. Proxy Sets Table

From the left navigation panel, navigate to the Proxy Sets Table screen by selecting **Protocol Configuration → Protocol Definition → Proxy Sets Table**. The values of the fields with an adjacent  icon have changed from the default.

The Proxy Sets Table with “Proxy Set ID” set to “0” specifies a list of SIP Proxy servers the AudioCodes MP-114 is going to monitor for connectivity health to determine when to become active as a Normal Server or a Survivability Server. In this case, both Avaya SES and AudioCodes MP-114 should be administered and the Avaya SES is positioned as the first Proxy (Home, the Normal Server).

The mechanism used to monitor the Avaya SES is also specified. SIP Options is used in the sample configuration with the AudioCodes MP-114 default Proxy Keep Alive Time of 60 seconds. This results in the AudioCodes MP-114 sending SIP Options messages to the Avaya SES and using the response as an acknowledgement that the Avaya SES is accessible from the branch location. If a response to a SIP Options message is not received, the AudioCodes MP-114 will continue to attempt to contact the Avaya SES for 60 seconds, the Proxy Keep Alive Time value, and then activate its SAS survivable SIP server feature.

Enter the IP Address of the Avaya SES in the Proxy address table and select TCP from the Transport Type drop-down list. Following the Avaya SES, enter the IP address of AudioCodes MP-114 and its supported Transport Type.

For Enable Proxy Keep Alive, select “Using Options” from the drop-down list.

Proxy Sets Table

Proxy Set ID
0

| | Proxy Address | Transport Type |
|---|---------------|----------------|
| 1 | 30.1.1.35 | TCP |
| 2 | 22.1.1.100 | TCP |
| 3 | | |
| 4 | | |
| 5 | | |

Enable Proxy Keep Alive
Using Options

Proxy Keep Alive Time
60

Proxy Load Balancing Method
Disable

Is Proxy Hot Swap
No

Submit

6.5. Coders Table

From the left navigation panel, navigate to the Coders Table screen by selecting **Protocol Configuration → Protocol Definition → Coders**.

Select the codec from the drop-down list that matches the codec configured in Avaya Communication Manager.

Coders Table

| Coder Name | Packetization Time | Rate | Payload Type | Silence Suppression |
|--------------|--------------------|------|--------------|---------------------|
| G.711U-law ▼ | 20 ▼ | 64 ▼ | 0 | Disabled ▼ |
| ▼ | ▼ | ▼ | | ▼ |
| ▼ | ▼ | ▼ | | ▼ |
| ▼ | ▼ | ▼ | | ▼ |
| ▼ | ▼ | ▼ | | ▼ |

Submit

6.6. DTMF & Dialing

From the left navigation panel, navigate to the DTMF & Dialing screen by selecting **Protocol Configuration → Protocol Definition → DTMF & Dialing**. The values of the fields with an adjacent icon have changed from the default.

The value of the “RFC 2833 Payload Type” field must match the value configured for the “Telephone Event Payload Type” for the Avaya Communication Manager SIP Trunks (i.e., on **Page 4** of the SIP Trunk Group form).

Because the full value of the Digit Mapping Rules is not viewable in the screen shot, the full rule used in the sample configuration for Branch 2 is shown below:

1xxx|11xxxxx|22xxxxx|33xxxxx|911|9911|91xxxxxxxxxx|9011x.T

The details of the Digit Mapping Rule are captured in **Table 2**. Refer to [6] for additional information on digit mapping rules.

| Digit String To Match | Sample Configuration Use |
|-------------------------|-------------------------------|
| 1xxx | HQ extensions |
| 11xxxxx 22xxxxx 33xxxxx | Branch extensions |
| 911 9911 | Emergency dialing |
| 91xxxxxxxxxx | North American Numbering Plan |
| 9011x.T | International dialing |

Table 2 – Digit Mapping Rule used in Sample Configuration


DTMF & Dialing

Basic Parameter List ▲

| | | |
|---|-----------------------------------|--|
| Max Digits In Phone Num | 19 | |
| Inter Digit Timeout for Overlap Dialing [sec] | 4 | |
| Declare RFC 2833 in SDP | Yes | |
| 1st Tx DTMF Option | RFC 2833 | |
| 2nd Tx DTMF Option | Not Supported | |
| RFC 2833 Payload Type | 127 | |
| Hook-Flash Option | Not Supported | |
| Digit Mapping Rules | 1xxx 11xxxx 22xxxx 33xxxx 911 991 | |
| Dial Tone Duration [sec] | 16 | |
| Hotline Dial Tone Duration [sec] | 16 | |
| Enable Special Digits | Disable | |
| Default Destination Number | 1000 | |
| Special Digit Representation | Special | |

Submit

6.7. Advanced Parameters

From the left navigation panel, navigate to the Advanced Parameters screen by selecting **Protocol Configuration → SIP Advanced Parameters → Advanced Parameters**. The values of the fields with an adjacent  icon have changed from the default.





Advanced Parameters

Basic Parameter List ▲

▼ General

| | | | |
|--------------------------------|--------------|---|--|
| IP Security | Disable | ▼ | |
| Filter Calls to IP | Don't Filter | ▼ | |
| ⚡ Enable Digit Delivery to Tel | Disable | ▼ | |
| ⚡ Enable Digit Delivery to IP | Disable | ▼ | |
| RTP Only Mode | Disable | ▼ | |
| Enable DID Wink | Disable | ▼ | |
| Delay Before DID Wink | 0 | | |
| Reanswer Time | 0 | | |
| PSTN Alert Timeout | 180 | | |

▼ Disconnect and Answer Supervision

| | | | |
|--------------------------------------|---------|---|---|
| Send Digit Pattern on Connect | | | |
| Enable Polarity Reversal | Enable | ▼ |  |
| Enable Current Disconnect | Enable | ▼ |  |
| Disconnect on Broken Connection | No | ▼ |  |
| Broken Connection Timeout [100 msec] | 100 | | |
| Disconnect Call on Silence Detection | No | ▼ | |
| ⚡ Silence Detection Period [sec] | 120 | | |
| ⚡ Silence Detection Method | None | ▼ |  |
| Enable Fax Re-Routing | Disable | ▼ | |

| | |
|--------------------------------|--|
| ▼ CDR and Debug | |
| CDR Server IP Address | <input type="text"/> |
| CDR Report Level | None ▼ |
| Debug Level | 0 ▼ |
| ▼ Misc. Parameters | |
| Progress Indicator to IP | Not Configured ▼ |
| Enable Busy Out | Disable ▼ |
| Default Release Cause | 3 |
| Max Number of Active Calls | 8 |
| Max Call Duration [min] | 0 |
| ⚡ Enable LAN Watchdog | Disable ▼ |
| Enable Calls Cut Through | Disable ▼ |
| Enable User-Information Usage | Disable ▼ |
| Out-Of-Service Behavior | ! Reorder Tone ▼ |
| Delay After Reset [sec] | 7 |
| ▼ Emergency Calls | |
| Emergency Numbers | 911 9911 <input type="text"/> <input type="text"/> |
| Emergency Calls Regret Timeout | 10 |
| Submit | |

6.7.1. “Disconnect on Broken Connection” Parameter

The AudioCodes gateway provides a parameter called “Disconnect on Broken Connection”. This parameter controls whether the AudioCodes gateway should release the active call if RTP packets are not received within a user-defined timeout period. This timeout period is controlled by the value in the “Broken Connection Timeout [100 msec]” field. The “Disconnect on Broken Connection” parameter should be set to “No”. The active call should not be released if RTP packets are not received within the timeout interval.

Avaya 96xx series SIP phones do not send any RTP packets when active calls are on hold. This hold state is initiated by pressing the [Hold]/[Transfer]/[Conference] softkey buttons on 96xx phones. If this parameter is not set to “No”, the active call is dropped after being on hold for 10 seconds (default). This scenario happens when the AudioCodes gateway is in SAS mode.

6.8. Stand-Alone Survivability

From the left navigation panel, navigate to the Stand-Alone Survivability screen by selecting **Protocol Configuration → SIP Advanced Parameters → Stand-Alone Survivability**. The values of the fields with an adjacent icon have changed from the default.

These key parameter values on this screen enable the AudioCodes MP-114 survivability feature, SAS. The SAS SIP Proxy and SIP Registrar will listen on TCP port 5060 for SIP messages. This must match the Avaya SES Survivable Call Processors configuration in **Section 4.1**.

AudioCodes software version 5.6 introduces two new fields in addition to the fields presented at its previous software version 5.4. The default values of new fields should be used. The “Proxy Sets Table” (see section 6.4) with Proxy Set ID of 0 is used as the SAS Proxy Set. Since the Redundant SAS Proxy Set is not used, set the value to “-1”.

| Name | Value |
|-------------------------|-------|
| SAS Proxy Set | 0 |
| Redundant SAS Proxy Set | -1 |

The screenshot shows the 'SAS Configuration' web interface. At the top, there's a blue header bar with the title 'SAS Configuration'. Below it, on the right, is a link 'Basic Parameter List' with an upward arrow. The main content area contains a table with the following parameters:

| | |
|-------------------------|--------|
| Enable SAS | Enable |
| SAS Local SIP UDP Port | 5060 |
| SAS Default Gateway IP | |
| SAS Registration Time | 200 |
| Short Number Length | 0 |
| SAS Local SIP TCP Port | 5060 |
| SAS Local SIP TLS Port | 5061 |
| SAS Proxy Set | 0 |
| Redundant SAS Proxy Set | -1 |

At the bottom right of the interface is a 'Submit' button with a blue checkmark icon.

6.9. Dest Number IP -> Tel

From the left navigation panel, navigate to **Protocol Configuration → Manipulation Tables → Dest Number IP -> Tel**.

The entry in this table strips the leading 9 from the dialed digit string (for numbers matching the **Destination Prefix**) for IP to PSTN calls while in Survivability Mode. In Normal Mode, this is done by Avaya Communication Manager.

As an example, the dialed number 9 1-732-555-1111 would strip the 9 leaving 1-732-555-1111 presented to the PSTN via the AudioCodes MP-114 FXO interface.

| Destination Phone Number Manipulation Table for IP -> Tel Calls | | | | | | |
|---|--------------------|---------------|-----------|------------------------|------------------------|---------------------------|
| <div> <div>▼</div> <div>Table Index</div> <div>1-10</div> <div>▼</div> </div> | | | | | | |
| | Destination Prefix | Source Prefix | Source IP | Stripped Digits Number | Prefix (Suffix) to Add | Number of Digits to Leave |
| 1 | 917 | * | * | 1 | | |
| 2 | | | | | | |
| 3 | | | | | | |
| 4 | | | | | | |
| 5 | | | | | | |
| 6 | | | | | | |
| 7 | | | | | | |
| 8 | | | | | | |
| 9 | | | | | | |
| 10 | | | | | | |

6.10. IP to Hunt Group Routing

From the left navigation panel, navigate to the IP to Hunt Group Routing Table screen by selecting **Protocol Configuration → Routing Tables → IP to Trunk Group Routing**.

The entries in this table are used by the AudioCodes MP-114 Gateway to route calls originating on IP and terminating on the gateway. Note that the AudioCodes “Hunt Group” concept is not the same as a “Hunt Group” in Avaya Communication Manager. The prefix of the called number is used to determine the selected AudioCodes MP-114 Hunt Group. In the sample configuration, the FXS analog phone numbers are entered explicitly and route to Hunt Group ID 1.

Hunt Group ID 1 consists of two FXS interfaces and Hunt Group ID 2 consists of one FXO interface. Hunt Group to Channel assignments are configured in **Section 6.13**. **Table 4** shows a summary of the Hunt Group assignments.

| Channel | Hunt Group ID |
|---------|---------------|
| FXS 1 | 1 |
| FXS 2 | 1 |
| FXO 3 | 2 |
| FXO 4 | Un-assigned |

Table 4 – Hunt Group Assignments

| | Dest. Host Prefix | Source Host Prefix | Dest. Phone Prefix | Source Phone Prefix | Source IP Address | Hunt Group ID | IP Profile ID | Source IPGroup ID |
|---|-------------------|--------------------|--------------------|---------------------|-------------------|---------------|---------------|-------------------|
| 1 | | | 2221020 | * | * | 1 | 0 | -1 |
| 2 | | | 2221021 | * | * | 1 | 0 | -1 |
| 3 | | | * | * | * | 2 | 0 | -1 |
| 4 | | | | | | | | |
| 5 | | | | | | | | |
| 6 | | | | | | | | |

Submit


6.11. Authentication

From the left navigation panel, navigate to the Authentication screen by selecting **Protocol Configuration → Endpoint Settings → Authentication**.

Enter the SIP user name and password that match the AudioCodes MP-114 FXS Analog Phone User Account created on Avaya SES in **Section 4.2.3**.

Authentication

| Gateway Port | User Name | Password |
|--------------|--------------------------------------|--|
| Port 1 FXS | <input type="text" value="2221020"/> | <input type="password" value="*****"/> |
| Port 2 FXS | <input type="text" value="2221021"/> | <input type="password" value="*****"/> |
| Port 3 FXO | <input type="text"/> | <input type="password"/> |
| Port 4 FXO | <input type="text"/> | <input type="password"/> |


Submit


6.12. Caller Display Information

From the left navigation panel, navigate to the Caller Display Information screen by selecting **Protocol Configuration → Endpoint Settings → Caller Display Information**.

Enter the name/number to be displayed on the called station in SAS mode for each interface. The FXS extension numbers are used in the sample configuration. In normal mode, the display information is controlled by the name and number configuration in Avaya Communication Manager.

Caller Display Information

| Gateway Port | Caller ID/Name | Presentation |
|--------------|----------------|--------------|
| Port 1 FXS | 2221020 | Allowed |
| Port 2 FXS | 2221021 | Allowed |
| Port 3 FXO | | Allowed |
| Port 4 FXO | | Allowed |


Submit

6.13. Endpoint Phone Number

From the left navigation panel, navigate to the Endpoint Phone Number Table screen by selecting **Protocol Configuration → Endpoint Number → Endpoint Phone Number**.

Enter the phone number assignment for each channel of the AudioCodes MP-114 as well as the associated Hunt Group ID. Channels 1 and 2 are the FXS interfaces. Channels 3 and 4 are the FXO interfaces.

Endpoint Phone Number Table

| | Channel(s) | Phone Number | Hunt Group ID | Tel Profile ID |
|---|------------|--------------|---------------|----------------|
| 1 | 1 | 2221020 | 1 | 1 |
| 2 | 2 | 2221021 | 1 | 1 |
| 3 | 3 | 2220000 | 2 | 1 |
| 4 | | | | |

Register

Un-Register

Submit

6.14. Hunt Group Settings

From the left navigation panel, navigate to the Hunt Group Settings screen by selecting **Protocol Configuration → Hunt/IP Group → Hunt Group Settings**.

The settings on this screen configure the method in which calls originating on IP and terminating on the gateway are assigned to channels within each Hunt Group.


Hunt Group 1, containing 2 FXS interfaces for analog phones, is configured to select the proper FXS interface to terminate calls based on the destination phone number.

Hunt Group 2, containing 1 FXO interface to the PSTN, is configured to select any interface in this Hunt Group in a Cyclic Ascending order. Cyclic Ascending is the default. Since only one FXO interface is configured for Hunt Group 2 in the sample configuration, no channel cycling is occurring.


The Contact User field for the Hunt Group 2 entry contains the SIP extension of the MP-114. This value is used in the Contact field of SIP INVITE and Registration messages from the MP-114 Gateway.


| | Hunt Group ID | Channel Select Mode | Registration Mode | Serving IP Group ID | Gateway Name | Contact User |
|---|---------------|----------------------|-------------------|---------------------|--------------|--------------|
| 1 | 1 | By Dest Phone Number | Per Endpoint | | | |
| 2 | 2 | Cyclic Ascending | Per Gateway | | | 2220000 |
| 3 | | | | | | |
| 4 | | | | | | |

6.15. Advanced Applications → FXO Settings

From the left navigation panel, navigate to the FXO Settings screen by selecting **Advanced Applications → FXO Settings**. The values of the fields with an adjacent  icon have changed from the default.

FXO Settings

| | | |
|---|-----------|---|
| Dialing Mode | One Stage |  |
| Waiting for Dial Tone | No | |
| Time to Wait before Dialing [msec] | 1000 | |
| Ring Detection Timeout [sec] | 8 | |
| Reorder Tone Duration [sec] | 255 | |
| Answer Supervision | No | |
| Rings before Detecting Caller ID | 1 | |
| Send Metering Message to IP | No | |
| Disconnect Call on Detection of Busy Tone | Enable | |
| Disconnect On Dial Tone | Disable | |
| Guard Time Between Calls | 1 | |


Submit

6.16. Message Waiting Indication via Stutter Dial Tone for Analog FXS

To enable analog stations connected to the FXS ports to receive stutter dial tone for audible message waiting notification, navigate to **Protocol Configuration → SIP Advanced Parameters → Supplementary Services**. Select “Enable” from the **Enable MWI** drop-down, as shown in the following screen. Press the **Submit** button. When a SIP user registers, or the message waiting status of a registered user changes, the Avaya SES will send SIP NOTIFY messages to update the message waiting status. The AudioCodes Gateway can process these NOTIFY messages, and provide normal dial tone to the FXS ports when there is no message waiting, and stutter dial tone when there is a message waiting (e.g., a new message in an Avaya Modular Messaging mailbox). It is not necessary that the AudioCodes Gateway subscribe to MWI, but this option is also available. Observe that the **Stutter Tone Duration** can also be configured.

The screenshot shows the AudioCodes configuration interface for MP-114 FXS_FXO. The left sidebar contains a tree view with categories like Coders, DTMF & Dialing, SIP Advanced Parameters, and Supplementary Services. The main panel is titled 'Supplementary Services' and contains several configuration sections. The 'Message Waiting Indication (MWI) Parameters' section is expanded, showing various settings. The 'Enable MWI' dropdown is set to 'Enable'. Other settings include MWI Analog Lamp (Disable), MWI Display (Disable), Subscribe to MWI (No), MWI Server IP Address (empty), MWI Server Transport Type (Not Configured), MWI Subscribe Expiration Time (7200), Stutter Tone Duration (2000), and MWI Subscribe Retry Time (120). The 'Conference' section is also visible, with 'Enable 3-Way Conference' set to 'Disable', 'Establish Conference Code' set to '!', and 'Conference ID' set to 'conf'. At the bottom, there are buttons for 'Submit', 'Subscribe to MWI', and 'Unsubscribe to MWI'.

| Supplementary Services | |
|---|-------------------|
| Enable Caller ID | Disable |
| Hook-Flash Code | |
| Caller ID Type | Standard Bellcore |
| ▼ Message Waiting Indication (MWI) Parameters | |
| Enable MWI | Enable |
| MWI Analog Lamp | Disable |
| MWI Display | Disable |
| Subscribe to MWI | No |
| MWI Server IP Address | |
| MWI Server Transport Type | Not Configured |
| MWI Subscribe Expiration Time | 7200 |
| Stutter Tone Duration | 2000 |
| MWI Subscribe Retry Time | 120 |
| ▼ Conference | |
| Enable 3-Way Conference | Disable |
| Establish Conference Code | ! |
| Conference ID | conf |

Buttons: Submit, Subscribe to MWI, Unsubscribe to MWI

6.17. Disable FXO Disconnect on Busy Tone Detection (Optional)

The AudioCodes Gateway can automatically detect when a call is connected to busy tone from the PSTN on an FXO line, and disconnect the call if desired. For the sample configuration, it is recommended that this feature be disabled. If the feature remains enabled, and an Avaya SIP Telephone in the branch makes a call to a PSTN number (in SAS mode) that is busy (e.g., a standard home telephone that is in use with no call waiting and no voice mail), the Avaya SIP Telephone will hear busy tone for a few seconds, and then the call appearance will be cleared. Although this frees the FXO more quickly, it may be perceived by the telephone user as a problem with the system. With the feature disabled as shown below, the Avaya SIP Telephone would simply hear busy tone until hanging up the telephone.

Navigate to **Advanced Applications → FXO Settings**. Using the drop-down menu, change the **Disconnect Call on Detection of Busy Tone** parameter to the value **Disable**. Click **Submit** in the lower right corner of the screen (not shown in the abbreviated screen below).

The screenshot shows the 'FXO Settings' configuration page. The left sidebar contains a tree view with the following structure:

- Configuration
- Management
- Status & Diagnostics
- Scenarios
- Search
- Basic (selected)
- Full
- Network Settings
- Media Settings
- Security Settings
- Protocol Configuration
 - Protocol Definition
 - SIP Advanced Parameters
 - Advanced Parameters
 - Supplementary Services
 - Metering Tones
 - Charge Codes
 - Keypad Features
 - Stand-Alone Survivability
 - Manipulation Tables
 - Routing Tables
 - Profile Definitions
 - Endpoint Settings
 - Endpoint Number
 - Hunt/IP Group
- Advanced Applications
 - Voice Mail Settings
 - RADIUS Parameters
 - FXO Settings (selected)

The main configuration area for 'FXO Settings' contains the following parameters:

| Parameter | Value |
|---|-----------|
| Dialing Mode | One Stage |
| Waiting for Dial Tone | No |
| Time to Wait before Dialing [msec] | 1000 |
| Ring Detection Timeout [sec] | 8 |
| Reorder Tone Duration [sec] | 255 |
| Answer Supervision | No |
| Rings before Detecting Caller ID | 1 |
| Send Metering Message to IP | No |
| Disconnect Call on Detection of Busy Tone | Disable |
| Disconnect On Dial Tone | Disable |
| Guard Time Between Calls | 1 |

6.18. .ini File


The AudioCodes MP-114 utilizes an initialization text file with a .ini extension. The .ini file contains MP-114 parameters that have been set by the WebUI, such as the parameters described in the previous sections. See [6] for additional information on the ini configuration file.

As of the AudioCodes MP-114 firmware version listed in **Table 1**, the following parameters are not configurable from the WebUI and must be modified directly in the .ini file.


- SASSurvivabilityMode
- ReliableConnectionPersistentMode
- CurrentDisconnectDuration

While the .ini file can be edited directly with a text editor, it is recommended to use the .ini file editing capability of the AudioCodes Web AdminPage. The AdminPage can be accessed from a browser by entering the following URL: <http://<MP-114 IP Address>/AdminPage>.

The AdminPage, similar to the one shown below, will be displayed. Select **ini Parameters** to access the .ini parameter editing screen.



The .ini editing screen, similar to the one shown below, will be displayed.




6.18.1. SASSurvivabilityMode


The **SASSurvivabilityMode** parameter determines how the SAS feature of the AudioCodes MP-114 will operate. By default, **SASSurvivabilityMode** is set to a value of 0 which enables SAS to be able to accept SIP Registrations while the AudioCodes MP-114 can simultaneously communicate with the Avaya SES.

SASSurvivabilityMode must be changed from the default value of 0 to a value of 2. This sets SAS to become active and only accept SIP Registrations when it is not able to communicate with Avaya SES.

To verify the current value of a parameter using the AdminPage, enter the parameter name in the top “Parameter Name” field and leave the “Enter Value” field blank. Click the adjacent “Apply New Value” button. The “Output Window” of the following screen shows the **SASSurvivabilityMode** parameter is currently set to the default value of 0.



To change the value of a parameter, enter the new parameter value in the “Enter Value” field. The following screen shows the **SASSurvivabilityMode** parameter being set to 2. The text appended to the “Output Window” shows the **SASSurvivabilityMode** parameter was successfully set to a value of 2.



6.18.2. ReliableConnectionPersistentMode

The **ReliableConnectionPersistentMode** parameter determines how the AudioCodes MP-114 establishes TCP connections. When **ReliableConnectionPersistentMode** is set to the default value of 0, all TCP/TLS connections established by the AudioCodes MP-114 are non-persistent connections.

ReliableConnectionPersistentMode must be changed from the default value of 0 to a value of 1. This configures the AudioCodes MP-114 to establish all TCP connections as persistent connections that will not be prematurely released.

The following screen shows the value of the **ReliableConnectionPersistentMode** parameter was successfully set to a value of 1.

The screenshot shows a web browser window titled "Admin Page - Microsoft Internet Explorer". The address bar shows "http://22.1.1.200/AdminPage". The browser's toolbar includes buttons for Back, Forward, Stop, Home, Search, Favorites, and a toolbar with icons for SnagIt, Links, and Settings. The main content area has a left sidebar with links: "Image Load to Device", "ini Parameters", and "Back to Main". The main area contains two forms for parameter configuration. The top form is for "Parameter Name: RELIABLECONNECTIONPERSISTENT" with "Enter Value: 1" and an "Apply New Value" button. The bottom form is for "Parameter Name: 3GDelErrorSDU" with an empty "Enter Value" field and an "Apply New Value" button. Below these forms is an "Output Window" displaying the following text:

```
Parameter Name: RELIABLECONNECTIONPERSISTENTMODE
The Value is invalid:
Parameter Current Value: 0
Parameter Description:if set to 1 - All TCP/TLS connections will be set as
persistent and will not be released

Parameter Name: RELIABLECONNECTIONPERSISTENTMODE
Parameter New Value:1
Parameter Description:if set to 1 - All TCP/TLS connections will be set as
persistent and will not be released
```

6.18.3. CurrentDisconnectDuration

The **CurrentDisconnectDuration** parameter determines the duration of time in milliseconds the analog line current is dropped indicating a disconnect pulse to the AudioCodes MP-114 FXO interfaces. For the sample configuration, this parameter was changed from the default value of 900ms to 600ms. This was required to obtain a proper disconnect on the AudioCodes MP-114 FXO Analog Trunk from the PSTN service provider.

Note: The need to change **CurrentDisconnectDuration** may not apply to all environments and will be determined by the PSTN service provider configuration of the analog trunk.

Also, the parameters **EnableReversalPolarity** and **EnableCurrentDisconnect** must both be enabled for **CurrentDisconnectDuration** to be active. The **EnableReversalPolarity** and **EnableCurrentDisconnect** parameters are both configured on the Advanced Parameters screen as shown in **Section 6.7**.


The following screen shows the value of the **CurrentDisconnectDuration** parameter was successfully set to a value of 600.

The screenshot shows a web browser window titled "Admin Page - Microsoft Internet Explorer" with the address bar displaying "http://22.1.1.200/AdminPage". The browser's toolbar includes buttons for Back, Forward, Stop, Home, Search, Favorites, and a toolbar with icons for various applications. The main content area of the browser shows the "Admin Page" interface. On the left side, there is a vertical navigation menu with links: "Image Load to Device", "ini Parameters", and "Back to Main". The main content area has a form with two sections. The top section is for editing the "CURRENTDISCONNECTDURATION" parameter. It has a "Parameter Name:" label with a dropdown menu showing "CURRENTDISCONNECTDURATION", an "Enter Value:" label with a text input field containing "600", and an "Apply New Value" button. The bottom section is for editing the "3GDelErrorSDU" parameter. It has a "Parameter Name:" label with a dropdown menu showing "3GDelErrorSDU", an "Enter Value:" label with an empty text input field, and an "Apply New Value" button. Below the form is an "Output Window" displaying the following text: "Parameter Name: CURRENTDISCONNECTDURATION", "The Value is invalid:", "Parameter Current Value: 900", "Parameter Description: Defines the current-disconnect duration (in msec).", "Parameter Name: CURRENTDISCONNECTDURATION", "Parameter New Value: 600", "Parameter Description: Defines the current-disconnect duration (in msec).".


6.19. Saving Changes to the AudioCodes Gateway



The **Submit** button on the screens in the **Configuration** tab will save changes to the volatile

memory (RAM) only. To save settings to non-volatile memory (flash), the  **Burn** button at the top of the screen can be used. Only configuration “burned” to non-volatile memory will be available after a hardware reset or power fail.

An alternate means to access the “burn” function is via the **Management** tab. Navigate to **Management Configuration → Maintenance Actions**. The **BURN** button illustrated in the following screen may be used. The on-screen text below should be self-explanatory.



The screenshot shows the AudioCodes MP-114 FXS_FXO web interface. The top navigation bar includes the AudioCodes logo, the device name 'MP-114 FXS_FXO', and buttons for 'Submit', 'Burn', 'Device Actions', 'Home', 'Help', and 'Log off'. The left sidebar has tabs for 'Configuration', 'Management', and 'Status & Diagnostics'. Under 'Management', there are sub-tabs for 'Scenarios' and 'Search'. A tree view on the left shows the following structure:

- Basic (selected)
- Full
- Management Configuration
 - Management Settings
 - Regional Settings
 - Maintenance Actions (selected)
- Software Update
 - Load Auxiliary Files
 - Software Upgrade Wizard
 - Configuration File

The main content area is titled 'Maintenance Actions' and contains three sections:

- Reset Configuration**
 - Reset Board: **Reset** button
 - Burn To FLASH: Yes (selected)
 - Graceful Option: No (selected)
- LOCK / UNLOCK**
 - Lock: **LOCK** button
 - Graceful Option: No (selected)
 - Current Admin State: UNLOCKED
- Save Configuration**
 - Burn To FLASH: **BURN** button

Below these sections, there is explanatory text:

For Reset Board :
If you choose not to burn the device's configuration into flash memory, all changes made since the last time the configuration was burned will be lost after the device is reset.

For Save Configuration: Saving configuration to flash memory may cause some temporary degradation in voice quality, therefore, it is recommended to perform this during low-traffic periods

7. Avaya 9600 SIP Phone

The configuration parameters of the Avaya 9600 SIP Phone specific to SIP Survivability and the sample configuration are described in this section. See reference [1] before setting or changing the parameters shown below.

| 46xxsettings.txt Parameter Name | Value Used in Sample Configuration | Description |
|------------------------------------|--|---|
| SIP_CONTROLLER_LIST | 30.1.1.35 | <p>A priority list of SIP Servers for the phone to use for SIP services.</p> <p>The sample configuration uses the Avaya SES Survivable Call Processor feature to specify the details of the survivable server. As a result, only the value of the Avaya SES IP Address is specified. The port and transport use the default values of 5061 and TLS when not specified.</p> <p>This parameter is provided as an alternative method to the Avaya SES Survivable Call Processor for setting each phones SIP Server list.</p> <p>The example below shows the values used for this parameter for a phone in Branch 2 if the Avaya SES Survivable Call Processor method were not used. The Avaya SES is the first priority SIP Server listed using the default port and transport of 5061 and TLS. Separated by a comma, the Branch 2 AudioCodes MP-114 is the next priority SIP Server using port 5070 and TCP transport.</p> <p>30.1.1.35,22.1.1.100:5070;transport=tcp</p> |

| | | |
|------------------------------|--------------|--|
| | | <p>The SIP Server list for each branch would require different values for the SIP_CONTROLLER_LIST, e.g. the list for Branch 1 phones will include the Avaya SES and the Branch 1 AudioCodes MP-114 while the list for Branch 2 phones will include the Avaya SES and the Branch 2 AudioCodes MP-114. To accomplish this, the GROUP system value mechanism can be implemented as described in [1].</p> |
| FAILBACK_POLICY | Auto | <p>While in Survivable Mode, determines the mechanism to use to fail back to the centralized SIP Server.</p> <p>Auto = the phone periodically checks the availability of the primary controller and dynamically fails back.</p> |
| FAST_RESPONSE_TIMEOUT | 2 | <p>The timer terminates SIP INVITE transactions if no SIP response is received within the specified number of seconds after sending the request. Useful when a phone goes off-hook after connectivity to the centralized SIP Server is lost, but before the phone has detected the connectivity loss.</p> <p>The default value of 4 seconds may be retained if desired.</p> <p>After the SIP INVITE is terminated, the phone immediately transitions to Survivable Mode.</p> |
| MSGNUM | 1010 | <p>The number dialed when the Message button is pressed and the phone is in Normal Mode.</p> |
| PSTN_VM_NUM | 917325551010 | <p>The number dialed when the Message button is pressed and the phone is in Survivable Mode.</p> |
| RECOVERYREGISTERWAIT | 60 | <p>A Reactive Monitoring Interval. If no response to a "maintenance check" REGISTER request is received within the timeout period, the phone will retry the monitoring attempt after a randomly selected delay of 50% - 90%</p> |

| | | |
|-----------------------------------|---|---|
| | | of this parameter. |
| DIALPLAN | 1xxx 11xxxxx 22 xxxxx 33xxxxx 9 11 9911 91xxxxx xxxxx 9011x+ | <p>Enables the acceleration of dialing when the WAN is down and the AudioCodes SAS is active, by defining the dial plan used in the phone. In normal mode, the Avaya telephone learns the dial plan from SES and does not require these settings to expedite dialing.</p> <p>The dialplan values used in the phone will generally match the values used by the AudioCodes MP-114 in Section 6.6.</p> <p>See [1] for additional format details on the DIALPLAN parameter.</p> |
| DISCOVER_AVAYA_ENVIRONMENT | 1 | Automatically determines if the active SIP Server is an Avaya server or not. |
| SIPREGPROXYPOLICY | alternate | <p>A policy to control how the phone treats a list of proxies in the SIP_CONTROLLER_LIST parameter</p> <p>alternate = remain registered with only the active controller</p> <p>simultaneous = remain registered with all available controllers</p> |
| SIPDOMAIN | | The enterprise SIP domain. Must be the same for all SIP controllers in the configuration. SIPDOMAIN is set to “retail.com” in the sample configuration. |

8. Verification and Troubleshooting


8.1. AudioCodes MP-114 Call Routing Status

From the left navigation panel, select the **Status & Diagnostics** tab, then navigate to the Call Routing Status screen by selecting **Gateway Statistics → Call Routing Status**.

The Call Routing Status screens from the Branch 2 AudioCodes MP-114 while in Normal Mode and Survivable Mode are shown below.

Normal Mode:

The status shows all call routing is using the centralized Avaya SES IP address named retail.com which is in an “OK” state.




The image shows a window titled "Call Routing Status". Inside the window is a table with three rows. The first row is a header with a dropdown arrow on the left. The second row shows "Current Call-Routing Method" as "Proxy/GK". The third row shows "Current Proxy" as "retail.com (30.1.1.35)". The fourth row shows "Current Proxy State" as "OK".

| Current Call-Routing Method | Proxy/GK |
|-----------------------------|------------------------|
| Current Proxy | retail.com (30.1.1.35) |
| Current Proxy State | OK |

Survivable Mode:

The status shows all call routing is using the internal AudioCodes SAS Proxy named retail.com and the Current Proxy State is in the “OK” state as presented by AudioCodes Software Version 5.6.



The image shows a window titled "Call Routing Status". Inside the window is a table with three rows. The first row is a header with a dropdown arrow on the left. The second row shows "Current Call-Routing Method" as "Proxy/GK". The third row shows "Current Proxy" as "retail.com (22.1.1.100)". The fourth row shows "Current Proxy State" as "OK". A mouse cursor is visible in the center of the window.

| Current Call-Routing Method | Proxy/GK |
|-----------------------------|-------------------------|
| Current Proxy | retail.com (22.1.1.100) |
| Current Proxy State | OK |


8.2. SAS/SBC Registered Users

From the left navigation panel, select **Status & Diagnostics** then navigate to the SAS/SBC Registered Users screen by selecting **Gateway Statistics → SAS/SBC Registered Users**.

The SAS Registered Users screens from the Branch 2 AudioCodes MP-114 while in Normal Mode and Survivable Mode are shown below.

Normal Mode:


The screen shows no active SAS users.



| Address Of Record | Contact |
|-------------------|---------|
|-------------------|---------|

Survivable Mode:

The screen shows three Branch 2 Avaya 9600 SIP Phones actively registered to the AudioCodes MP-114 SAS.



| Address Of Record | Contact |
|--------------------|--|
| 2221010@RETAIL.COM | <sip:2221010@22.1.1.180;avaya-sc-enabled;transport=tcp>;q=1;expires=7200;reg-id=2;+sip.instance="urn:uuid:00000000-0000-1000-8000-00073bd274d0"> |
| 2221011@RETAIL.COM | <sip:2221011@22.1.1.198;avaya-sc-enabled;transport=tcp>;q=1;expires=7200;reg-id=2;+sip.instance="urn:uuid:00000000-0000-1000-8000-00073bb5aad2"> |
| 2221012@RETAIL.COM | <sip:2221012@22.1.1.183;avaya-sc-enabled;transport=tcp>;q=1;expires=7200;reg-id=2;+sip.instance="urn:uuid:00000000-0000-1000-8000-00040dec5487"> |

8.3. SES Registered Users

The following screen shows Avaya SES registered users from Branch 2 in normal mode, when the WAN is up. This screen can be accessed from the Avaya SES Home server by clicking on **Users → Search Registered Users**.

Note the user registration for the “gateway user” (first record), the three Avaya SIP phones (second, third, and fourth records), and the two FXS stations connected to the AudioCodes gateway at the branch (last two records).

| Handle and Name | Address | Expires |
|---|--|-------------------------------|
| <input type="checkbox"/> 2220000@retail.com MP114, Branch 2 - MP114 | sip:2220000@22.1.1.100:5070;transport=tcp | Tue, 03 Feb 2009 11:17:09 EST |
| <input type="checkbox"/> 2221010@retail.com User 1, SIE - BR2 | sip:2221010@22.1.1.180:5061;avaya-sc-enabled;transport=tls | Tue, 03 Feb 2009 11:10:08 EST |
| <input type="checkbox"/> 2221011@retail.com User 1, Branch 2 - User 1 | sip:2221011@22.1.1.198:5061;avaya-sc-enabled;transport=tls | Tue, 03 Feb 2009 11:06:20 EST |
| <input type="checkbox"/> 2221012@retail.com User 3, SIE - BR2 | sip:2221012@22.1.1.183:5061;avaya-sc-enabled;transport=tls | Tue, 03 Feb 2009 10:55:49 EST |
| <input type="checkbox"/> 2221020@retail.com MP114 FXS, Branch 2 - MP114 FXS | sip:2221020@22.1.1.100:5070;transport=tcp | Tue, 03 Feb 2009 11:17:09 EST |
| <input type="checkbox"/> 2221021@retail.com FXS User, SIE - BR2 | sip:2221021@22.1.1.100:5070;transport=tcp | Tue, 03 Feb 2009 11:17:09 EST |

8.4. Timing Expectations for Fail-over to AudioCodes SAS Mode

This section is intended to set *approximate* expectations for the length of time before Avaya 9600 SIP Telephones in the branch will acquire service from the AudioCodes Gateway, when a failure occurs such that the branch is unable to communicate with the central Avaya SES. In practice, failover timing will depend on a variety of factors. Using the configuration described in these Application Notes, when the IP WAN is disconnected, idle Avaya SIP Telephones in the branch will typically display the “Acquiring Service...” screen in approximately 45 seconds. With multiple identical idle phones in the same branch, it would not be unusual for some phones to register to the AudioCodes Gateway for SAS service before others, with the earliest registering in approximately one minute and the latest registering in approximately two minutes. In other words, the Avaya SIP Telephones in the branch can typically place and receive calls processed by the AudioCodes Gateway approximately two minutes after the branch is isolated by a WAN failure.

8.5. Timing Expectations for Fail-back to Normal Mode

This section is intended to set *approximate* expectations for the length of time before Avaya 9600 SIP Telephones registered to the AudioCodes Gateway in SAS mode will re-acquire service from the Avaya SES for normal service, once the branch communications with the central Avaya SES is restored. In practice, failover timing will depend on a variety of factors. Using the configuration described in these Application Notes, when the IP WAN is restored such that the branch telephones can again reach the Avaya SES, idle Avaya SIP Telephones in the branch will typically be registered with the Avaya SES in one minute or less. With multiple identical idle phones in the same branch, it would not be unusual for some phones to register back with the SES before others. For example, some may register within 30 seconds, others within 45 seconds, with others registering in approximately one minute.

9. Conclusion

SIP endpoints deployed at remote branch locations risk a loss of service if a break in connectivity to the centralized SIP call control platform occurs. Connectivity loss can be caused by WAN access problems being experienced at the branch or network problems at the centralized site blocking access to the Avaya SIP call control platform. These Application Notes present the configuration steps to implement the Avaya Communication Manager Survivable SIP Gateway Solution to avoid service disruptions to these remote branch SIP endpoints.

10. References

Avaya Application Notes and additional resources can be found at the following web address <http://www.avaya.com/gcm/master-usa/en-us/resource/>. Avaya Product Support web site can be found at the following web address <http://support.avaya.com/>.

The following Avaya references are relevant to these Application Notes:

- [1] *Avaya one-X Deskphone Edition for 9600 Series SIP IP Telephones Administrator Guide*
Doc ID: 16-601944, Issue 4, December 2008
- [2] *Administering SIP Enablement Services on the Avaya S8300 Server*,
Doc ID: 03-602508, Issue 1, January 2008
- [3] *Administrator Guide for Avaya Communication Manager*,
Doc ID: 03-300509, Issue 4, January 2008
- [4] *Avaya Communication Manager Survivable SIP Gateway Solution using the AudioCodes MP-114 in a Distributed Trunking Configuration – Issue 1.1*

The following AudioCodes references are relevant to these Application Notes:

- [5] *AudioCodes SIP MP-124 & MP-11x Release Notes Version 5.6*,
Version 5.6
<http://www.audiocodes.com/filehandler.ashx?fileid=42853>
- [6] *AudioCodes SIP MP-124 & MP-11x User's Manual Version 5.6*
<http://www.audiocodes.com/filehandler.ashx?fileid=36362>

11. Change History

| Issue | Date | Reason |
|-------|------------|---|
| 1.1 | 04/27/2009 | Revised version with additional configuration changes on AudioCodes MP-114 which has been upgraded to software version 5.6. Without these changes, the FXS stations of MP-114 fail to make outgoing calls when the MP-114 is in Survivability Mode. Support of T.38 Fax Relay mode at AudioCodes MP-114. |
| 1.0 | 03/14/2009 | First Published version. The AudioCodes MP-114 runs software version 5.4 in the sample configuration. |

©2009 Avaya Inc. All Rights Reserved.

Avaya and the Avaya Logo are trademarks of Avaya Inc. All trademarks identified by ® and ™ are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners. The information provided in these Application Notes is subject to change without notice. The configurations, technical data, and recommendations provided in these Application Notes are believed to be accurate and dependable, but are presented without express or implied warranty. Users are responsible for their application of any products specified in these Application Notes.

Please e-mail any questions or comments pertaining to these Application Notes along with the full title name and filename, located in the lower right corner, directly to the Avaya DevConnect Program at devconnect@avaya.com.