



## **Avaya Solution & Interoperability Test Lab**

---

# **Application Notes for Configuring Level 3 SIP Trunking with Avaya Aura® Communication Manager Access Element 5.2.1, Avaya Aura® Session Manager 6.1 and Avaya Session Border Controller for Enterprise – Issue 1.0**

### **Abstract**

These Application Notes describe the steps to configure Session Initiation Protocol (SIP) Trunking between Level 3 SIP Trunking and an Avaya SIP-enabled enterprise solution. The Avaya solution consists of Avaya Aura® Session Manager 6.1, Avaya Aura® Communication Manager Access Element 5.2.1, Avaya Session Border Controller for Enterprise and various Avaya endpoints. Level 3 is a member of the Avaya DevConnect Service Provider program.

Information in these Application Notes has been obtained through DevConnect compliance testing and additional technical discussions. Testing was conducted via the DevConnect Program at the Avaya Solution and Interoperability Test Lab.

# 1. Introduction

These Application Notes describe the steps to configure Session Initiation Protocol (SIP) Trunking between Level 3 SIP Trunking and an Avaya SIP-enabled enterprise solution. The Avaya solution consists of Avaya Aura® Session Manager 6.1, Avaya Aura® Communication Manager Access Element 5.2.1, Avaya Session Border Controller for Enterprise and various Avaya endpoints.

Customers using this Avaya SIP-enabled enterprise solution with Level 3 SIP Trunking are able to place and receive PSTN calls via a broadband WAN connection with SIP. This converged network solution is an alternative to traditional PSTN trunks such as ISDN-PRI.

## 2. General Test Approach and Test Results

The general test approach was to connect a simulated enterprise site to Level 3 SIP Trunking via the public Internet and exercise the features and functionality listed in **Section 2.1**. The simulated enterprise site was comprised of Communication Manager, Session Manager and Avaya Session Border Controller for Enterprise.

DevConnect Compliance Testing is conducted jointly by Avaya and DevConnect members. The jointly-defined test plan focuses on exercising APIs and/or standards-based interfaces pertinent to the interoperability of the tested products and their functionalities. DevConnect Compliance Testing is not intended to substitute full product performance or feature testing performed by DevConnect members, nor is it to be construed as an endorsement by Avaya of the suitability or completeness of a DevConnect member's solution.

### 2.1. Interoperability Compliance Testing

To verify SIP trunking interoperability, the following features and functionality were covered during the interoperability compliance test. Please note that SIP endpoints were not tested since SIP endpoints are not supported on a Communication Manager Access Element.

- Avaya Session Border Controller for Enterprise (SBCE) provides Digest Authentication to Level 3 on behalf of Communication Manager. INVITE and REFER messages sent from Communication Manager are challenged by Level 3. The challenge is answered by the Avaya SBCE.
- Response to SIP OPTIONS queries
- Incoming PSTN calls to various phone types including H.323, digital, and analog telephones at the enterprise. All inbound PSTN calls were routed to the enterprise across the SIP trunk from the service provider.
- Outgoing PSTN calls from various phone types including H.323, digital, and analog telephones at the enterprise. All outbound PSTN calls were routed from the enterprise across the SIP trunk to the service provider.
- Inbound and outbound PSTN calls to/from Avaya one-X® Communicator (soft client) Avaya one-X® Communicator can place calls from the local computer or control a remote phone. Both of these modes were tested. Avaya one-X® Communicator also

supports two Voice Over IP (VoIP) protocols: H.323 and SIP. Only the H.323 version of Avaya one-X® Communicator was tested.

- Various call types including: local, long distance, international, outbound toll-free, operator assisted calls, and local directory assistance (411).
- Codec G.711MU and G.729A
- DTMF transmission using RFC 2833
- Caller ID presentation and Caller ID restriction
- Response to incomplete call attempts and trunk errors
- Voicemail navigation for inbound and outbound calls
- Voicemail Message Waiting Indicator (MWI)
- User features such as hold and resume, internal call forwarding, transfer, and conference
- Off-net call forwarding and mobility (extension to cellular)
- T.38 Fax
- Network Call Redirection using the SIP REFER method

Items not supported or not tested include the following:

- Inbound toll-free and emergency calls are supported but were not tested.
- Call redirection requested by a 302 response is not supported by Level 3.

## 2.2. Test Results

Interoperability testing of Level 3 SIP Trunking was completed with successful results for all test cases with the exception of the observations/limitations described below.

- **Max-Forwards:** On incoming PSTN calls to the enterprise, the Max-Forwards value in the incoming SIP INVITE is set to a value of 9. This value was observed to be too small to allow the message to traverse all the SIP hops internal to the enterprise to reach the destination in all cases. Thus, the Avaya SBCE was used to increase this value when the INVITE arrived at the Avaya SBCE from the network. (See **Section 7.6.1**)
- **No Matching Codec Offered:** If the Communication Manager SIP trunk is improperly configured to have no matching codec with the service provider and an outbound call is placed, the service provider returns a “480 Temporarily Unavailable” response instead of a “488 Not Acceptable Here” response. The user hears fast busy.
- **Calling Party Number (PSTN transfers):** The calling party number displayed on the PSTN phone is not updated to reflect the true connected party on calls that are transferred to the PSTN. After the call transfer is complete, the calling party number displays the number of the transferring party and not the actual connected party. Communication Manager provides the new connected party information by updating the Contact header in an UPDATE message. Level 3 does not use the UPDATE message for this purpose.
- **EC500 use of idle-call appearance:** Outbound calls from an EC500 remote phone to the PSTN via the idle-call appearance feature name extension (FNE) are dropped after 30 seconds.
- **Avaya one-X® Communicator Conferencing:** When conferencing two PSTN calls using Avaya one-X® Communicator, some call legs were observed to have no audio if

the conference was initiated by clicking the Conference button during an PSTN active call, then entering the added PSTN party number. Conference calls were successful if the first PSTN active call was first put on hold, a new PSTN call was placed and answered and lastly the Conference button was selected to conference the two calls together.

## 2.3. Support

For technical support on Level 3 SIP Trunking, contact Level 3 using the Customer Center links at [www.level3.com](http://www.level3.com) or by calling 1-877-2LEVEL3.

Avaya customers may obtain documentation and support for Avaya products by visiting <http://support.avaya.com>.


## 3. Reference Configuration

**Figure 1** illustrates a sample Avaya SIP-enabled enterprise solution connected to Level 3 SIP Trunking. This is the configuration used for compliance testing.

The Avaya components used to create the simulated customer site included:

- Communication Manager
- Session Manager
- System Manager
- Avaya G650 Media Gateway
- Avaya Session Border Controller for Enterprise
- Avaya 1600-Series IP telephones (H.323)
- Avaya 9600-Series IP telephones (H.323)
- Avaya one-X® Communicator (H.323)
- Avaya digital and analog telephones
- Fax machine

Located at the edge of the enterprise is the Avaya SBCE. It has a public side that connects to the external network and a private side that connects to the enterprise network. All SIP and RTP traffic entering or leaving the enterprise flows through the Avaya SBCE. In this way, the Avaya SBCE can protect the enterprise against any SIP-based attacks. The Avaya SBCE provides network address translation at both the IP and SIP layers. For security reasons, any actual public IP addresses used in the configuration have been replaced with private IP addresses. Similarly, any references to real routable PSTN numbers have also been changed to numbers that cannot be routed by the PSTN.



**Figure 1: Avaya IP Telephony Network using Level 3 SIP Trunking**

A separate trunk was created between Communication Manager and Session Manager to carry the service provider traffic. This was done so that any trunk or codec setting required by the service provider could be applied only to this trunk and not affect other enterprise SIP traffic. In addition, this trunk carried both inbound and outbound traffic.

For inbound calls, the calls flow from the service provider to the Avaya SBCE then to Session Manager. Session Manager uses the configured dial patterns (or regular expressions) and routing policies to determine the recipient (in this case the Communication Manager) and on which link to send the call. Once the call arrives at Communication Manager, further incoming call treatment, such as incoming digit translations and class of service restrictions may be performed.

Outbound calls to the PSTN are first processed by Communication Manager and may be subject to outbound features such as automatic route selection, digit manipulation and class of service restrictions. Once Communication Manager selects the proper SIP trunk, the call is routed to Session Manager. The Session Manager once again uses the configured dial patterns (or regular expressions) to determine the route to the Avaya SBCE. From the Avaya SBCE, the call is sent to Level 3 SIP Trunking.

For the compliance test, 10 digit numbering was used for this purpose. Thus for outbound calls, the enterprise sent 10 digits in the SIP source headers (i.e., From, Contact, and P-Asserted-Identity). The enterprise was configured to send 11 digits in the SIP destination headers (Request URI and To). For inbound calls, Level 3 sent 10 digits in both the source headers and destination headers.

Level 3 listened for SIP signaling on port 5070 using UDP instead of the standard SIP port of 5060. The Avaya SBCE continued to listen on port 5060. Testing was conducted with and without the use of the SIP REFER method for redirected calls. Level 3 used Digest Authentication to challenge INVITE and REFER messages from the enterprise. The Avaya SBCE responded to the challenges on behalf of the enterprise to send the correct credentials to allow the calls to proceed.

## 4. Equipment and Software Validated

The following equipment and software were used for the sample configuration provided:

Avaya IP Telephony Solution Components	
Equipment/Software	Release/Version
Avaya Aura® Communication Manager running on duplex Avaya S8710 Servers	5.2.1 SP12.01 (R015x.02.1.016.4-19751)
Avaya G650 Media Gateway <ul style="list-style-type: none"><li>• IP Server Interface (IPSI) TN2312BP</li><li>• Control LAN (CLAN) TN799DP</li><li>• IP Media Processor (MEDPRO) TN2602AP</li></ul>	HW15 FW054 HW01 FW040 HW02 FW061
Avaya Aura® System Manager running on an Avaya S8800 Server	6.1 SP8 Patch 1 (Build 6.1.0.0.7345-6.1.5.803) (System Platform 6.0.3.7.3)
Avaya Aura® Session Manager running on an Avaya S8800 Server	6.1 SP7 (Build asm-6.1.7.0.617012)
Avaya Session Border Controller for Enterprise running on a Dell R210 V2 server	4.0.5Q09
Avaya 1608 IP Telephone (H.323) running Avaya one-X® Deskphone Value Edition	1.3.1
Avaya 9640G IP Telephone (H.323) running Avaya one-X® Deskphone Edition	3.1 SP4 (3.1.04S)
Avaya 9641G IP Telephone (H.323) running Avaya one-X® Deskphone Edition	6.2 (6.2.119)
Avaya one-X® Communicator (H.323)	6.1 (Build 6.1.0.12-GA-30334)
Avaya 2420 Digital Telephone	n/a
Avaya 6210 Analog Telephone	n/a
Level 3 SIP Trunking Solution Components	
Equipment/Software	Release/Version
Level 3 Enterprise Edge	Version 1

**Table 1: Equipment and Software Tested**

The specific configuration above was used for the compliance testing. Note that this solution will be compatible with other Avaya Server and Media Gateway platforms running similar versions of Communication Manager and Session Manager.

## 5. Configure Avaya Aura® Communication Manager

This section describes the procedure for configuring Communication Manager for Level 3 SIP Trunking. A SIP trunk is established between Communication Manager and Session Manager for use by traffic to and from Level 3. It is assumed the general installation of Communication Manager, Avaya Media Gateway and Session Manager has been previously completed and is not discussed here.

The Communication Manager configuration was performed using the System Access Terminal (SAT). Some screens in this section have been abridged and highlighted for brevity and clarity in presentation. Note that the IP addresses and phone numbers shown throughout these Application Notes have been edited so that the actual public IP addresses of the network elements and public PSTN numbers are not revealed.

### 5.1. Licensing and Capacity

Use the **display system-parameters customer-options** command to verify that the **Maximum Administered SIP Trunks** value on **Page 2** is sufficient to support the desired number of simultaneous SIP calls across all SIP trunks at the enterprise including any trunks to the service provider. The example shows that 800 SIP trunks are available and 208 are in use. The license file installed on the system controls the maximum values for these attributes. If a required feature is not enabled or there is insufficient capacity, contact an authorized Avaya sales representative to add additional capacity.

<b>display system-parameters customer-options</b>		Page	2 of 10
OPTIONAL FEATURES			
IP PORT CAPACITIES		USED	
Maximum Administered H.323 Trunks:		800	200
Maximum Concurrently Registered IP Stations:		18000	5
Maximum Administered Remote Office Trunks:		0	0
Maximum Concurrently Registered Remote Office Stations:		0	0
Maximum Concurrently Registered IP eCons:		0	0
Max Concur Registered Unauthenticated H.323 Stations:		0	0
Maximum Video Capable H.323 Stations:		0	0
Maximum Video Capable IP Softphones:		0	0
<b>Maximum Administered SIP Trunks:</b>		<b>800</b>	<b>208</b>
Maximum Administered Ad-hoc Video Conferencing Ports:		0	0
Maximum Number of DS1 Boards with Echo Cancellation:		0	0
Maximum TN2501 VAL Boards:		10	1
Maximum Media Gateway VAL Sources:		0	0
Maximum TN2602 Boards with 80 VoIP Channels:		128	0
Maximum TN2602 Boards with 320 VoIP Channels:		128	2
Maximum Number of Expanded Meet-me Conference Ports:		0	0



## 5.2. System Features

Use the **change system-parameters features** command to set the **Trunk-to-Trunk Transfer** field to **all** to allow incoming calls from the PSTN to be transferred to another PSTN endpoint. If for security reasons, incoming calls should not be allowed to transfer back to the PSTN then leave the field set to **none**.

```
change system-parameters features                                     Page 1 of 19
      FEATURE-RELATED SYSTEM PARAMETERS
        Self Station Display Enabled? n
          Trunk-to-Trunk Transfer: all
        Automatic Callback with Called Party Queuing? n
        Automatic Callback - No Answer Timeout Interval (rings): 3
          Call Park Timeout Interval (minutes): 10
        Off-Premises Tone Detect Timeout Interval (seconds): 20
          AAR/ARS Dial Tone Required? y
```

On **Page 9**, verify that a text string has been defined to replace the Calling Party Number (CPN) for restricted or unavailable calls. This text string is entered in the two fields highlighted below. The compliance test used the value of **unknown** for both.

```
change system-parameters features                                     Page 9 of 19
      FEATURE-RELATED SYSTEM PARAMETERS

      CPN/ANI/ICLID PARAMETERS
        CPN/ANI/ICLID Replacement for Restricted Calls: unknown
        CPN/ANI/ICLID Replacement for Unavailable Calls: unknown

      DISPLAY TEXT
        Identity When Bridging: principal
        User Guidance Display? n
        Extension only label for Team button on 96xx H.323 terminals? n

      INTERNATIONAL CALL ROUTING PARAMETERS
        Local Country Code:
        International Access Code:

      ENBLOC DIALING PARAMETERS
        Enable Enbloc Dialing without ARS FAC? n

      CALLER ID ON CALL WAITING PARAMETERS
        Caller ID on Call Waiting Delay Timer (msec): 200
```

### 5.3. IP Node Names

Use the **change node-names ip** command to verify that node names have been previously defined for the IP addresses of the CLAN circuit pack (**clan1**) and for Session Manager (**bvSM**). These node names will be needed for defining the service provider signaling group in **Section 5.6**.

change node-names ip		Page 1 of 2
IP NODE NAMES		
Name	IP Address	
<b>bvSM</b>	<b>10.32.24.235</b>	
<b>clan1</b>	<b>10.1.2.233</b>	
default	0.0.0.0	
medpro1	10.1.2.235	
procr	. . .	
procr1	10.1.2.11	
procr2	10.1.2.21	

### 5.4. Codecs

Use the **change ip-codec-set** command to define a list of codecs to use for calls between the enterprise and the service provider. For the compliance test, G.729A and G.711MU were tested using IP codec set 4. To use these codecs, enter **G.729A** and **G.711MU** in the **Audio Codec** column of the table in the order of preference. Default values can be used for all other fields.

change ip-codec-set 4		Page 1 of 2
IP Codec Set		
Codec Set: 4		
Audio Codec	Silence Suppression	Frames Per Pkt
1: <b>G.729A</b>	n	2
2: <b>G.711MU</b>	n	2
3:		

On **Page 2**, set the **Fax Mode** to **t.38-standard**.

change ip-codec-set 4		Page 2 of 2
IP Codec Set		
Allow Direct-IP Multimedia? n		
FAX	Mode	Redundancy
Modem	off	0
TDD/TTY	US	3

## 5.5. IP Network Region

Create a separate IP network region for the service provider trunk. This allows for separate codec or quality of service settings to be used (if necessary) for calls between the enterprise and the service provider versus calls within the enterprise or elsewhere. For the compliance test, IP network region 4 was chosen for the service provider trunk. Use the **change ip-network-region 4** command to configure region 4 with the following parameters:

- Set the **Authoritative Domain** field to match the SIP domain of the enterprise. In this configuration, the domain name is **avaya.com**. This name appears in the “From” header of SIP messages originating from this IP region.
- Enter a descriptive name in the **Name** field.
- Enable **IP-IP Direct Audio** (shuffling) to allow audio traffic to be sent directly between IP endpoints without using media resources in the Avaya Media Gateway. Set both **Intra-region** and **Inter-region IP-IP Direct Audio** to **yes**. This is the default setting. Shuffling can be further restricted at the trunk level on the Signaling Group form.
- Set the **Codec Set** field to the IP codec set defined in **Section 5.4**.
- Default values can be used for all other fields.

```
change ip-network-region 4                                     Page 1 of 19

                                IP NETWORK REGION

Region: 4
Location:                Authoritative Domain: avaya.com
Name: SP Region
MEDIA PARAMETERS                Intra-region IP-IP Direct Audio: yes
                                Inter-region IP-IP Direct Audio: yes
                                IP Audio Hairpinning? n
    Codec Set: 4
    UDP Port Min: 2048
    UDP Port Max: 3329
DIFFSERV/TOS PARAMETERS                RTCP Reporting Enabled? y
    Call Control PHB Value: 46        RTCP MONITOR SERVER PARAMETERS
    Audio PHB Value: 46                Use Default Server Parameters? y
    Video PHB Value: 26
802.1P/Q PARAMETERS
    Call Control 802.1p Priority: 6
    Audio 802.1p Priority: 6
    Video 802.1p Priority: 5        AUDIO RESOURCE RESERVATION PARAMETERS
H.323 IP ENDPOINTS                RSVP Enabled? n
    H.323 Link Bounce Recovery? y
    Idle Traffic Interval (sec): 20
    Keep-Alive Interval (sec): 5
    Keep-Alive Count: 5
```

On **Page 3**, define the IP codec set to be used for traffic between region 4 and region 1. Enter the desired IP codec set in the **codec set** column of the row with destination region (**dst rgn**) **1**. Default values may be used for all other fields. The example below shows the settings used for the compliance test. It indicates that codec set 4 will be used for calls between region 4 (the service provider region) and region 1 (the rest of the enterprise). Creating this table entry for IP network region 4 will automatically create a complementary table entry on the IP network region 1 form for destination region 4. This complementary table entry can be viewed using the **display ip-network-region 1** command and navigating to **Page 3**.

change ip-network-region 4										Page	3	of	19
Source Region: 4      Inter Network Region Connection Management										I			M
										G	A		t
<b>dst</b>	<b>codec</b>	direct	WAN-BW-limits	Video	Intervening	Dyn	A	G					c
<b>rgn</b>	<b>set</b>	WAN	Units	Total Norm	Prio Shr Regions	CAC	R	L					e
<b>1</b>	<b>4</b>	y	NoLimit				n						t
2													
3													
4	4											all	

## 5.6. Signaling Group

Use the **add signaling-group** command to create a signaling group between Communication Manager and Session Manager for use by the service provider trunk. This signaling group is used for inbound and outbound calls between the service provider and the enterprise. For the compliance test, signaling group 34 was used and was configured using the parameters highlighted below.

- Set the **Group Type** field to **sip**.
- Set the **Transport Method** to the recommended default value of **tls** (Transport Layer Security). The transport method specified here is used between the Communication Manager and Session Manager.
- Set the **IMS Enabled** field to **n**. This specifies the Communication Manager will serve as an Access Element for Session Manager.
- Set the **Near-end Node Name** to **clan1**. This node name maps to the IP address of the CLAN circuit pack as defined in **Section 5.3**.
- Set the **Far-end Node Name** to **bvSM**. This node name maps to the IP address of Session Manager as defined in **Section 5.3**.
- Set the **Near-end Listen Port** and **Far-end Listen Port** to a valid unused port instead of the default well-known port value for the chosen transport protocol. (For TLS, the well-known port value is 5061 and for TCP the well-known port value is 5060). At the time of Session Manager installation, a SIP connection between Communication Manager and Session Manager would have been established for use by all Communication Manager SIP traffic using the well-known port value for TLS. By creating a new signaling group with a separate port value, a separate SIP connection is created between Communication Manager and Session Manager for SIP traffic to the service provider. As a result, any signaling group or trunk group settings (**Section 5.7**) will only affect the service provider

traffic and not other SIP traffic at the enterprise. The compliance test was conducted with the **Near-end Listen Port** and **Far-end Listen Port** set to **5066**.

- Set the **Far-end Network Region** to the IP network region defined for the service provider in **Section 5.5**.
- Set the **Far-end Domain** to the domain of the enterprise.
- Set **Direct IP-IP Audio Connections** to **y**. This field will enable media shuffling on the SIP trunk allowing Communication Manager to redirect media traffic directly between the SIP trunk and the enterprise endpoint. If this value is set to **n**, then the Avaya Media Gateway will remain in the media path of all calls between the SIP trunk and the endpoint. Depending on the number of media resources available in the Avaya Media Gateway, these resources may be depleted during high call volume preventing additional calls from completing.
- Set the **DTMF over IP** field to **rtp-payload**. This value enables Communication Manager to send DTMF transmissions using RFC 2833.
- Set the **Alternate Route Timer** to **15**. This defines the number of seconds that Communication Manager will wait for a response (other than 100 Trying) to an outbound INVITE before selecting another route. If an alternate route is not defined, then the call is cancelled after this interval.
- Default values may be used for all other fields.

<b>add signaling-group 34</b>		Page 1 of 1
SIGNALING GROUP		
Group Number: 34	Group Type: sip	
	Transport Method: tls	
IMS Enabled? n		
Near-end Node Name: clan1	Far-end Node Name: bvSM	
Near-end Listen Port: 5066	Far-end Listen Port: 5066	
	Far-end Network Region: 4	
Far-end Domain: avaya.com		
Incoming Dialog Loopbacks: eliminate	Bypass If IP Threshold Exceeded? n	
DTMF over IP: rtp-payload	RFC 3389 Comfort Noise? n	
Session Establishment Timer(min): 3	Direct IP-IP Audio Connections? y	
Enable Layer 3 Test? n	IP Audio Hairpinning? n	
H.323 Station Outgoing Direct Media? n	Direct IP-IP Early Media? n	
	Alternate Route Timer(sec): 15	

## 5.7. Trunk Group

Use the **add trunk-group** command to create a trunk group for the signaling group created in **Section 5.6**. For the compliance test, trunk group 34 was configured using the parameters highlighted below.

- Set the **Group Type** field to **sip**.
- Enter a descriptive name for the **Group Name**.
- Enter an available trunk access code (TAC) that is consistent with the existing dial plan in the **TAC** field.
- Set the **Service Type** field to **public-ntwrk**.
- Set the **Signaling Group** to the signaling group shown in **Section 5.6**.
- Set the **Number of Members** field to the number of trunk members in the SIP trunk group. This value determines how many simultaneous SIP calls can be supported by this trunk.
- Default values were used for all other fields.

<b>add trunk-group 34</b>		Page 1 of 21	
TRUNK GROUP			
Group Number: 34	<b>Group Type: sip</b>	CDR Reports: y	
<b>Group Name: SP Trunk</b>	COR: 1	TN: 1	<b>TAC: 134</b>
Direction: two-way	Outgoing Display? n	Night Service:	
Dial Access? n			
Queue Length: 0			
<b>Service Type: public-ntwrk</b>	Auth Code? n		
<b>Signaling Group: 34</b>			
<b>Number of Members: 10</b>			

On **Page 2**, the **Redirect On OPTIM Failure** value is the amount of time (in milliseconds) that Communication Manager will wait for a response (other than 100 Trying) to a pending INVITE sent to an EC500 remote endpoint before selecting another route. If another route is not defined, then the call is cancelled after this interval. This time interval should be set to a value equal to the **Alternate Route Timer** on the signaling group form described in **Section 5.6**.

Verify that the **Preferred Minimum Session Refresh Interval** is set to a value acceptable to the service provider. This value defines the interval that re-INVITEs must be sent to keep the active session alive. For the compliance test, the value of **600** seconds was used.

add trunk-group 34 Group Type: sip	Page 2 of 21
TRUNK PARAMETERS	
Unicode Name: auto	
Redirect On OPTIM Failure: 15000	
SCCAN? n	Digital Loss Group: 18
Preferred Minimum Session Refresh Interval(sec): 600	

On **Page 3**, set the **Numbering Format** field to **public**. This field specifies the format of the calling party number (CPN) sent to the far-end.

Set the **Replace Restricted Numbers** and **Replace Unavailable Numbers** fields to **y**. This will allow the CPN displayed on local endpoints to be replaced with the value set in **Section 5.2**, if the inbound call enabled CPN block. For outbound calls, these same settings request that CPN block be activated on the far-end destination if a local user requests CPN block on a particular call routed out this trunk. Default values were used for all other fields.

add trunk-group 34	Page 3 of 21
TRUNK FEATURES	
ACA Assignment? n	Measured: none
	Maintenance Tests? y
Numbering Format: public	
	UI Treatment: service-provider
	Replace Restricted Numbers? y
	Replace Unavailable Numbers? y
Show ANSWERED BY on Display? y	

On **Page 4**, the **Network Call Redirection** field may be set to **y** or **n**. Level 3 supports both settings. If set to **y**, Communication Manager will use the SIP REFER method to redirect calls back to the PSTN. Otherwise, a re-INVITE is used. Set the **Send Diversion Header** field to **y** and the **Support Request History** field to **n**. The **Send Diversion Header** field provides additional information to the network if the call has been redirected. These settings are needed to support call forwarding of inbound calls back to the PSTN and some Extension to Cellular (EC500) call scenarios.

Set the **Telephone Event Payload Type** to **101**, the value preferred by Level 3.

add trunk-group 34	Page 4 of 21
PROTOCOL VARIATIONS	
Mark Users as Phone? n	
Prepend '+' to Calling Number? n	
Send Transferring Party Information? n	
Network Call Redirection? y	
Send Diversion Header? y	
Support Request History? n	
Telephone Event Payload Type: 101	

## 5.8. Calling Party Information

The calling party number is sent in the SIP “From”, “Contact” and “PAI” headers. Since public numbering was selected to define the format of this number (**Section 5.7**), use the **change public-unknown-numbering** command to create an entry for each extension which has a DID assigned. The DID number will be one assigned by the SIP service provider. It is used to authenticate the caller.

In the sample configuration, multiple DID numbers were assigned for testing. These numbers were assigned to the extensions 30023, 30024 and 30025. Thus, these same 10-digit numbers were used in the outbound calling party information on the service provider trunk when calls were originated from these extensions.

change public-unknown-numbering 0					Page 1 of 1
NUMBERING - PUBLIC/UNKNOWN FORMAT					
Ext Len	Ext Code	Trk Grp(s)	CPN Prefix	Total CPN Len	
5	3			5	Total Administered: 4
5	30023	34	9735551234	10	Maximum Entries: 9999
5	30025	34	9735551235	10	
5	30030	34	9735551236	10	



In a real customer environment, normally the DID number is comprised of the local extension plus a prefix. If this is true, then a single public-unknown-numbering entry can be applied for all extensions. In the example below, all stations with a 5-digit extension beginning with 3 will send the calling party number as the **CPN Prefix** plus the extension number.

change public-unknown-numbering 0					Page 1 of 1
NUMBERING - PUBLIC/UNKNOWN FORMAT					
Total					
<b>Ext Len</b>	<b>Ext Code</b>	<b>Trk Grp(s)</b>	<b>CPN Prefix</b>	<b>CPN Len</b>	
5	3	34	97355	10	Total Administered: 1 Maximum Entries: 9999

## 5.9. Outbound Routing

In these Application Notes, the Automatic Route Selection (ARS) feature is used to route outbound calls via the SIP trunk to the service provider. In the sample configuration, the single digit 9 is used as the ARS access code. Enterprise callers will dial 9 to reach an “outside line”. This common configuration is illustrated below with little elaboration. Use the **change dialplan analysis** command to define a dialed string beginning with 9 of length 1 as a feature access code (**fac**).

change dialplan analysis										Page 1 of 12
DIAL PLAN ANALYSIS TABLE										
Location: all										Percent Full: 2
	Dialed String	Total Length	Call Type	Dialed String	Total Length	Call Type	Dialed String	Total Length	Call Type	
1		3	dac							
2		5	ext							
222		5	aar							
3		5	ext							
3234		7	ext							
4		5	ext							
5		5	ext							
6		5	ext							
7		7	ext							
8		1	fac							
<b>9</b>		<b>1</b>	<b>fac</b>							
*		3	fac							
#		3	fac							

Use the **change feature-access-codes** command to configure **9** as the **Auto Route Selection (ARS) – Access Code 1**.

<b>change feature-access-codes</b>	Page 1 of 8
FEATURE ACCESS CODE (FAC)	
Abbreviated Dialing List1 Access Code:	*01
Abbreviated Dialing List2 Access Code:	*02
Abbreviated Dialing List3 Access Code:	*03
Abbreviated Dial - Prgm Group List Access Code:	*04
Announcement Access Code:	*05
Answer Back Access Code:	
Attendant Access Code:	
Auto Alternate Routing (AAR) Access Code:	8
<b>Auto Route Selection (ARS) – Access Code 1:</b>	<b>9</b>
Access Code 2:	
Automatic Callback Activation:	Deactivation:
Call Forwarding Activation Busy/DA: *13 All: *11	Deactivation: *12

Use the **change ars analysis** command to configure the routing of dialed digits following the first digit 9. The example below shows a subset of the dialed strings tested as part of the compliance test. See **Section 2.1** for the complete list of call types tested. All dialed strings are mapped to **Route Pattern 34** which contains the SIP trunk to the service provider (as defined next).

change ars analysis 0						Page	1 of	2
ARS DIGIT ANALYSIS TABLE								
Location: all						Percent Full: 2		
	Dialed	Total		Route	Call	Node	ANI	
	String	Min	Max	Pattern	Type	Num	Reqd	
0		1	1	34	op		n	
0		11	11	34	op		n	
011		10	18	34	intl		n	
1800		11	11	34	fpna		n	
1877		11	11	34	fpna		n	
1908		11	11	34	fpna		n	
411		3	3	34	svcl		n	

The route pattern defines which trunk group will be used for the call and performs any necessary digit manipulation. Use the **change route-pattern** command to configure the parameters for the service provider trunk route pattern in the following manner. The example below shows the values used for route pattern 34 during the compliance test.

- **Pattern Name:** Enter a descriptive name.
- **Grp No:** Enter the outbound trunk group for the SIP service provider. For the compliance test, trunk group 34 was used.
- **FRL:** Set the Facility Restriction Level (**FRL**) field to a level that allows access to this trunk for all users that require it. The value of **0** is the least restrictive level.
- **Pfx Mrk: 1** The prefix mark (**Pfx Mrk**) of one will prefix any FNPA 10-digit number with a 1 and leave numbers of any other length unchanged. This will ensure 1 + 10 digits are sent to the service provider for long distance North American Numbering Plan (NANP) numbers.
- **LAR: next**

change route-pattern 34										Page	1	of	3	
Pattern Number: 34    Pattern Name: SP Route														
SCCAN? n    Secure SIP? n														
Grp	FRL	NPA	Pfx	Hop	Toll	No.	Inserted			DCS/	IXC			
No			Mrk	Lmt	List	Del	Digits			QSIG				
Dgts										Intw				
1:	34	0	1							n	user			
2:										n	user			
3:										n	user			
4:										n	user			
5:										n	user			
6:										n	user			
BCC VALUE    TSC    CA-TSC    ITC    BCIE    Service/Feature    PARM    No.    Numbering    LAR														
0 1 2 M 4 W    Request										Dgts	Format			
										Subaddress				
1:	y	y	y	y	y	n	n		rest			next		
2:	y	y	y	y	y	n	n		rest			none		
3:	y	y	y	y	y	n	n		rest			none		
4:	y	y	y	y	y	n	n		rest			none		
5:	y	y	y	y	y	n	n		rest			none		
6:	y	y	y	y	y	n	n		rest			none		

## 6. Configure Avaya Aura® Session Manager


This section provides the procedures for configuring Session Manager. The procedures include configuring the following items:

- SIP domain
- Logical/physical Location that can be occupied by SIP Entities.
- Adaptation module to perform dial plan manipulation.
- SIP Entities corresponding to Communication Manager, the Avaya SBCE and Session Manager.
- Entity Links, which define the SIP trunk parameters used by Session Manager when routing calls to/from SIP Entities.
- Routing Policies, which control call routing between the SIP Entities.
- Dial Patterns, which governs which Routing Policy is used to service a call.
- Session Manager, corresponding to the Session Manager Server to be managed by System Manager.

It may not be necessary to create all the items above when creating a connection to the service provider since some of these items would have already been defined as part of the initial Session Manager installation. This includes items such as certain SIP domains, locations, SIP entities, and Session Manager itself. However, each item should be reviewed to verify the configuration.

## 6.1. Avaya Aura® System Manager Login and Navigation

Session Manager configuration is accomplished by accessing the browser-based GUI of System Manager, using the URL “https://<ip-address>/SMGR”, where “<ip-address>” is the IP address of System Manager. Log in with the appropriate credentials and click on **Login** (not shown). The **Home** page is displayed. The links displayed below will be referenced in subsequent sections to navigate to items requiring configuration. Most items will be located under the **Elements** → **Routing** link highlighted below.



Clicking the **Elements** → **Routing** link, displays the **Introduction to Network Routing Policy** page. In the left-hand pane is a navigation tree containing many of the items to be configured in the following sections.

**AVAYA** Avaya Aura® System Manager 6.1 [Help](#) | [About](#) | [Change Password](#) | [Log off admin](#)

**Routing** × **Home**

Home / Elements / Routing- Introduction to Network Routing Policy [Help ?](#)

### Introduction to Network Routing Policy

Network Routing Policy consists of several routing applications like "Domains", "Locations", "SIP Entities", etc.

The recommended order to use the routing applications (that means the overall routing workflow) to configure your network configuration is as follows:

- Step 1: Create "Domains" of type SIP (other routing applications are referring domains of type SIP).
- Step 2: Create "Locations"
- Step 3: Create "Adaptations"
- Step 4: Create "SIP Entities"

## 6.2. Specify SIP Domain

Create a SIP domain for each domain for which Session Manager will need to be aware in order to route calls. For the compliance test, this includes the enterprise domain (**avaya.com**). Navigate to **Routing** → **Domains** in the left-hand navigation pane (**Section 6.1**) and click the **New** button in the right pane (not shown). In the new right pane that appears (shown below), fill in the following:

- **Name:** Enter the domain name.
- **Type:** Select **sip** from the pull-down menu.
- **Notes:** Add a brief description (optional).

Click **Commit**. The screen below shows the entry for the enterprise domain.

**Domain Management** [Commit](#) [Cancel](#)

1 Item | [Refresh](#) Filter: [Enable](#)

Name	Type	Default	Notes
* <input type="text" value="avaya.com"/>	sip ▼	<input type="checkbox"/>	<input type="text" value="Enterprise Domain"/>

\* Input Required [Commit](#) [Cancel](#)

### 6.3. Add Location

Locations can be used to identify logical and/or physical locations where SIP Entities reside for purposes of bandwidth management and call admission control. A single location was defined for the enterprise even though multiple subnets were used. The screens below show the addition of the location named **Location 1**, which includes all equipment on the enterprise including Communication Manager, Session Manager and the Avaya SBCE.

To add a location, navigate to **Routing → Locations** in the left-hand navigation pane (**Section 6.1**) and click the **New** button in the right pane (not shown). In the new right pane that appears (shown below), fill in the following:

In the **General** section, enter the following values. Use default values for all remaining fields.

- **Name:** Enter a descriptive name for the location.
- **Notes:** Add a brief description (optional).

**Location Details**

CommitCancel

**General**

\* Name: Location 1

Notes: SP Subnet(s)

Scroll down to the **Location Pattern** section. Click **Add** and enter the following values. Use default values for all remaining fields.

- **IP Address Pattern:** An IP address pattern used to identify the location.
- **Notes:** Add a brief description (optional).

Click **Commit** to save.

**Location Pattern**

AddRemove

3 Items RefreshFilter: Enable

<input type="checkbox"/>	IP Address Pattern	Notes
<input type="checkbox"/>	* 10.1.2.*	
<input type="checkbox"/>	* 10.32.24.235	SM 6.1 (devcon-asm)
<input type="checkbox"/>	* 10.32.128.*	

Select : All, None

## 6.4. Add Adaptation Module

Session Manager can be configured with adaptation modules that can modify SIP messages before or after routing decisions have been made. A generic adaptation module **DigitConversionAdapter** supports digit conversion of telephone numbers in specific headers of SIP messages. Other adaptation modules are built on this generic module, and can modify other headers to permit interoperability with third party SIP products.

For the compliance test, an adaptation was applied to the Communication Manager SIP entity and maps inbound DID numbers from Level 3 to local Communication Manager extensions.

To create the adaptation that will be applied to the Communication Manager SIP entity, navigate to **Routing → Adaptations** in the left-hand navigation pane and click on the **New** button in the right pane (not shown). In the new right pane that appears (shown below), fill in the following:

In the **General** section, enter the following values. Use default values for all remaining fields.

- **Adaptation name:** Enter a descriptive name for the adaptation.
- **Module name:** Enter **DigitConversionAdapter**.

**Adaptation Details**CommitCancel

**General**

\* **Adaptation name:**

**Module name:**

**Module parameter:**

**Egress URI Parameters:**

**Notes:**



To map inbound DID numbers from Level 3 to Communication Manager extensions, scroll down to the **Digit Conversion for Outgoing Calls from SM** section. Create an entry for each DID to be mapped. Click **Add** and enter the following values for each mapping. Use default values for all remaining fields.

- **Matching Pattern:** Enter a digit string used to match the inbound DID number.
- **Min:** Enter a minimum dialed number length used in the match criteria.
- **Max:** Enter a maximum dialed number length used in the match criteria.
- **Delete Digits** Enter the number of digits to delete from the beginning of the received number.
- **Insert Digits:** Enter the number of digits to insert at the beginning of the received number.
- **Address to modify:** Select **destination** since this digit conversion only applies to the destination number.

Click **Commit** to save.

### Digit Conversion for Incoming Calls to SM

Add
Remove

0 Items
Refresh
Filter: Enable

	Matching Pattern	Min	Max	Phone Context	Delete Digits	Insert Digits	Address to modify	Notes
--	------------------	-----	-----	---------------	---------------	---------------	-------------------	-------

### Digit Conversion for Outgoing Calls from SM

Add
Remove

5 Items
Refresh
Filter: Enable

	Matching Pattern ▲	Min	Max	Phone Context	Delete Digits	Insert Digits	Address to modify	Notes
<input type="checkbox"/>	* 9735551234	* 10	* 10		* 10	30023	destination ▼	Level 3
<input type="checkbox"/>	* 9735551235	* 10	* 10		* 10	30025	destination ▼	Level 3
<input type="checkbox"/>	* 9735551236	* 10	* 10		* 10	30030	destination ▼	Level 3

## 6.5. Add SIP Entities

A SIP Entity must be added for Session Manager and for each SIP telephony system connected to Session Manager which includes Communication Manager and the Avaya SBCE. Navigate to **Routing → SIP Entities** in the left-hand navigation pane (**Section 6.1**) and click on the **New** button in the right pane (not shown). In the new right pane that appears (shown below), fill in the following:

In the **General** section, enter the following values. Use default values for all remaining fields.

- **Name:** Enter a descriptive name.
- **FQDN or IP Address:** Enter the FQDN or IP address of the SIP Entity that is used for SIP signaling.
- **Type:** Enter **Session Manager** for Session Manager, **CM** for Communication Manager and **SIP Trunk** for the Avaya SBCE.
- **Adaptation:** This field is only present if **Type** is not set to **Session Manager**. If applicable, select the appropriate **Adaptation name** created in **Section 6.4** that will be applied to this entity.
- **Location:** Select the location that applies to the SIP entity being created. For the compliance test, all components were located in location **Location 1**.
- **Time Zone:** Select the time zone for the location above.

The following screen shows the addition of Session Manager. The IP address of the virtual SM-100 Security Module is entered for **FQDN or IP Address**.

**SIP Entity Details** [Commit] [Cancel]

**General**

\* **Name:** devcon-asm

\* **FQDN or IP Address:** 10.32.24.235

**Type:** Session Manager

**Notes:**

**Location:** Location 1

**Outbound Proxy:**

**Time Zone:** America/New\_York

**Credential name:**

**SIP Link Monitoring**

**SIP Link Monitoring:** Use Session Manager Configuration

To define the ports used by Session Manager, scroll down to the **Port** section of the **SIP Entity Details** screen. This section is only present for **Session Manager** SIP entities.

In the **Port** section, click **Add** and enter the following values. Use default values for all remaining fields:

- **Port:** Port number on which the Session Manager can listen for SIP requests.
- **Protocol:** Transport protocol to be used with this port.
- **Default Domain:** The default domain associated with this port. For the compliance test, this was the enterprise SIP domain.

Defaults can be used for the remaining fields. Click **Commit** to save.

For the compliance test, four port entries were used. The first three are the standard ports used for SIP traffic: port 5060 for UDP/TCP and port 5061 for TLS. In addition, port 5066 defined in **Section 5.6** for use with service provider SIP traffic between Communication Manager and Session Manager was added to the list.

**Port**

4 Items

Filter:

<input type="checkbox"/>	Port	Protocol	Default Domain	Notes
<input type="checkbox"/>	<input type="text" value="5060"/>	<input type="button" value="TCP"/>	<input type="button" value="avaya.com"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text" value="5060"/>	<input type="button" value="UDP"/>	<input type="button" value="avaya.com"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text" value="5061"/>	<input type="button" value="TLS"/>	<input type="button" value="avaya.com"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text" value="5066"/>	<input type="button" value="TLS"/>	<input type="button" value="avaya.com"/>	<input type="text"/>

Select : All, None

\* Input Required

The following screen shows the addition of Communication Manager. In order for Session Manager to send SIP service provider traffic on a separate entity link to Communication Manager, this requires the creation of a separate SIP entity for Communication Manager other than the one created at Session Manager installation for use with all other SIP traffic. The **FQDN or IP Address** field is set to the IP address of the Avaya Server running Communication Manager. For the **Adaptation** field, select the adaptation module previously defined for Communication Manager in **Section 6.4**. The **Location** field is set to **Location 1** which is the location defined for the subnet where Communication Manager resides.

**SIP Entity Details**

CommitCancel

**General**

\* Name:

Trenton Trk 34

\* FQDN or IP Address:

10.1.2.233

Type:

CM

Notes:

Adaptation:

TrentonTrk34-Adapt2

Location:

Location 1

Time Zone:

America/New\_York

Override Port & Transport with DNS SRV:

☐

\* SIP Timer B/F (in seconds):

4

Credential name:

Call Detail Recording:

none

The following screen shows the addition of the Avaya SBCE. The **FQDN or IP Address** field is set to the IP address of its private network interface (see **Figure 1**). The **Adaptation** field is left blank. The **Location** field is set to **Location 1** which is the location defined for the subnet where the Avaya SBCE resides.

**SIP Entity Details**

CommitCancel

**General**

\* Name:

ASBCE

\* FQDN or IP Address:

10.32.128.18

Type:

SIP Trunk

Notes:

CPE Avaya SBC For Enterprise

Adaptation:

Location:

Location 1

Time Zone:

America/New\_York

Override Port & Transport with DNS SRV:

☐

\* SIP Timer B/F (in seconds):

4

Credential name:

Call Detail Recording:

egress

**SIP Link Monitoring**

SIP Link Monitoring:

Use Session Manager Configuration

## 6.6. Add Entity Links

A SIP trunk between Session Manager and a telephony system is described by an Entity Link. Two Entity Links were created: one to Communication Manager for use only by service provider traffic and one to the Avaya SBCE. To add an Entity Link, navigate to **Routing → Entity Links** in the left-hand navigation pane (**Section 6.1**) and click on the **New** button in the right pane (not shown). In the new right pane that appears (shown below), fill in the following:

- **Name:** Enter a descriptive name.
- **SIP Entity 1:** Select the Session Manager.
- **Protocol:** Select the transport protocol used for this link.
- **Port:** Port number on which Session Manager will receive SIP requests from the far-end. For the Communication Manager Entity Link, this must match the **Far-end Listen Port** defined on the Communication Manager signaling group in **Section 5.6**.
- **SIP Entity 2:** Select the name of the other system. For the Communication Manager Entity Link, select the Communication Manager SIP Entity defined in **Section 6.5**.
- **Port:** Port number on which the other system receives SIP requests from the Session Manager. For the Communication Manager Entity Link, this must match the **Near-end Listen Port** defined on the Communication Manager signaling group in **Section 5.6**.
- **Connection Policy:** Select **Trusted** from the pull-down menu.

Click **Commit** to save. The following screen illustrates the Entity Link to Communication Manager. The protocol and ports defined here must match the values used on the Communication Manager signaling group form in **Section 5.6**.

Name	SIP Entity 1	Protocol	Port	SIP Entity 2	Port	Connection Policy	Notes
* TrentonTrk34-Link	* devcon-asm	TLS	* 5066	* Trenton Trk 34	* 5066	Trusted	

The following screen illustrates the Entity Link to the Avaya SBCE.

Entity Links Commit Cancel

1 Item | Refresh Filter: Enable

Name	SIP Entity 1	Protocol	Port	SIP Entity 2	Port	Connection Policy	Notes
* ASBCE-link	* devcon-asm	TCP	* 5060	* ASBCE	* 5060	Trusted	

## 6.7. Add Routing Policies

Routing policies describe the conditions under which calls will be routed to the SIP Entities specified in **Section 6.5**. Two routing policies must be added: one for Communication Manager and one for the Avaya SBCE. To add a routing policy, navigate to **Routing → Routing Policies** in the left-hand navigation pane (**Section 6.1**) and click on the **New** button in the right pane (not shown). In the new right pane that appears (shown below), fill in the following:

In the **General** section, enter the following values. Use default values for all remaining fields.

- **Name:** Enter a descriptive name.
- **Notes:** Add a brief description (optional).

In the **SIP Entity as Destination** section, click **Select**. The **SIP Entity List** page opens (not shown). Select the appropriate SIP entity to which this routing policy applies and click **Select**. The selected SIP Entity displays on the Routing Policy Details page as shown below. Use default values for remaining fields. Click **Commit** to save.

The following screens show the Routing Policies for Communication Manager and the Avaya SBCE.

Routing Policy Details Commit Cancel

**General**

\* **Name:** Trenton Route

**Disabled:** ☐

**Notes:**

**SIP Entity as Destination**

Select

Name	FQDN or IP Address	Type	Notes
Trenton Trk 34	10.1.2.233	CM	

Routing Policy Details

CommitCancel

General

\* Name: ASBCE-route

Disabled: ☐

Notes: Outbound to ASBCE for SP testing

SIP Entity as Destination

Select

Name	FQDN or IP Address	Type	Notes
ASBCE	10.32.128.18	SIP Trunk	CPE Avaya SBC For Enterprise

## 6.8. Add Dial Patterns

Dial Patterns are needed to route calls through Session Manager. For the compliance test, dial patterns were needed to route calls from Communication Manager to Level 3 and vice versa. Dial Patterns define which route policy will be selected for a particular call based on the dialed digits, destination domain and originating location. To add a dial pattern, navigate to **Routing → Dial Patterns** in the left-hand navigation pane (**Section 6.1**) and click on the **New** button in the right pane (not shown). In the new right pane that appears (shown below), fill in the following:

In the **General** section, enter the following values. Use default values for all remaining fields.

- **Pattern:** Enter a dial string that will be matched against the Request-URI of the call.
- **Min:** Enter a minimum length used in the match criteria.
- **Max:** Enter a maximum length used in the match criteria.
- **SIP Domain:** Enter the destination domain used in the match criteria.
- **Notes:** Add a brief description (optional).

In the **Originating Locations and Routing Policies** section, click **Add**. From the **Originating Locations and Routing Policy List** that appears (not shown), select the appropriate originating location for use in the match criteria. Lastly, select the routing policy from the list that will be used to route all calls that match the specified criteria. Click **Select**.

Default values can be used for the remaining fields. Click **Commit** to save.



Two examples of the dial patterns used for the compliance test are shown below. The first example shows that 11 digit numbers that begin with a 1 and have a destination domain of **avaya.com** from **ALL** locations uses route policy **ASBCE-route**.

Dial Pattern Details
Commit
Cancel

General

\* Pattern: 1

\* Min: 11

\* Max: 11

Emergency Call: ☐

SIP Domain: avaya.com

Notes:

Originating Locations and Routing Policies

Add Remove

1 Item Refresh Filter: Enable

<input type="checkbox"/>	Originating Location Name 1 ▲	Originating Location Notes	Routing Policy Name	Rank 2 ▲	Routing Policy Disabled	Routing Policy Destination	Routing Policy Notes
<input type="checkbox"/>	-ALL-	Any Locations	ASBCE-route	0	<input type="checkbox"/>	ASBCE	Outbound to ASBCE for SP testing

Select : All, None

The second example shows that **10** digit numbers that start with **973555** to any domain and originating from any location uses route policy **Trenton Trk 34**. These are the DID numbers assigned to the enterprise from Level 3.

Dial Pattern Details
Commit
Cancel

General

\* Pattern: 973555

\* Min: 10

\* Max: 10

Emergency Call: ☐

SIP Domain: -ALL-

Notes: Level 3 inbound DID numbers

Originating Locations and Routing Policies

Add Remove

1 Item Refresh Filter: Enable

<input type="checkbox"/>	Originating Location Name 1 ▲	Originating Location Notes	Routing Policy Name	Rank 2 ▲	Routing Policy Disabled	Routing Policy Destination	Routing Policy Notes
<input type="checkbox"/>	-ALL-	Any Locations	Trenton Route	0	<input type="checkbox"/>	Trenton Trk 34	

Select : All, None

The complete list of dial patterns defined for the compliance test is shown below.

Dial Patterns

Edit New Duplicate Delete More Actions ▼ Commit

8 Items Refresh Filter: Enable

<input type="checkbox"/>	Pattern	Min	Max	Emergency Call	SIP Domain	Notes
<input type="checkbox"/>	<u>0</u>	1	11	<input type="checkbox"/>	avaya.com	
<input type="checkbox"/>	<u>011</u>	10	18	<input type="checkbox"/>	avaya.com	
<input type="checkbox"/>	<u>1</u>	11	11	<input type="checkbox"/>	avaya.com	
<input type="checkbox"/>	<u>411</u>	3	3	<input type="checkbox"/>	avaya.com	
<input type="checkbox"/>	<u>973555</u>	10	10	<input type="checkbox"/>	-ALL-	Level 3 inbound DID numbers

Select : All, None

## 6.9. Add/View Avaya Aura® Session Manager

The creation of a Session Manager element provides the linkage between System Manager and Session Manager. This was most likely done as part of the initial Session Manager installation. To add a Session Manager, from the **Home** page, navigate to **Elements → Session Manager → Session Manager Administration** in the left-hand navigation pane (**Section 6.1**) and click on the **New** button in the right pane (not shown). If the Session Manager already exists, select the appropriate Session Manager and click **View** (not shown) to view the configuration. Enter/verify the data as described below and shown in the following screen:

In the **General** section, enter the following values:

- **SIP Entity Name:** Select the SIP Entity created for Session Manager.
- **Description:** Add a brief description (optional).
- **Management Access Point Host Name/IP:** Enter the IP address of the Session Manager management interface.

The screen below shows the Session Manager values used for the compliance test.

**View Session Manager**Return

General | Security Module | NIC Bonding | Monitoring | CDR | Personal Profile Manager (PPM) - Connection Settings | Event Server |  
Expand All | Collapse All

**General** ▾

**SIP Entity Name**

**Description**

**Management Access Point Host Name/IP**

**Direct Routing to Endpoints**

In the **Security Module** section, enter the following values:

- **SIP Entity IP Address:** Should be filled in automatically based on the SIP Entity Name. Otherwise, enter IP address of Session Manager signaling interface.
- **Network Mask:** Enter the network mask corresponding to the IP address of Session Manager.
- **Default Gateway:** Enter the IP address of the default gateway for Session Manager.

Use default values for the remaining fields. Click **Save** (not shown) to add this Session Manager. The screen below shows the remaining Session Manager values used for the compliance test.

**Security Module** ▼

<b>SIP Entity IP Address</b>	10.32.24.235
<b>Network Mask</b>	255.255.255.0
<b>Default Gateway</b>	10.32.24.1
<b>Call Control PHB</b>	46
<b>QOS Priority</b>	6
<b>Speed &amp; Duplex</b>	Auto
<b>VLAN ID</b>	


## 7. Configure Avaya Session Border Controller for Enterprise

This section describes the configuration of the Avaya SBCE. It is assumed that the initial installation of the Avaya SBCE has been completed including the assignment of a management IP address. For the compliance test, the Avaya SBCE management interface was on the same subnet as the private interface A1. However at a customer site, the management interface **must** be provisioned on a different subnet than either the Avaya SBCE private or public network interfaces (e.g., A1 and B1). If the management interface has not been configured on a separate subnet, then contact your Avaya representative for guidance in correcting the configuration.

On all screens described in this section, it is to be assumed that parameters are left at their default values unless specified otherwise.

### 7.1. Access the Management Interface

Use a web browser to access the web interface by entering the URL **https://<ip-addr>**, where **<ip-addr>** is the management IP address assigned during installation. A screen will appear (not shown) requesting the user to **Choose a destination**. Select **UC-Sec Control Center** and the Avaya SBCE login page will appear as shown below. Log in with appropriate credentials.




The UC-Sec™ family of products from Sipera Systems delivers comprehensive VoIP security by adapting the best practices of internet security and by using unique, sophisticated techniques such as VoIP protocol misuse & anomaly detection, behavioral learning based anomaly detection and voice spam detection to protect VoIP networks.

[Visit the Sipera Systems website to learn more.](#)


**NOTICE TO USERS:** This system is for authorized use only. Unauthorized use of this system is strictly prohibited. Unauthorized or improper use of this system may result in civil and/or criminal penalties. Use of this system constitutes consent to security monitoring. All activity is logged with login info, host name and IP address.

After logging in, the Welcome screen will appear as shown below. All configuration screens of the Avaya SBCE are accessed by navigating the menu tree in the left pane.



## 7.2. Verify Network Configuration and Enable Interfaces

To view the network information provided during installation, navigate to **System Management**. In the right pane, click the **View Config** icon highlighted below.



A System Information page will appear showing the information provided during installation. In the **Appliance Name** field is the name of the device (**sp-ucsec1**). This name will be referenced in other configuration screens. Interfaces **A1** and **B1** represent the private and public interfaces of the Avaya SBCE. Each of these interfaces must be enabled after installation.

System Information: sp-ucsec1

Network Configuration

General Settings

Appliance Name	sp-ucsec1
Box Type	SIP
Deployment Mode	Proxy

Device Settings

HA Mode	No
Secure Channel Mode	None
Two Bypass Mode	No

Network Settings

IP	Public IP	Netmask	Gateway	Interface
10.32.128.18	10.32.128.18	255.255.255.0	10.32.128.254	A1
192.168.96.228	192.168.96.228	255.255.255.224	192.168.96.254	B1

DNS Configuration

Primary DNS	10.32.128.200
Secondary DNS	
DNS Location	DMZ
DNS Client IP	10.32.128.18

Management IP(s)

IP	10.32.128.17
----	--------------

To enable the interfaces, first navigate to **Device Specific Settings** → **Network Management** in the left pane and select the device being managed in the center pane. The right pane will show the same **A1** and **B1** interfaces displayed in the previous screen. Click on the **Interface Configuration** tab.

The screenshot shows the UC-Sec Control Center interface. On the left, the 'Device Specific Settings' menu is expanded, and 'Network Management' is selected. In the center pane, 'sp-ucsec1' is selected under 'UC-Sec Devices'. The right pane shows the 'Interface Configuration' tab. A warning message states: 'Modifications or deletions of an IP address or its associated data require an application restart before taking effect. Application restarts can be issued from System Management.' Below this, there are fields for 'A1 Netmask' (255.255.255.0), 'A2 Netmask' (disabled), 'B1 Netmask' (255.255.255.224), and 'B2 Netmask' (disabled). There are buttons for 'Add IP', 'Save Changes', and 'Clear Changes'. A table lists the interfaces with their IP addresses, public IPs, gateways, and administrative status.

IP Address	Public IP	Gateway	Interface	
10.32.128.18		10.32.128.254	A1	✗
192.168.96.228		192.168.96.254	B1	✗

On the **Interface Configuration** tab, verify the **Administrative Status** is **Enabled** for both the **A1** and **B1** interfaces. If not, click the **Toggle State** button to enable the interface.

Network Configuration		Interface Configuration
Name	Administrative Status	
A1	Enabled	Toggle State
A2	Disabled	Toggle State
B1	Enabled	Toggle State
B2	Disabled	Toggle State



## 7.3. Signaling Interface

A signaling interface defines an IP address, protocols and listen ports that the Avaya SBCE can use for signaling. Create a signaling interface for both the internal and external sides of the Avaya SBCE.

To create a new interface, navigate to **Device Specific Settings → Signaling Interface** in the left pane. In the center pane, select the Avaya SBCE device (**sp-ucsec1**) to be managed. In the right pane, select **Add Signaling Interface**. A pop-up window (not shown) will appear requesting the name of the new interface, followed by series of pop-up windows in which the interface parameters can be configured. Once complete, the settings are shown in the far right pane.

For the compliance test, signaling interface **Int\_Sig\_Intf** was created for the Avaya SBCE internal interface. When configuring the interface, configure the parameters as follows:

- Set **Name** to a descriptive name.
- Set the **Signaling IP** to the IP address associated with the private interface (A1) defined in **Section 7.2**.
- Set **TCP port** to the port the Avaya SBCE will listen on for SIP requests from Session Manager.

Signaling interface **Ext\_Sig\_Intf** was created for the Avaya SBCE external interface. When configuring the interface, configure the parameters as follows:

- Set **Name** to a descriptive name.
- Set the **Signaling IP** to the IP address associated with the public interface (B1) defined in **Section 7.2**.
- Set **UDP port** to the port the Avaya SBCE will listen on for SIP requests from the service provider.

The screenshot displays the UC-Sec Control Center interface. The left pane shows the navigation tree with 'Signaling Interface' selected under 'Device Specific Settings'. The center pane shows 'UC-Sec Devices' with 'sp-ucsec1' selected. The right pane shows the 'Signaling Interface' configuration table with two entries: 'Int\_Sig\_Intf' and 'Ext\_Sig\_Intf'. An 'Add Signaling Interface' button is visible in the top right of the right pane.

Name	Signaling IP	TCP Port	UDP Port	TLS Port	TLS Profile		
Int_Sig_Intf	10.32.128.18	5060	---	---	None		
Ext_Sig_Intf	192.168.96.228	---	5060	---	None		

## 7.4. Media Interface

A media interface defines an IP address and port range for transmitting media. Create a media interface for both the internal and external sides of the Avaya SBCE.

To create a new interface, navigate to **Device Specific Settings → Media Interface** in the left pane. In the center pane, select the Avaya SBCE device (**sp-ucsec1**) to be managed. In the right pane, select **Add Media Interface**. A pop-up window (not shown) will appear requesting the name of the new interface, followed by series of pop-up windows in which the interface parameters can be configured. Once complete, the settings are shown in the far right pane.

For the compliance test, signaling interface **Int\_Media\_Intf** was created for the Avaya SBCE internal interface. When configuring the interface, configure the parameters as follows:

- Set **Name** to a descriptive name.
- Set the **Media IP** to the IP address associated with the private interface (A1) defined in **Section 7.2**.
- Set **Port Range** to a range of ports acceptable to both the Avaya SBCE and Session Manager. For the compliance test, the port range used was selected arbitrarily.

Signaling interface **Ent\_Media\_Intf** was created for the Avaya SBCE external interface. When configuring the interface, configure the parameters as follows:

- Set **Name** to a descriptive name.
- Set the **Media IP** to the IP address associated with the public interface (B1) defined in **Section 7.2**.
- Set **Port Range** to a range of ports acceptable to both the Avaya SBCE and the service provider. For the compliance test, the port range used was selected arbitrarily.

The screenshot displays the UC-Sec Control Center interface. On the left, a navigation pane shows the 'Media Interface' option under 'Device Specific Settings' highlighted. The main area is titled 'Device Specific Settings > Media Interface: sp-ucsec1'. It features a 'Media Interface' tab and a table listing configured interfaces. A warning message states: 'Modifying or deleting an existing media interface will require an application restart before taking effect. Application restarts can be issued from System Management.' An 'Add Media Interface' button is visible. The table contains the following data:

Name	Media IP	Port Range		
Int_Media_Intf	10.32.128.18	35000 - 40000		
Ext_Media_Intf	192.168.96.228	35000 - 40000		

## 7.5. Server Interworking

A server interworking profile defines a set of parameters that aid in interworking between the Avaya SBCE and a connected server. Create a server interworking profile for the Session Manager and the service provider SIP server. These profiles will be applied to the appropriate server in **Section 7.7.1** and **7.7.2**.

To create a new profile, navigate to **Global Profiles → Server Interworking** in the left pane. In the center pane, select **Add Profile**. A pop-up window (not shown) will appear requesting the name of the new profile, followed by series of pop-up windows in which the profile parameters can be configured. Once complete, the settings are shown in the far right pane. To view the settings of an existing profile, select the profile from the center pane. The settings will appear in the right pane.

The screenshot displays the UC-Sec Control Center interface. On the left, the navigation pane shows the hierarchy: UC-Sec Control Center > Global Profiles > Server Interworking. The 'Server Interworking' item is highlighted. The main pane is titled 'Global Profiles > Server Interworking: Avaya-SM'. It features a list of profiles on the left, with 'Avaya-SM' selected. The right pane shows the configuration for the selected profile, with tabs for General, Timers, URI Manipulation, Header Manipulation, and Advanced. The 'General' tab is active, displaying a table of parameters.

General	
Hold Support	RFC3264
180 Handling	None
181 Handling	None
182 Handling	None
183 Handling	None
Refer Handling	No
3xx Handling	No
Diversion Header Support	No

### 7.5.1. Server Interworking – Session Manager

For the compliance test, server interworking profile **Avaya-SM** was created for Session Manager. When creating the profile, configure the General tab parameters as follows:

- Set **Hold Support** to **RFC3264**.
- Enable **T.38 Support**.

General	
Hold Support	RFC3264
180 Handling	None
181 Handling	None
182 Handling	None
183 Handling	None
Refer Handling	No
3xx Handling	No
Diversion Header Support	No
Delayed SDP Handling	No
T.38 Support	Yes
URI Scheme	SIP
Via Header Format	RFC3261

Privacy	
Privacy Enabled	No
User Name	
P-Asserted-Identity	No
P-Preferred-Identity	No
Privacy Header	

DTMF	
DTMF Support	None

[Edit](#)

On the Advanced tab, disable **Topology Hiding: Change Call-ID** and enable the **Avaya Extensions**. It was necessary to disable **Topology Hiding: Change Call-ID** for the Level 3 server interworking profile. See **Section 7.5.2** for details. It is disabled here in the Session Manager interworking profile as a precaution.

General
Timers
URI Manipulation
Header Manipulation
Advanced

Advanced Settings	
Record Routes	BOTH
Topology Hiding: Change Call-ID	No
Call-Info NAT	No
Change Max Forwards	Yes
Include End Point IP for Context Lookup	No
OCS Extensions	No
AVAYA Extensions	Yes
NORTEL Extensions	No
SLIC Extensions	No
Diversion Manipulation	No
Metaswitch Extensions	No
Reset on Talk Spurt	No
Reset SRTP Context on Session Refresh	No
Has Remote SBC	Yes
Route Response on Via Port	No
Cisco Extensions	No

Edit

### 7.5.2. Server Interworking – Level 3

For the compliance test, server interworking profile **SP-Level3** was created for the Level 3 SIP server. When creating the profile, configure the General tab parameters as follows:

- Set **Hold Support** to **RFC3264**.
- Enable **T.38 Support**.

General	
Hold Support	RFC3264
180 Handling	None
181 Handling	None
182 Handling	None
183 Handling	None
Refer Handling	No
3xx Handling	No
Diversion Header Support	No
Delayed SDP Handling	No
T.38 Support	Yes
URI Scheme	SIP
Via Header Format	RFC3261
Privacy	
Privacy Enabled	No
User Name	
P-Asserted-Identity	No
P-Preferred-Identity	No
Privacy Header	
DTMF	
DTMF Support	None

[Edit](#)

On the Advanced tab, disable **Topology Hiding: Change Call-ID** and disable the **Avaya Extensions**. It is necessary to disable **Topology Hiding: Change Call-ID** when Network Call Redirection (NCR) is enabled on Communication Manager. Otherwise, the wrong Call-ID is passed in the Replaces parameter of the Refer-To header in the REFER message sent to the Level 3. If this occurs, the transferred call fails with a 603 Decline response from Level 3 and the original call has one-way audio.


Advanced Settings	
Record Routes	BOTH
Topology Hiding: Change Call-ID	No
Call-Info NAT	No
Change Max Forwards	Yes
Include End Point IP for Context Lookup	No
OCS Extensions	No
AVAYA Extensions	No
NORTEL Extensions	No
SLIC Extensions	No
Diversion Manipulation	No
Metaswitch Extensions	No
Reset on Talk Spurt	No
Reset SRTP Context on Session Refresh	No
Has Remote SBC	Yes
Route Response on Via Port	No
Cisco Extensions	No

[Edit](#)

## 7.6. Signaling Manipulation

Signaling manipulation scripts provides for the manipulation of SIP messages which cannot be done by other configuration within the Avaya SBCE. Session Manager requires the signaling manipulation script defined in **Section 7.6.1**. It is applied to the Level 3 SIP server in **Section 7.7.2**.

To create a script, navigate to **Global Profiles → Signaling Manipulation** in the left pane. In the center pane, select **Add Script**. A script editor window (not shown) will appear in which the script can be entered line by line. The **Title** box at the top of the editor window (not shown) is where the name of the script is entered. Once complete, the script is shown in the far right pane. To view an existing script, select the script from the center pane. The settings will appear in the right pane.





### 7.6.1. Signaling Manipulation – Level 3

For the compliance test, signaling manipulation script **IncMaxFwd** was created for the Level 3 SIP server. The script increases the value of the Max-Forwards header in an inbound INVITE message from Level 3. The initial Max-Forwards value is too small to allow the message to traverse all the SIP hops internal to the enterprise to reach the destination in all cases. Thus, the Avaya SBCE was used to increase this value when the INVITE arrived at the Avaya SBCE from the network.

Signaling Manipulation


```
within session "INVITE"
{
  act on request where $DIRECTION="INBOUND" and $ENTRY_POINT="PRE_ROUTING"
  {
    if (exists($HEADERS["Max-Forwards"][1])) then
    {
      $HEADERS["Max-Forwards"][1] = "70";
    }
  }
}
```

Edit

## 7.7. Server Configuration

A server configuration profile defines the attributes of the physical server. Create a server configuration profile for the Session Manager and the service provider SIP server.

To create a new profile, navigate to **Global Profiles → Server Configuration** in the left pane. In the center pane, select **Add Profile**. A pop-up window (not shown) will appear requesting the name of the new profile, followed by series of pop-up windows in which the profile parameters can be configured. Once complete, the settings are shown in the far right pane. To view the settings of an existing profile, select the profile from the center pane. The settings will appear in the right pane.



### 7.7.1. Server Configuration – Session Manager

For the compliance test, server configuration profile **Avaya-SM** was created for Session Manager. When creating the profile, configure the General tab parameters as follows:

- Set **Server Type** to **Call Server**.
- Set **IP Addresses / FQDNs** to the IP address of Session Manager signaling interface.
- Set **Supported Transports** to the transport protocol used for SIP signaling between the Session Manager and the Avaya SBCE.
- Set the **TCP Port** to the port the Session Manager will listen on for SIP requests from the Avaya SBCE.

The screenshot shows the configuration interface for the 'Avaya-SM' profile. At the top, there are three buttons: 'Rename Profile', 'Clone Profile', and 'Delete Profile'. Below these are four tabs: 'General', 'Authentication', 'Heartbeat', and 'Advanced'. The 'General' tab is selected. The configuration table below has the following data:

General	
Server Type	Call Server
IP Addresses / FQDNs	10.32.24.235
Supported Transports	TCP
TCP Port	5060

At the bottom of the table is an 'Edit' button.

On the Advanced tab, set the **Interworking Profile** field to the interworking profile for the Session Manager defined in **Section 7.5.1**.

The screenshot shows the configuration interface for the 'Avaya-SM' profile, with the 'Advanced' tab selected. The configuration table below has the following data:

Advanced	
Enable DoS Protection	<input type="checkbox"/>
Enable Grooming	<input type="checkbox"/>
Interworking Profile	Avaya-SM
Signaling Manipulation Script	None
TCP Connection Type	SUBID

At the bottom of the table is an 'Edit' button.

### 7.7.2. Server Configuration – Level 3

For the compliance test, server configuration profile **SP-Level3** was created for Level 3. When creating the profile, configure the General tab parameters as follows:

- Set **Server Type** to **Trunk Server**.
- Set **IP Addresses / FQDNs** to the IP address of the Level 3 SIP server.
- Set **Supported Transports** to the transport protocol used for SIP signaling between Level 3 and the Avaya SBCE.
- Set the **UDP Port** to the port Level 3 will listen on for SIP requests from the Avaya SBCE.

The screenshot shows the configuration interface for the 'SP-Level3' profile. At the top, there are three buttons: 'Rename Profile', 'Clone Profile', and 'Delete Profile'. Below these are four tabs: 'General', 'Authentication', 'Heartbeat', and 'Advanced'. The 'General' tab is selected, showing a table with the following configuration:

General	
Server Type	Trunk Server
IP Addresses / FQDNs	192.168.35.84
Supported Transports	UDP
UDP Port	5070

Below the table is an 'Edit' button.

On the Authentication tab, configure the parameters using the credentials provided by Level 3 as follows:

- Click the **Enable Authentication** check box.
- Set **User Name** to the user name provided by Level 3.
- Set **Password** to the password provided by Level 3. This field is not shown in the summary screenshot below.
- Set **Realm** to the realm provided by Level 3.

The screenshot shows the configuration interface for the 'SP-Level3' profile, specifically the 'Authentication' tab. At the top, there are three buttons: 'Rename Profile', 'Clone Profile', and 'Delete Profile'. Below these are four tabs: 'General', 'Authentication', 'Heartbeat', and 'Advanced'. The 'Authentication' tab is selected, showing a table with the following configuration:

Authentication	
Enable Authentication	<input checked="" type="checkbox"/>
User Name	1-23Q-3413
Realm	BroadWorks

Below the table is an 'Edit' button.

Session Manager will generate OPTIONS messages that will be forwarded by the Avaya SBCE to the service provider. Alternatively, the Avaya SBCE can be configured to send OPTIONS messages to the service provider. Both approaches were tested by the compliance test. To configure the Avaya SBCE to generate OPTIONS messages configure the parameters on the Heartbeat tab as follows:

- Click the **Enable Heartbeat** check box.
- Set **Method** to **OPTIONS**.
- Set **Frequency** to the desired interval between OPTIONS messages.
- Set **From URI** to a valid URI in the form of **number@domain** where the **number** is a valid DID assigned to the enterprise and the **domain** is the enterprise SIP domain.
- Set **To URI** to a valid URI in the form of **number@domain** where the **number** is the same number used in the **From URI** and the **domain** is the service provider domain.

[Rename Profile](#)
[Clone Profile](#)
[Delete Profile](#)

[General](#)
[Authentication](#)
[Heartbeat](#)
[Advanced](#)

Heartbeat	
Enable Heartbeat	<input checked="" type="checkbox"/>
Method	OPTIONS
Frequency	60 seconds
From URI	9732418445@sip.avaya.com
To URI	9732418445@192.168.35.84
TCP Probe	<input type="checkbox"/>

[Edit](#)

On the Advanced tab, set the **Interworking Profile** field to the interworking profile for Level 3 defined in **Section 7.5.2**. Set the **Signaling Manipulation Script** field to the signaling manipulation script for the Level 3 SIP server defined in **Section 7.6.1**.

Advanced	
Enable DoS Protection	<input type="checkbox"/>
Enable Grooming	<input type="checkbox"/>
Interworking Profile	SP-Level3
Signaling Manipulation Script	IncMaxFwd
UDP Connection Type	SUBID

[Edit](#)

## 7.8. Signaling Rules

A signaling rule defines the processing to be applied to the selected signaling traffic. A signaling rule is one component of the larger endpoint policy group defined in **Section 7.10**. A specific signaling rule was created for Session Manager. The Level 3 SIP server used the **default** rule.

To create a new rule, navigate to **Domain Policies → Signaling Rules** in the left pane. In the center pane, select **Add Rule**. A pop-up window (not shown) will appear requesting the name of the new rule, followed by series of pop-up windows in which the rule parameters can be configured. Once complete, the settings are shown in the far right pane. To view the settings of an existing rule, select the rule from the center pane. The settings will appear in the right pane. The example below shows the selection of rule **SM6-1\_SigRules**.

UC-Sec Control Center

Domain Policies > Signaling Rules: SM6-1\_SigRules

[Add Rule](#) [Filter By Device...](#) [Rename Rule](#) [Clone Rule](#) [Delete Rule](#)

**Signaling Rules**

default

SM6-1\_SigRules

[Click here to add a description.](#)

**General** **Requests** **Responses** **Request Headers** **Response Headers** **Signaling QoS**







Inbound	
Requests	Allow
Non-2XX Final Responses	Allow
Optional Request Headers	Allow
Optional Response Headers	Allow

### 7.8.1. Signaling Rules – Session Manager

For the compliance test, signaling rule **SM6-1\_SigRules** was created for Session Manager to prevent proprietary headers in the SIP messages sent from the Session Manager from being propagated to Level 3. Select this rule in the center pane, then select the Request Headers tab to view the manipulations performed on request messages such as the initial INVITE or UPDATE message.











An entry is created by clicking the **Add In Header Control** or **Add Out Header Control** button depending on the direction (relative to the Avaya SBCE) of the message to be modified. The entries perform the following actions:

1. Removes the **P-Charging Vector** header from the **INVITE** message in the **IN** direction (Session Manager to Avaya SBCE).
2. Removes the **P-Charging Vector** header from the **UPDATE** message in the **IN** direction.
3. Removes the **P-Location** header from the **INVITE** message in the **IN** direction.

General Requests Responses Request Headers Response Headers Signaling QoS								
Add In Header Control					Add Out Header Control			
Row	Header Name	Method Name	Header Criteria	Action	Proprietary	Direction		
1	P-Charging-Vector	INVITE	Forbidden	Remove Header	Yes	IN		
2	P-Charging-Vector	UPDATE	Forbidden	Remove Header	Yes	IN		
3	P-Location	INVITE	Forbidden	Remove Header	Yes	IN		

Similarly, manipulations can be performed on SIP response messages. These can be viewed by selecting the Response Headers tab as shown below. Entries were created in the same manner as was done on the Request Headers tab. The entries shown perform the following actions:

1. Removes the **P-Charging Vector** header from the **200** response to an **INVITE** message in the **IN** direction (Session Manager to Avaya SBCE).
2. Removes the **P-Charging Vector** header from the **200** response to an **UPDATE** message in the **IN** direction.
3. Removes the **P-Location** header from the **181** response to an **INVITE** message in the **IN** direction.
4. Removes the **P-Location** header from the **183** response to an **INVITE** message in the **IN** direction.
5. Removes the **P-Location** header from the **200** response to an **INVITE** message in the **IN** direction.


General Requests Responses Request Headers Response Headers Signaling QoS									
Add In Header Control					Add Out Header Control				
Row	Header Name	Response Code	Method Name	Header Criteria	Action	Proprietary	Direction		
1	P-Charging-Vector	200	INVITE	Forbidden	Remove Header	Yes	IN		
2	P-Charging-Vector	200	UPDATE	Forbidden	Remove Header	Yes	IN		
3	P-Location	181	INVITE	Forbidden	Remove Header	Yes	IN		
4	P-Location	183	INVITE	Forbidden	Remove Header	Yes	IN		
5	P-Location	200	INVITE	Forbidden	Remove Header	Yes	IN		




## 7.9. Media Rules

A media rule defines the processing to be applied to the selected media. A media rule is one component of the larger endpoint policy group defined in **Section 7.10**.

To create a new rule, navigate to **Domain Policies** → **Media Rules** in the left pane. In the center pane, select **Add Rule**. A pop-up window (not shown) will appear requesting the name of the new rule, followed by series of pop-up windows in which the rule parameters can be configured. Once complete, the settings are shown in the far right pane. Alternatively, a new rule may be created by selecting an existing rule in the center pane and clicking the **Clone Rule** button in the right pane. This will create a copy of the selected rule which can then be edited as needed. To view the settings of an existing rule, select the rule from the center pane. The settings will appear in the right pane.



For the compliance test, a single media rule **modified-dft-low-med** was created that was used for both the Session Manager and the Level 3 SIP server. It was created by cloning the existing rule **default-low-med** which uses unencrypted media and then disabling **Media Anomaly Detection** on the Media Anomaly tab. This was done to prevent some false media errors from impacting the RTP media stream.





## 7.10. Endpoint Policy Groups

An endpoint policy group is a set of policies that will be applied to traffic between the Avaya SBCE and a signaling endpoint (connected server). Thus, an endpoint policy group must be created for Session Manager and the service provider SIP server. The endpoint policy group is applied to the traffic as part of the endpoint flow defined in **Section 7.13**.

To create a new group, navigate to **Domain Policies → End Point Policy Groups** in the left pane. In the center pane, select **Add Group**. A pop-up window (not shown) will appear requesting the name of the new group, followed by series of pop-up windows in which the group parameters can be configured. Once complete, the settings are shown in the far right pane. To view the settings of an existing group, select the group from the center pane. The settings will appear in the right pane.



The screenshot shows the UC-Sec Control Center interface. On the left is a navigation tree with 'End Point Policy Groups' selected. The main area is titled 'Domain Policies > End Point Policy Groups: SM6-1'. It features an 'Add Group' button, a 'Filter By Device...' dropdown, and buttons for 'Rename Group' and 'Delete Group'. Below these are instructions to 'Click here to add a description.' and 'Hover over a row to see its description.' A 'Policy Group' tab is active, showing a table with columns: Order, Application, Border, Media, Security, Signaling, Time of Day, and an edit/delete icon. The table contains one row with the following values: Order 1, Application default, Border default, Media modified-dft-low-med, Security default-low, Signaling SM6-1\_SigRules, Time of Day default. Above the table are buttons for 'View Summary' and 'Add Policy Set'.

Order	Application	Border	Media	Security	Signaling	Time of Day	
1	default	default	modified-dft-low-med	default-low	SM6-1_SigRules	default	 

### 7.10.1. Endpoint Policy Group – Session Manager


For the compliance test, endpoint policy group **SM6-1** was created for Session Manager. Default values were used for each of the rules which comprise the group with the exception of **Media** and **Signaling**. For **Media**, select the media rule created in **Section 7.9**. For **Signaling**, select the signaling rule created for the Session Manager in **Section 7.8.1**.

This is a detailed view of the 'Policy Group' configuration for SM6-1. It shows a table with the same columns as the previous screenshot. The values are: Order 1, Application default, Border default, Media modified-dft-low-med, Security default-low, Signaling SM6-1\_SigRules, Time of Day default. Above the table are buttons for 'View Summary' and 'Add Policy Set'.

Order	Application	Border	Media	Security	Signaling	Time of Day	
1	default	default	modified-dft-low-med	default-low	SM6-1_SigRules	default	 

### 7.10.2. Endpoint Policy Group – Level 3

For the compliance test, endpoint policy group **General-SP** was created for the Level 3 SIP server. Default values were used for each of the rules which comprise the group with the exception of **Media**. For **Media**, select the media rule created in **Section 7.9**.




Order	Application	Border	Media	Security	Signaling	Time of Day		
1	default	default	modified-dft-low-med	default-low	default	default		

## 7.11. Routing

A routing profile defines where traffic will be directed based on the contents of the URI. A routing profile is applied only after the traffic has matched an endpoint server flow defined in **Section 7.13**. Create a routing profile for the Session Manager and the service provider SIP server.

To create a new profile, navigate to **Global Profiles → Routing** in the left pane. In the center pane, select **Add Profile**. A pop-up window (not shown) will appear requesting the name of the new profile, followed by series of pop-up windows in which the profile parameters can be configured. Once complete, the settings are shown in the far right pane. To view the settings of an existing profile, select the profile from the center pane. The settings will appear in the right pane. The example below shows the selection of profile **To\_SM**.



Priority	URI Group	Next Hop Server 1	Next Hop Server 2	Next Hop Priority	NAPTR	SRV	Next Hop in Dialog	Ignore Route Header	Outgoing Transport		
1	*	10.32.24.235	---	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	TCP		

### 7.11.1. Routing – Session Manager

For the compliance test, routing profile **To\_SM** was created for Session Manager. When creating the profile, configure the parameters as follows:

- Set the **URI Group** to the wild card \* to match on any URI.
- Set the **Next Hop Server 1** field to the IP address of the Session Manager signaling interface.
- Enable **Next Hop Priority**.
- Set the **Outgoing Transport** field to **TCP**.

Priority	URI Group	Next Hop Server 1	Next Hop Server 2	Next Hop Priority	NAPTR	SRV	Next Hop in Dialog	Ignore Route Header	Outgoing Transport		
1	*	10.32.24.235	---	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	TCP		

### 7.11.2. Routing – Level 3

For the compliance test, routing profile **To\_Trunks** was created for Level 3. When creating the profile, configure the parameters as follows:

- Set the **URI Group** to the wild card \* to match on any URI.
- Set the **Next Hop Server 1** field to the IP address of the Level 3 SIP server followed by the port number.
- Enable **Next Hop Priority**.
- Set the **Outgoing Transport** field to **UDP**.

Priority	URI Group	Next Hop Server 1	Next Hop Server 2	Next Hop Priority	NAPTR	SRV	Next Hop in Dialog	Ignore Route Header	Outgoing Transport		
1	*	192.168.35.84:5070	---	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	UDP		

## 7.12. Topology Hiding

Topology hiding allows the host part of some SIP message headers to be modified in order to prevent private network information from being propagated to the untrusted public network. It can also be used as an interoperability tool to adapt the host portion of these same headers to meet the requirements of the connected servers. The topology hiding profile is applied as part of the endpoint flow in **Section 7.13**.

To create a new profile, navigate to **Global Profiles → Topology Hiding** in the left pane. In the center pane, select **Add Profile**. A pop-up window (not shown) will appear requesting the name of the new profile, followed by a pop-up window in which a header can be selected and configured. Additional headers can be added in this window. Once complete, the settings are shown in the far right pane. To view the settings of an existing profile, select the profile from the center pane. The settings will appear in the right pane. The example below shows the selection of profile **Avaya\_SM**.

The screenshot displays the UC-Sec Control Center interface. On the left, the 'Global Profiles' tree is expanded, and 'Topology Hiding' is selected. The center pane shows the 'Global Profiles > Topology Hiding: Avaya-SM' configuration page. The 'Add Profile' button is highlighted. Below it, the 'Topology Hiding Profiles' list shows 'Avaya-SM' selected. The right pane displays the configuration for the 'Avaya-SM' profile, including a table for 'Topology Hiding' settings.

Header	Criteria	Replace Action	Overwrite Value
To	IP/Domain	Overwrite	avaya.com
Record-Route	IP/Domain	Auto	---
From	IP/Domain	Overwrite	avaya.com
Via	IP/Domain	Auto	---
SDP	IP/Domain	Auto	---
Request-Line	IP/Domain	Overwrite	avaya.com

### 7.12.1. Topology Hiding – Session Manager

For the compliance test, topology hiding profile **Avaya\_SM** was created for Session Manager. This profile will be applied to traffic from the Avaya SBCE to Session Manager. When creating the profile, configure the parameters as follows:

- Set **Header** to the header whose host part of the URI is to be modified.
- Set **Criteria** to **IP/Domain** to indicate that the host part should be modified if it is an IP address or a domain.
- Set **Replace Action** to **Auto** for all headers except **Request-Line**, **From** and **To** which should be set to **Overwrite**.
- For those headers to be overwritten, the **Overwrite Value** is set to the enterprise domain (**avaya.com**).

Topology Hiding			
Header	Criteria	Replace Action	Overwrite Value
SDP	IP/Domain	Auto	---
Request-Line	IP/Domain	Overwrite	avaya.com
From	IP/Domain	Overwrite	avaya.com
Record-Route	IP/Domain	Auto	---
To	IP/Domain	Overwrite	avaya.com
Via	IP/Domain	Auto	---
Edit			

### 7.12.2. Topology Hiding – Level 3

For the compliance test, topology hiding profile **SP-General** was created for Level 3. This profile will be applied to traffic from the Avaya SBCE to Level 3. When creating the profile, configure the parameters as follows:

- Set **Header** to the header whose host part of the URI is to be modified.
- Set **Criteria** to **IP/Domain** to indicate that the host part should be modified if it is an IP address or a domain.
- Set **Replace Action** to **Auto** for all headers except **Request-Line**, **From** and **To**. Set the **Replace Action** for the **Request-Line** and **To** headers to **Next Hop** which is the IP address of the Level 3 SIP server. Set the **Replace Action** for the **From** header to **Signaling Interface** which is the IP address of the public interface of the Avaya SBCE.

Topology Hiding			
Header	Criteria	Replace Action	Overwrite Value
SDP	IP/Domain	Auto	---
Request-Line	IP/Domain	Next Hop	---
From	IP/Domain	Signaling Interface	---
Record-Route	IP/Domain	Auto	---
To	IP/Domain	Next Hop	---
Via	IP/Domain	Auto	---
Edit			

## 7.13. End Point Flows

Endpoint flows are used to determine the signaling endpoints involved in a call in order to apply the appropriate policies. When a packet arrives at the Avaya SBCE, the content of the packet (IP addresses, URIs, etc) is used to determine which flow it matches. Once the flow is determined, the flow points to policies and profiles which control processing, privileges, authentication, routing, etc. Once routing is applied and the destination endpoint is determined, the policies for the destination endpoint are applied. Thus, two flows are involved in every call: the source endpoint flow and the destination endpoint flow. In the case of SIP trunking, the signaling endpoints are the Session Manager and the service provider SIP server.

To create a new flow for a server endpoint, navigate to **Device Specific Settings → End Point Flows** in the left pane. In the center pane, select the Avaya SBCE device (**sp-ucsec1**) to be managed. In the right pane, select the Server Flows tab and click the **Add Flow** button. A pop-up window (not shown) will appear requesting the name of the new flow and the flow parameters. Once complete, the settings are shown in the far right pane.



### 7.13.1. End Point Flow – Session Manager

For the compliance test, endpoint flow **SM** was created for the Session Manager. All traffic from the Session Manager will match this flow as the source flow and use the specified **Routing Profile To\_Trunks** to determine the destination server and corresponding destination flow. The **End Point Policy** and **Topology Hiding Profile** will be applied as appropriate. When creating the flow, configure the parameters as follows:

- For the **Flow Name**, enter a descriptive name.
- For **Server Configuration**, select the Session Manager server created in **Section 7.7.1**.
- To match all traffic, set the **URI Group**, **Transport**, and **Remote Subnet** to \*.
- Set the **Received Interface** to the external signaling interface.
- Set the **Signaling Interface** to the internal signaling interface.
- Set the **Media Interface** to the internal media interface.
- Set the **End Point Policy Group** to the endpoint policy group defined for Session Manager in **Section 7.10.1**.
- Set the **Routing Profile** to the routing profile defined in **Section 7.11.2** used to direct traffic to the Level 3 SIP server.

- Set the **Topology Hiding Profile** to the topology hiding profile defined for Session Manager in **Section 7.12.1**.

Server Configuration: Avaya-SM													
Priority	Flow Name	URI Group	Transport	Remote Subnet	Received Interface	Signaling Interface	Media Interface	End Point Policy Group	Routing Profile	Topology Hiding Profile	File Transfer Profile		
1	SM	*	*	*	Ext_Sig_Intf	Int_Sig_Intf	Int_Media_Intf	SM6-1	To_Trunks	Avaya-SM	None		

### 7.13.2. End Point Flow – Level 3

For the compliance test, endpoint flow **Level3** was created for the Level 3 SIP server. All traffic from Level 3 will match this flow as the source flow and use the specified **Routing Profile To\_SM** to determine the destination server and corresponding destination flow. The **End Point Policy** and **Topology Hiding Profile** will be applied as appropriate. When creating the flow, configure the parameters as follows:

- For the **Flow Name**, enter a descriptive name.
- For **Server Configuration**, select the Level 3 SIP server created in **Section 7.7.2**.
- To match all traffic, set the **URI Group**, **Transport**, and **Remote Subnet** to \*.
- Set the **Received Interface** to the internal signaling interface.
- Set the **Signaling Interface** to the external signaling interface.
- Set the **Media Interface** to the external media interface.
- Set the **End Point Policy Group** to the endpoint policy group defined for Level 3 in **Section 7.10.2**.
- Set the **Routing Profile** to the routing profile defined in **Section 7.11.1** used to direct traffic to the Session Manager.
- Set the **Topology Hiding Profile** to the topology hiding profile defined for Level 3 in **Section 7.12.2**.

Server Configuration: SP-Level3													
Priority	Flow Name	URI Group	Transport	Remote Subnet	Received Interface	Signaling Interface	Media Interface	End Point Policy Group	Routing Profile	Topology Hiding Profile	File Transfer Profile		
1	Level3	*	*	*	Int_Sig_Intf	Ext_Sig_Intf	Ext_Media_Intf	General-SP	To_SM	SP-General	None		



## 8. Verification Steps

This section provides verification steps that may be performed in the field to verify that the solution is configured properly. This section also provides a list of useful troubleshooting commands that can be used to troubleshoot the solution.

### Verification Steps:

1. Verify that endpoints at the enterprise site can place calls to the PSTN and that the call remains active for more than 35 seconds. This time period is included to verify that proper routing of the SIP messaging has satisfied SIP protocol timers.
2. Verify that endpoints at the enterprise site can receive calls from the PSTN and that the call can remain active for more than 35 seconds.
3. Verify that the user on the PSTN can end an active call by hanging up.
4. Verify that an endpoint at the enterprise site can end an active call by hanging up.

### Troubleshooting:

1. Communication Manager:
  - **list trace station** <extension number> - Traces calls to and from a specific station.
  - **list trace tac** <trunk access code number> - Trace calls over a specific trunk group.
  - **status station** <extension number> - Displays signaling and media information for an active call on a specific station.
  - **status trunk** <trunk access code number> - Displays trunk group information.
  - **status trunk** <trunk access code number/channel number> - Displays signaling and media information for an active trunk channel.
2. Session Manager:
  - **Call Routing Test** - The Call Routing Test verifies the routing for a particular source and destination. To run the routing test, navigate to **Elements → Session Manager → System Tools → Call Routing Test**. Enter the requested data to run the test.

## 9. Conclusion

These Application Notes describe the configuration necessary to connect Avaya Aura® Communication Manager, Avaya Aura® Session Manager and Avaya Session Border Controller for Enterprise to Level 3 SIP Trunking. Level 3 SIP Trunking is a SIP-based Voice over IP solution for customers ranging from small businesses to large enterprises. Level 3 SIP Trunking provides businesses a flexible, cost-saving alternative to traditional hardwired telephony trunks. Please refer to **Section 2.2** for any exceptions or workarounds.

## 10. References

This section references the documentation relevant to these Application Notes. Additional Avaya product documentation is available at <http://support.avaya.com>.

- [1] *Installing and Configuring Avaya Aura® System Platform*, Release 6.0.3, February 2011.
- [2] *Administering Avaya Aura® System Platform*, Release 6.0.3, February 2011.
- [3] *Administering Avaya Aura® Communication Manager*, August 2010, Document Number 03-300509.
- [4] *Avaya Aura® Communication Manager Feature Description and Implementation*, August 2010, Document Number 555-245-205.
- [5] *Installing and Upgrading Avaya Aura® System Manager*, Release 6.1, November 2010.
- [6] *Administering Avaya Aura® System Manager*, Release 6.1, November 2010.
- [7] *Installing and Configuring Avaya Aura® Session Manager*, Release 6.1, April 2011, Document Number 03-603473.
- [8] *Administering Avaya Aura® Session Manager*, Release 6.1, October 2011, Document Number 03-603324.
- [9] *Avaya 1600 Series IP Deskphones Administrator Guide Release 1.3.x*, May 2010, Document Number 16-601443.
- [10] *4600 Series IP Telephone LAN Administrator Guide*, October 2007, Document Number 555-233-507.
- [11] *Avaya one-X® Deskphone Edition for 9600 Series IP Telephones Administrator Guide*, November 2009, Document Number 16-300698.
- [12] *Administering Avaya one-X® Communicator*, July 2011.
- [13] RFC 3261 *SIP: Session Initiation Protocol*, <http://www.ietf.org/>
- [14] RFC 2833 *RTP Payload for DTMF Digits, Telephony Tones and Telephony Signals*, <http://www.ietf.org/>

---

**©2012 Avaya Inc. All Rights Reserved.**

Avaya and the Avaya Logo are trademarks of Avaya Inc. All trademarks identified by ® and ™ are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners. The information provided in these Application Notes is subject to change without notice. The configurations, technical data, and recommendations provided in these Application Notes are believed to be accurate and dependable, but are presented without express or implied warranty. Users are responsible for their application of any products specified in these Application Notes.

Please e-mail any questions or comments pertaining to these Application Notes along with the full title name and filename, located in the lower right corner, directly to the Avaya DevConnect Program at [devconnect@avaya.com](mailto:devconnect@avaya.com).