



## **Avaya Solution & Interoperability Test Lab**

---

# **Application Notes for Configuring Avaya Aura® Communication Manager R6.2 as an Evolution Server, Avaya Aura® Session Manager R6.2 and Avaya Session Border Controller for Enterprise to support Cable and Wireless SIP IP Trunking Service - Issue 1.0**

## **Abstract**

These Application Notes describe the steps used to configure Session Initiation Protocol (SIP) trunking between the Cable and Wireless SIP IP Trunking service and an Avaya SIP enabled Enterprise Solution. The Avaya solution consists of Avaya Session Border Controller for Enterprise, Avaya Aura® Session Manager and Avaya Aura® Communication Manager as an Evolution Server. Cable and Wireless is a member of the DevConnect Service Provider program.

Information in these Application Notes has been obtained through DevConnect compliance testing and additional technical discussions. Testing was conducted via the DevConnect Program at the Avaya Solution and Interoperability Test Lab.

**NOTE:** This Application Note is applicable with Avaya Aura® 6.2 which is currently in Controlled Introduction. Avaya Aura® 6.2 will be Generally Available in Summer 2012.

# 1. Introduction

These Application Notes describe the steps used to configure Session Initiation Protocol (SIP) trunking between Cable and Wireless SIP IP Trunking service and an Avaya SIP-enabled Enterprise Solution. The Avaya solution consists of Avaya Session Border Controller for Enterprise (Avaya SBCE), Avaya Aura® Session Manager and Avaya Aura® Communication Manager Evolution Server. Customers using this Avaya SIP-enabled enterprise solution with the Cable and Wireless SIP IP Trunking service are able to place and receive PSTN calls via a dedicated Internet connection and the SIP protocol. This converged network solution is an alternative to traditional PSTN trunks. This approach generally results in lower cost for the Enterprise customer.

## 2. General Test Approach and Test Results

The general test approach was to configure a simulated enterprise site using an Avaya SIP telephony solution consisting of Communication Manager, Session Manager and Avaya SBCE. The enterprise site was configured to use the SIP IP Trunking service provided by Cable and Wireless.

DevConnect Compliance Testing is conducted jointly by Avaya and DevConnect members. The jointly-defined test plan focuses on exercising APIs and/or standards-based interfaces pertinent to the interoperability of the tested products and their functionalities. DevConnect Compliance Testing is not intended to substitute full product performance or feature testing performed by DevConnect members, nor is it to be construed as an endorsement by Avaya of the suitability or completeness of a DevConnect member's solution.

### 2.1. Interoperability Compliance Testing

The general test approach was to configure a simulated enterprise site using an Avaya SIP telephony solution consisting of Communication Manager, Session Manager and Avaya SBCE. The enterprise site was configured to use the SIP IP Trunking service provided by Cable and Wireless. The interoperability test included the following:

- Incoming calls to the enterprise site from the PSTN routed to the DDI numbers assigned by Cable and Wireless
- Incoming PSTN calls made to SIP, H.323 and Analogue telephones at the enterprise
- Outgoing calls from the enterprise site completed via Cable and Wireless to PSTN destinations
- Outgoing calls from the enterprise to the PSTN made from SIP, H.323 and Analogue telephones
- Calls using the G.711A, and G.729A codecs
- DTMF transmission using RFC 2833 with successful Voice Mail/Vector navigation for inbound and outbound calls
- User features such as hold and resume, transfer, conference, call forwarding, etc
- Caller ID Presentation and Caller ID Restriction
- Direct IP-to-IP media (also known as “shuffling”) with SIP and H.323 telephones
- Call coverage and call forwarding for endpoints at the enterprise site

- Transmission and response of SIP OPTIONS messages sent by Cable and Wireless requiring Avaya response and sent by Avaya requiring Cable and Wireless response

## 2.2. Test Results

Interoperability testing of the sample configuration was completed with successful results for the Cable and Wireless SIP IP Trunking service with the following observations:

- No inbound toll free numbers were tested as none were available from the Service Provider
- No Emergency Services numbers were tested as test calls to these numbers should be pre-arranged with the Operator
- T.38 fax is not supported
- Network Call Redirect using SIP 302 Moved Temporarily is not supported
- User to User Information using the Contact header in a SIP 302 "Moved Temporarily" message is not supported
- The Avaya SBCE delayed the sending of the 180 Ringing which triggered the re-transmission of the 180 Ringing from the CM. The Network responded with PRACK to both and waited for 200 OK to each PRACK, when only one was sent the call failed. The solution was to eliminate the delay on the Avaya SBCE, but this is a potential issue where network delays occur.
- Unsupported codecs in the INVITE SDP from the CM caused failures even when supported codecs were available
- International CLI was not delivered to the enterprise equipment, possible restriction in UK networks


## 2.3. Support

For technical support on Cable and Wireless products please use the following web link.

<http://www.cw.com/contact-us/>.

### 3. Reference Configuration

**Figure 1** illustrates the test configuration. The test configuration shows an Enterprise site connected to the Cable and Wireless SIP IP Trunking service. Located at the Enterprise site is an Avaya SBCE, Session Manager and Communication Manager. Endpoints are Avaya 96x0 series and Avaya 96x1 series IP telephones (with SIP and H.323 firmware), Avaya 46xx series IP telephones (with H.323 firmware), Avaya 16xx series IP telephones (with SIP firmware) Avaya A175 Desktop Video Device running Flare Experience, Avaya analogue telephones and an analogue fax machine. Also included in the test configuration was an Avaya one-X® Communicator soft phone running on a laptop PC configured for H.323.



**Figure 1: Test Set-up Cable and Wireless SIP IP Trunking to Avaya Enterprise**

## 4. Equipment and Software Validated

The following equipment and software were used for the sample configuration provided:

Equipment/Software	Release/Version
<b>Avaya</b>	
Avaya Aura® Communication Manager running on Avaya S8800 Server	R6.2 Build R016x.02.0.823.0
Avaya G430 Media Gateway	FW 30.12.1
Avaya Aura® Session Manager running on Avaya S8800 Server	R6.2 Build 6.2.0.0.620110
Avaya Aura® System Manager running on Avaya S8800 Server	R6.2 (System Platform 6.2.0.0.27, Template 6.2.12.0)
Avaya Session Border Controller For Enterprise running on Dell R210 V2 server	4.0.5.Q09
Avaya 1616 Phone (H.323)	1.301
Avaya 4621 Phone (H.323)	2.902
Avaya 9630 Phone (H.323)	3.103
Avaya A175 Desktop Video Device (SIP)	Flare Experience Release 1.1
Avaya 9630 Phone (SIP)	R2.6 SP6
Avaya one-X® Communicator (H.323) on Lenovo T510 Laptop PC	6.1.3.08-SP3-Patch2-35791
Analogue Phone	N/A
<b>Cable and Wireless</b>	
ACME Packet Net-Net 9200 SBC	SD7.0.0 MR-11 GA (Build 864)
Genband C20 Soft-Switch	CVM13 (12.0.12)

**Note:** At the time of test, Communication Manager R6.2 was in the Control Introduction phase prior to being made GA.

## 5. Configure Avaya Aura ® Communication Manager

This section describes the steps for configuring Communication Manager for SIP Trunking. SIP trunks are established between Communication Manager and Session Manager. These SIP trunks will carry SIP Signalling associated with the Cable and Wireless SIP IP Trunking service. For incoming calls, the Session Manager receives SIP messages from the Avaya Session Border Controller for Enterprise (Avaya SBCE) and directs the incoming SIP messages to Communication Manager. Once the message arrives at Communication Manager, further incoming call treatment, such as incoming digit translations and class of service restrictions may be performed. All outgoing calls to the PSTN are processed within Communication Manager and may be first subject to outbound features such as automatic route selection, digit manipulation and class of service restrictions. Once Communication Manager selects a SIP trunk, the SIP signalling is routed to the Session Manager. The Session Manager directs the outbound SIP messages to the Avaya SBCE at the enterprise site that then sends the SIP messages to the Cable and Wireless network. Communication Manager Configuration was performed using the System Access Terminal (SAT). Some screens in this section have been abridged and highlighted for brevity and clarity in presentation. The general installation of the Avaya S8800 Servers and Avaya G430 Media Gateway is presumed to have been previously completed and is not discussed here.

### 5.1. Confirm System Features

The license file installed on the system controls the maximum values for these attributes. If a required feature is not enabled or there is insufficient capacity, contact an authorized Avaya sales representative to add additional capacity. Use the **display system-parameters customer-options** command and on **Page 2**, verify that the **Maximum Administered SIP Trunks** supported by the system is sufficient for the combination of trunks to the Cable and Wireless network, and any other SIP trunks used.

display system-parameters customer-options		Page	2 of 11
OPTIONAL FEATURES			
IP PORT CAPACITIES	USED		
Maximum Administered H.323 Trunks:	12000	0	
Maximum Concurrently Registered IP Stations:	18000	3	
Maximum Administered Remote Office Trunks:	12000	0	
Maximum Concurrently Registered Remote Office Stations:	18000	0	
Maximum Concurrently Registered IP eCons:	414	0	
Max Concur Registered Unauthenticated H.323 Stations:	100	0	
Maximum Video Capable Stations:	18000	0	
Maximum Video Capable IP Softphones:	18000	0	
<b>Maximum Administered SIP Trunks:</b>	<b>24000</b>	<b>62</b>	
Maximum Administered Ad-hoc Video Conferencing Ports:	24000	0	
Maximum Number of DS1 Boards with Echo Cancellation:	522	0	
Maximum TN2501 VAL Boards:	128	0	
Maximum Media Gateway VAL Sources:	250	1	
Maximum TN2602 Boards with 80 VoIP Channels:	128	0	
Maximum TN2602 Boards with 320 VoIP Channels:	128	0	
Maximum Number of Expanded Meet-me Conference Ports:	300	0	

On **Page 4**, verify that the **IP Trunks** field is set to **y**.

display system-parameters customer-options		Page 4 of 11
OPTIONAL FEATURES		
Emergency Access to Attendant? y		IP Stations? y
Enable 'dadmin' Login? y		
Enhanced Conferencing? y		ISDN Feature Plus? n
Enhanced EC500? y	ISDN/SIP Network Call Redirection? y	
Enterprise Survivable Server? n		ISDN-BRI Trunks? y
Enterprise Wide Licensing? n		ISDN-PRI? y
ESS Administration? y	Local Survivable Processor? n	
Extended Cvg/Fwd Admin? y	Malicious Call Trace? y	
External Device Alarm Admin? y	Media Encryption Over IP? n	
Five Port Networks Max Per MCC? n	Mode Code for Centralized Voice Mail? n	
Flexible Billing? n		
Forced Entry of Account Codes? y	Multifrequency Signaling? y	
Global Call Classification? y	Multimedia Call Handling (Basic)? y	
Hospitality (Basic)? y	Multimedia Call Handling (Enhanced)? y	
Hospitality (G3V3 Enhancements)? y	Multimedia IP SIP Trunking? y	
IP Trunks? y		
IP Attendant Consoles? y		

## 5.2. Administer IP Node Names

The node names defined here will be used in other configuration screens to define a SIP signalling group between Communication Manager and Session Manager. In the **IP Node Names** form, assign the node **Name** and **IP Address** for the Session Manager. In this case, **SM100** and **10.10.7.61** are the **Name** and **IP Address** for the Session Manager SIP interface. Also note the **procr** name as this is the processor interface that Communication Manager will use as the SIP signalling interface to Session Manager.

display node-names ip		IP NODE NAMES
<b>Name</b>	<b>IP Address</b>	
BGSM	10.10.9.61	
IPOLan2	10.10.7.110	
MXBridge	10.10.2.164	
admin	10.10.7.100	
asmmax	10.10.6.30	
default	0.0.0.0	
<b>procr</b>	<b>10.10.7.52</b>	
procr6	::	
<b>sm100</b>	<b>10.10.7.61</b>	
smpub	86.47.122.50	

### 5.3. Administer IP Network Region

Use the **change ip-network-region 1** command to set the following values:

- The **Authoritative Domain** field is configured to match the domain name configured on Session Manager. In this configuration, the domain name is **avaya.com**.
- By default, **IP-IP Direct Audio** (both **Intra-** and **Inter-Region**) is enabled (**yes**) to allow audio traffic to be sent directly between endpoints without using gateway VoIP resources. When a PSTN call is shuffled, the media stream is established directly between the enterprise end-point and the internal media interface of the Avaya SBCE.
- The **Codec Set** is set to the number of the IP codec set to be used for calls within the IP network region. In this case, codec set **1** is used.

```
change ip-network-region 1                                     Page 1 of 20
                                                                IP NETWORK REGION
Region: 1
Location: 1           Authoritative Domain: avaya.com
Name: default
MEDIA PARAMETERS
    Codec Set: 1           Intra-region IP-IP Direct Audio: yes
                          Inter-region IP-IP Direct Audio: yes
                          IP Audio Hairpinning? n
    UDP Port Min: 10000
    UDP Port Max: 50001
DIFFSERV/TOS PARAMETERS
    Call Control PHB Value: 46
    Audio PHB Value: 46
    Video PHB Value: 26
802.1P/Q PARAMETERS
    Call Control 802.1p Priority: 6
    Audio 802.1p Priority: 6
    Video 802.1p Priority: 5
H.323 IP ENDPOINTS
    H.323 Link Bounce Recovery? y
    Idle Traffic Interval (sec): 20
    Keep-Alive Interval (sec): 5
    Keep-Alive Count: 5
                                                                AUDIO RESOURCE RESERVATION PARAMETERS
                                                                RSVP Enabled? n
```



## 5.4. Administer IP Codec Set

Open the **IP Codec Set** form for the codec set specified in the IP Network Region form, **Section 5.3**. Enter the list of audio codecs eligible to be used in order of preference. For the interoperability test the codecs supported by Cable and Wireless were configured, namely **G.729A**, and **G.711A**.

change ip-codec-set 1 Page 1 of 2

IP Codec Set

Codec Set: 1

	Audio Codec	Silence Suppression	Frames Per Pkt	Packet Size (ms)
1:	<b>G.729A</b>	<b>n</b>	<b>2</b>	<b>20</b>
2:	<b>G.711A</b>	<b>n</b>	<b>2</b>	<b>20</b>
3:				

The Cable and Wireless SIP IP Trunking service does not currently support T.38 for transmission of fax. Although not supported as a standard configuration by Avaya, G.711 pass-through was tested. To set G.711 pass-through, navigate to **Page 2** and configure by setting the **Fax Mode** to **pass-through** as shown below.

change ip-codec-set 1 Page 2 of 2

IP Codec Set

Allow Direct-IP Multimedia? n

	Mode	Redundancy
<b>FAX</b>	<b>pass-through</b>	<b>0</b>
Modem	off	0
TDD/TTY	US	3
Clear-channel	n	0

## 5.5. Administer SIP Signaling Groups

This signalling group (and trunk group) will be used for inbound and outbound PSTN calls to the Cable and Wireless SIP IP Trunking service. During test, this was configured to use **TCP** and port **5060** to facilitate tracing and fault analysis. It is recommended however, to use **TLS** (Transport Layer Security) and the default TLS port of **5061** for security. Configure the **Signaling Group** using the **add signaling-group x** command, where **x** is an available signalling group, as follows:

- Set **Group Type** to **sip**
- Set **Transport Method** to **tcp**
- Set **Peer Detection Enabled** to **y** allowing the Communication Manager to automatically detect if the peer server is a Session Manager
- Set **Near-end Node Name** to the processor interface (node name **procr** as defined in the **IP Node Names** form shown in **Section 5.2**)
- Set **Far-end Node Name** to the Session Manager (node name **SM100** as defined in the **IP Node Names** form shown in **Section 5.2**)
- Set **Near-end Listen Port** and **Far-end Listen Port** to **5060** (Commonly used TCP port value)
- Set **Far-end Network Region** to the IP Network Region configured in **Section 5.3**. (logically establishes the far-end for calls using this signalling group as network region **1**)
- Leave **Far-end Domain** blank (allows the CM to accept calls from any SIP domain on the associated trunk )
- Set **Direct IP-IP Audio Connections** to **y**
- Leave **DTMF over IP** at default value of **rtp-payload** (Enables **RFC2833** for DTMF transmission from the Communication Manager)

The default values for the other fields may be used.

change signaling-group 1		Page 1 of 2
SIGNALING GROUP		
Group Number: 1	Group Type: sip	
IMS Enabled? n	Transport Method: tcp	
Q-SIP? n		
IP Video? n	Enforce SIPS URI for SRTP? y	
Peer Detection Enabled? y	Peer Server: SM	
Near-end Node Name: procr	Far-end Node Name: sm100	
Near-end Listen Port: 5060	Far-end Listen Port: 5060	
	Far-end Network Region: 1	
Far-end Domain:		
Incoming Dialog Loopbacks: eliminate	Bypass If IP Threshold Exceeded? n	
DTMF over IP: rtp-payload	RFC 3389 Comfort Noise? n	
Session Establishment Timer(min): 3	Direct IP-IP Audio Connections? y	
Enable Layer 3 Test? y	IP Audio Hairpinning? n	
H.323 Station Outgoing Direct Media? n	Initial IP-IP Direct Media? n	
	Alternate Route Timer(sec): 6	

## 5.6. Administer SIP Trunk Group

A trunk group is associated with the signaling group described in **Section 5.5**. Configure the trunk group using the **add trunk-group x** command, where **x** is an available trunk group. On **Page 1** of this form:

- Set the **Group Type** field to **sip**
- Choose a descriptive **Group Name**
- Specify a trunk access code (**TAC**) consistent with the dial plan
- The **Direction** is set to **two-way** to allow incoming and outgoing calls
- Set the **Service Type** field to **public-ntwrk** – required setting when using the Diversion header
- Specify the signalling group associated with this trunk group in the **Signaling Group** field as previously configured in **Section 5.5**
- Specify the **Number of Members** supported by this SIP trunk group

add trunk-group 1		Page 1 of 21	
TRUNK GROUP			
Group Number: 1	Group Type: sip	CDR Reports: y	
Group Name: to SM100	COR: 1	TN: 1	TAC: 101
Direction: two-way	Outgoing Display? y		
Dial Access? n	Night Service:		
Queue Length: 0			
Service Type: public-ntwrk	Auth Code? n		
		Member Assignment Method: auto	
		Signaling Group: 1	
		Number of Members: 10	

On **Page 2** of the trunk-group form, the **Preferred Minimum Session Refresh Interval (sec)** field should be set to a value mutually agreed upon with Cable and Wireless to prevent unnecessary SIP messages during call setup.

Add trunk-group 1		Page 2 of 21	
Group Type: sip			
TRUNK PARAMETERS			
Unicode Name: auto			
		Redirect On OPTIM Failure: 5000	
SCCAN? n	Digital Loss Group: 18		
		Preferred Minimum Session Refresh Interval(sec): 1800	
Disconnect Supervision - In? y Out? y			

On **Page 3**, set the **Numbering Format** field to **public**. This allows delivery of CLI in E.164 format with a leading “+”.

add trunk-group 1		Page 3 of 21
TRUNK FEATURES		
ACA Assignment? n	Measured: none	Maintenance Tests? y
Numbering Format: public		
UII Treatment: service-provider		
Replace Restricted Numbers? n		
Replace Unavailable Numbers? n		

On **Page 4** of this form:

- Set **Send Diversion Header** to **y** to include the header in forwarded and transferred calls. This is not currently used by Cable and Wireless but is included as it was set for test.
- Set **Support Request History** to **n** as Cable and Wireless does not use History Info making it an unnecessary extension to the SIP INVITE
- Set the **Telephone Event Payload Type** to **101** to match the value preferred by Cable and Wireless
- Set **Always Use re-INVITE for Display Updates** to **y** as the most effective method employed by the CM of modifying an existing dialogue

add trunk-group 1		Page 4 of 21
PROTOCOL VARIATIONS		
Mark Users as Phone? n		
Prepend '+' to Calling Number? n		
Send Transferring Party Information? n		
Network Call Redirection? y		
Send Diversion Header? y		
Support Request History? n		
Telephone Event Payload Type: 101		
Convert 180 to 183 for Early Media? n		
Always Use re-INVITE for Display Updates? y		
Identity for Calling Party Display: P-Asserted-Identity		
Enable Q-SIP? n		

**Note: Network Call Redirection** was only set to **y** for NCR testing. It was set to default value **n** for all other tests.

## 5.7. Administer Calling Party Number Information

Use the **change private-unknown-numbering** command to configure Communication Manager to send the calling party number. In the test configuration, individual stations were mapped to send numbers allocated from the Cable and Wireless DDI range supplied. This calling party number is sent in the SIP From, Contact and PAI headers, and displayed on display-equipped PSTN telephones. Note that the digits identifying the DDI range are not shown.

change public-unknown-numbering 0					Page 1 of 2
NUMBERING - PUBLIC/UNKNOWN FORMAT					
Ext	Ext	Trk	CPN	Total	
Len	Code	Grp(s)	Prefix	CPN	
				Len	
4	1305	1	441491xxxxx3	12	Total Administered: 8
4	1306	1	441491xxxxx8	12	Maximum Entries: 9999
4	1308	1	441491xxxxx6	12	Note: If an entry applies to a SIP connection to Avaya Aura(R) Session Manager, the resulting number must be a complete E.164 number.
4	1601	1	441491xxxxx1	12	
4	1602	1	441491xxxxx2	12	
4	1605	1	441491xxxxx6	12	
4	1651	1	441491xxxxx5	12	
4	1670	1	441491xxxxx4	12	

## 5.8. Administer Route Selection for Outbound Calls

In the test environment, the Automatic Route Selection (ARS) feature was used to route outbound calls via the SIP trunk to the Cable and Wireless SIP IP Trunking service. The single digit **9** was used as the ARS access code providing a facility for telephone users to dial 9 to reach an outside line. Use the **change feature-access-codes** command to configure a digit as the **Auto Route Selection (ARS) - Access Code 1**.

change feature-access-codes		Page 1 of 10
FEATURE ACCESS CODE (FAC)		
Abbreviated Dialing List1 Access Code:		
Abbreviated Dialing List2 Access Code:		
Abbreviated Dialing List3 Access Code:		
Abbreviated Dial - Prgm Group List Access Code:		
Announcement Access Code: *60		
Answer Back Access Code:		
Attendant Access Code:		
Auto Alternate Routing (AAR) Access Code: 5		
<b>Auto Route Selection (ARS) - Access Code 1: 9</b>		Access Code 2:

Use the **change ars analysis** command to configure the routing of dialled digits following the first digit 9. A small sample of dial patterns are shown here as an example. Further administration of ARS is beyond the scope of this document. The example entries shown will match outgoing calls to numbers beginning 0 or 00. Note that exact maximum number lengths should be used where possible to reduce post-dial delay. Calls are sent to **Route Pattern 1**.

change ars analysis 0							Page 1 of 2
ARS DIGIT ANALYSIS TABLE							
Location: all							Percent Full: 0
	Dialed String	Total Min	Total Max	Route Pattern	Call Type	Node Num	ANI Reqd
	0	9	11	1	pubu		n
	00	12	14	1	pubu		n
	003538	14	14	1	pubu		n
	0035391	13	13	1	pubu		n
	0800	10	10	1	pubu		n
	118	5	6	1	pubu		n

Use the **change route-pattern x** command, where **x** is an available route pattern, to add the SIP trunk group to the route pattern that ARS selects. In this configuration, route pattern **1** is used to route calls to trunk group **1**. Numbering Plan Indicator (NPI) of the Calling Party Number is set to private and Type of Numbering (TON) is set to local by using **Numbering Format** of **lev0-pvt**. If E.164 and international are required, set this field to **intl-pub**

change route-pattern 1														Page 1 of 3							
Pattern Number: 1    Pattern Name: all calls																					
SCCAN? n    Secure SIP? n																					
Grp	FRL	NPA	Pfx	Hop	Toll	No.	Inserted							DCS/	IXC						
No			Mrk	Lmt	List	Del	Digits							QSIG							
							Dgts							Intw							
1:	1	0												n	user						
2:														n	user						
3:														n	user						
4:														n	user						
5:														n	user						
6:														n	user						
BCC VALUE    TSC    CA-TSC    ITC BCIE Service/Feature PARM    No. Numbering LAR																					
0 1 2 M 4 W    Request														Dgts Format							
														Subaddress							
1:	y	y	y	y	y	n	n	rest						lev0-pvt	none						
2:	y	y	y	y	y	n	n	rest							none						
3:	y	y	y	y	y	n	n	rest							none						
4:	y	y	y	y	y	n	n	rest							none						
5:	y	y	y	y	y	n	n	rest							none						
6:	y	y	y	y	y	n	n	rest							none						

## 5.9. Administer Incoming Digit Translation

This step configures the settings necessary to map incoming DDI calls to the proper Communication Manager extension(s). The incoming digits sent in the INVITE message from Cable and Wireless can be manipulated as necessary to route calls to the desired extension. In the example, the incoming DDI numbers provided by Cable and Wireless for testing are assigned to the internal extensions of the test equipment configured within the Communication Manager. The **change inc-call-handling-trmt trunk-group 1** command is used to translate numbers **1491xxxxx5** to **1491xxxxx9** to the 4 digit extension by deleting **all** of the incoming digits and inserting the extension number. Note that the significant digits beyond the city code have been obscured.

change inc-call-handling-trmt trunk-group 1					Page	1 of	30
INCOMING CALL HANDLING TREATMENT							
Service/ Feature	Number Len	Number Digits	Del	Insert			
public-ntwrk	10	1491xxxxx1	all	1601			
public-ntwrk	10	1491xxxxx2	all	1602			
public-ntwrk	10	1491xxxxx3	all	1305			
public-ntwrk	10	1491xxxxx4	all	1670			
public-ntwrk	10	1491xxxxx5	all	1651			
public-ntwrk	10	1491xxxxx6	all	1308			
public-ntwrk	10	1491xxxxx7	all	1605			
public-ntwrk	10	1491xxxxx8	all	1306			
public-ntwrk	10	1491xxxxx9	all	1671			

## 5.10. EC500 Configuration

When EC500 is enabled on the Communication Manager station, a call to that station will generate a new outbound call from Communication Manager to the configured EC500 destination, typically a mobile phone. The following screen shows an example EC500 configuration for the user with station extension 1601. Use the command **change off-pbx-telephone station mapping x** where **x** is the Communication Manager station.

- The **Station Extension** field will automatically populate with station extension
- For **Application** enter **EC500**
- Enter a **Dial Prefix** (e.g., 9) if required by the routing configuration
- For the **Phone Number** enter the phone that will also be called (e.g. **0035386xxxxxxx**)
- Set the **Trunk Selection** to **1** so that Trunk Group 1 will be used for routing
- Set the **Config Set** to **1**

change off-pbx-telephone station-mapping 1601							Page 1 of 3
STATIONS WITH OFF-PBX TELEPHONE INTEGRATION							
Station Extension	Application	Dial Prefix	CC	Phone Number	Trunk Selection	Config Set	Dual Mode
1601	EC500	-	-	0035386xxxxxxx	1	1	

Save Communication Manager changes by entering **save translation** to make them permanent.

## 6. Configuring Avaya Aura® Session Manager

This section provides the procedures for configuring Session Manager. The Session Manager is configured via the System Manager. The procedures include the following areas:

- Log in to Avaya Aura® System Manager
- Administer SIP domain
- Administer Locations
- Administer Adaptations
- Administer SIP Entities
- Administer Entity Links
- Administer Routing Policies
- Administer Dial Patterns
- Administer Application for Avaya Aura® Communication Manager
- Administer Application Sequence for Avaya Aura® Communication Manager
- Administer SIP Extensions

### 6.1. Log in to Avaya Aura® System Manager

Access the System Manager using a Web Browser by entering **http://<FQDN>/SMGR**, where <FQDN> is the fully qualified domain name of System Manager. Log in using appropriate credentials (not shown) and the Home tab will be presented with menu options shown below.

**AVAYA** Avaya Aura® System Manager 6.2 Last Logged on at May 24, 2012 10:59 AM  
[Help](#) | [About](#) | [Change Password](#) | [Log off admin](#)

Users	Elements	Services
<b>Administrators</b> Manage Administrative Users	<b>B5800 Branch Gateway</b> Manage B5800 Branch Gateway 6.2 elements	<b>Backup and Restore</b> Backup and restore System Manager database
<b>Directory Synchronization</b> Synchronize users with the enterprise directory	<b>Communication Manager</b> Manage Communication Manager 5.2 and higher elements	<b>Bulk Import and Export</b> Manage Bulk Import and Export of Users, User Global Settings, Roles, Elements and others
<b>Groups &amp; Roles</b> Manage groups, roles and assign roles to users	<b>Conferencing</b> Manage Conferencing Multimedia Server objects	<b>Configurations</b> Manage system wide configurations
<b>UCM Roles</b> Manage UCM Roles, assign roles to users	<b>Inventory</b> Manage, discover, and navigate to elements, update element software	<b>Events</b> Manage alarms, view and harvest logs
<b>User Management</b> Manage users, shared user resources and provision users	<b>Meeting Exchange</b> Manage Meeting Exchange and Avaya Aura Conferencing 6.0 elements	<b>Licenses</b> View and configure licenses
	<b>Messaging</b> Manage Avaya Aura Messaging, Communication Manager Messaging, and Modular Messaging	<b>Replication</b> Track data replication nodes, repair replication nodes
	<b>Presence</b> Presence	<b>Scheduler</b> Schedule, track, cancel, update and delete jobs
	<b>Routing</b> Network Routing Policy	<b>Security</b> Manage Security Certificates
	<b>Session Manager</b> Session Manager Element Manager	<b>Templates</b> Manage Templates for Communication Manager, Messaging System and B5800 Branch Gateway elements



## 6.2. Administer SIP Domain

To add the SIP domain that will be used with Session Manager, select **Routing** from the **Home** tab menu and in the resulting tab select **Domains** from left hand menu. Click the **New** button to create a new SIP domain entry. In the **Name** field enter the domain name (e.g., **avaya.com**) and optionally a description for the domain in the **Notes** field. Click **Commit** to save changes.



Avaya Aura® System Manager 6.2

Last Logged on at May 24, 2012 10:59 AM  
Help | About | Change Password | Log off admin

Routing x Home

Routing

Domains

Locations

Adaptations

SIP Entities

Entity Links

Time Ranges

Routing Policies

Dial Patterns

Regular Expressions

Defaults

Home / Elements / Routing / Domains

Domain Management

Help ?

Edit New Duplicate Delete More Actions

1 Item Refresh Filter: Enable

<input type="checkbox"/>	Name	Type	Default	Notes
<input type="checkbox"/>	avaya.com	sip	<input type="checkbox"/>	

Select : All, None

## 6.3. Administer Locations

Locations can be used to identify logical and/or physical locations where SIP Entities reside, for the purposes of bandwidth management. One location is added to the sample configuration for all of the enterprise SIP entities. On the **Routing** tab select **Locations** from the left hand menu. Under **General**, in the **Name** field, enter an informative name for the location. Scroll to the bottom of the page and under **Location Pattern**, click **Add**, then enter an **IP Address Pattern** in the resulting new row, \* is used to specify any number of allowed characters at the end of the string. Below is the location configuration used for the test enterprise.

Home / Elements / Routing / Locations

Location Details

CommitCancelHelp ?

Call Admission Control has been set to ignore SDP. All calls will be counted using the Default Audio Bandwidth. Note: If this setting is disabled, you should return to this form to review settings for multimedia bandwidth.  
See Session Manager -> Session Manager Administration -> Global Settings

General

\* Name:SIPLab7

Notes:

Overall Managed Bandwidth

Managed Bandwidth Units:Kbit/sec

Total Bandwidth:

Per-Call Bandwidth Parameters

\* Default Audio Bandwidth:80Kbit/sec

Alarm Threshold

Audio Alarm Threshold:80%

\* Latency before Audio Alarm Trigger:5Minutes

Location Pattern

AddRemove

3 Items RefreshFilter: Enable

<input type="checkbox"/>	IP Address Pattern	Notes
<input type="checkbox"/>	* 10.10.7.*	
<input type="checkbox"/>	* 10.10.2.*	
<input type="checkbox"/>	* 10.10.8.*	

Select : All, None

## 6.4. Administer Adaptations

Adaptations can be used to modify the called and calling party numbers to meet the requirements of the service. The called party number present in the SIP INVITE Request URI is modified by the **Digit Conversion** in the Adaptation. Additionally, the called and calling party numbers can also be modified using **Digit Conversion** when **fromto=true** is entered in the **Module Parameters**. The example shown was used in test to prefix the called party number with a **9** which is a requirement of Cable and Wireless. The module **DigitConversionAdaptor** is used and terminating numbers starting with a **0** for national and international calls and **1** for Operator and Directory Enquiries are analysed and the **9** inserted.

These rules are applied to both the origination and the destination addresses.

Home / Elements / Routing / Adaptations

Adaptation Details

CommitCancelHelp ?

General

\* Adaptation name: Add 9

Module name: DigitConversionAdapter

Module parameter: fromto=true

Egress URI Parameters:

Notes:

Digit Conversion for Incoming Calls to SM

AddRemove

0 Items RefreshFilter: Enable

	Matching Pattern	Min	Max	Phone Context	Delete Digits	Insert Digits	Address to modify	Adaptation Data	Notes
--	------------------	-----	-----	---------------	---------------	---------------	-------------------	-----------------	-------

Digit Conversion for Outgoing Calls from SM

AddRemove

2 Items RefreshFilter: Enable

	Matching Pattern	Min	Max	Phone Context	Delete Digits	Insert Digits	Address to modify	Adaptation Data	Notes
<input type="checkbox"/>	* 0	* 1	* 36		* 0	9	both		
<input type="checkbox"/>	* 1	* 3	* 6		* 0	9	both		

## 6.5. Administer SIP Entities

A SIP Entity must be added for each SIP-based telephony system supported by a SIP connection to the Session Manager. To add a SIP Entity, select **SIP Entities** on the left panel menu and then click on the **New** button (not shown). The following will need to be entered for each SIP Entity.

Under **General**:

- In the **Name** field enter an informative name
- In the **FQDN or IP Address** field enter the IP address of Session Manager or the signalling interface on the connecting system
- In the **Type** field use **Session Manager** for a Session Manager SIP entity, **CM** for a Communication Manager SIP entity and **Gateway** for the Session Border Controller SIP entity
- In the **Location** field select the appropriate location from the drop down menu
- In the **Time Zone** field enter the time zone for the SIP Entity

In this configuration there are three SIP Entities:

- Avaya Aura® Session Manager SIP Entity
- Avaya Aura® Communication Manager SIP Entity
- Avaya Session Border Controller for Enterprise SIP Entity

### 6.5.1. Avaya Aura® Session Manager SIP Entity

The following screens show the SIP entity for Session Manager. The **FQDN or IP Address** field is set to the IP address of the Session Manager SIP signalling interface. The Session Manager must be configured with the port numbers on the protocols that will be used by the other SIP entities. To configure these, scroll to the bottom of the page and under **Port**, click **Add**, then edit the fields in the resulting new row.

- In the **Port** field enter the port number on which the system listens for SIP requests
- In the **Protocol** field enter the transport protocol to be used for SIP requests
- In the **Default Domain** field, from the drop down menu select **avaya.com** as the default domain

Home / Elements / Routing / SIP Entities

SIP Entity Details Help ? Commit Cancel

**General**

\* Name: ASMDot7

\* FQDN or IP Address: 10.10.7.61

Type: Session Manager

Notes:

Location: SIPLab7

Outbound Proxy:

Time Zone: Etc/GMT

Credential name:

**SIP Link Monitoring**

SIP Link Monitoring: Use Session Manager Configuration

**Entity Links** Add Remove

2 Items Refresh Filter: Enable

	SIP Entity 1	Protocol	Port	SIP Entity 2	Port	Connection Policy
<input type="checkbox"/>	ASMDot7	TCP	* 5060	ASBCAE	* 5060	Trusted
<input type="checkbox"/>	ASMDot7	TCP	* 5060	CMEVO	* 5060	Trusted

Select : All, None

**Port**

TCP Failover port:

TLS Failover port:

Add Remove

3 Items Refresh Filter: Enable

	Port	Protocol	Default Domain	Notes
<input type="checkbox"/>	5060	TCP	avaya.com	
<input type="checkbox"/>	5060	UDP	avaya.com	
<input type="checkbox"/>	5061	TLS	avaya.com	

### 6.5.2. Avaya Aura® Communication Manager SIP Entity

The following screen shows the SIP entity for Communication Manager which is configured as an Evolution Server. The **FQDN or IP Address** field is set to the IP address of the interface on Communication Manager that will be providing SIP signalling.

Home / Elements / Routing / SIP Entities

SIP Entity Details

Help ?

Commit Cancel

General

\* Name: CMEVO

\* FQDN or IP Address: 10.10.7.52

Type: CM

Notes:

Adaptation:

Location: SIPLab7

Time Zone: Etc/GMT

Override Port & Transport with DNS SRV: ☐

\* SIP Timer B/F (in seconds): 4

Credential name:

Call Detail Recording: none

SIP Link Monitoring

SIP Link Monitoring: Use Session Manager Configuration

### 6.5.3. Avaya Session Border Controller for Enterprise SIP Entity

The following screen shows the SIP Entity for the Session Border Controller. The **FQDN or IP Address** field is set to the IP address of the Session Border Controller private network interface.

Home / Elements / Routing / SIP Entities

SIP Entity Details

Help ?

Commit Cancel

General

\* Name: ASBCAE

\* FQDN or IP Address: 10.10.7.180

Type: Gateway

Notes:

Adaptation: Add 9

Location: SIPLab7

Time Zone: Etc/GMT

Override Port & Transport with DNS SRV: ☐

\* SIP Timer B/F (in seconds): 4

Credential name:

Call Detail Recording: none

SIP Link Monitoring

SIP Link Monitoring: Use Session Manager Configuration

## 6.6. Administer Entity Links

A SIP trunk between a Session Manager and another system is described by an Entity Link. To add an Entity Link, select **Entity Links** on the left panel menu and click on the **New** button (not shown). Fill in the following fields in the new row that is displayed.

- In the **Name** field enter an informative name
- In the **SIP Entity 1** field select the name given to the Session Manager Entity, in this case **ASMdot7**
- In the **Port** field enter the port number to which the other system sends its SIP requests
- In the **SIP Entity 2** field enter the other SIP Entity for this link, created in **Section 6.5**
- In the **Port** field enter the port number to which the other system expects to receive SIP requests
- In the **Connection Policy** field enter **Trusted** to make the other system trusted
- In the **Protocol** field enter the transport protocol to be used to send SIP requests

Click **Commit** to save changes. The following screen shows the Entity Links used in this configuration.

Home / Elements / Routing / Entity Links

Entity Links Help ?

Edit New Duplicate Delete More Actions ▾

2 Items Refresh Filter: Enable

<input type="checkbox"/>	Name	SIP Entity 1	Protocol	Port	SIP Entity 2	Port	Connection Policy	Notes
<input type="checkbox"/>	toASBCAE	ASMdot7	TCP	5060	ASBCAE	5060	Trusted	
<input type="checkbox"/>	toCM	ASMdot7	TCP	5060	CMEVO	5060	Trusted	

Select : All, None

## 6.7. Administer Routing Policies

Routing policies must be created to direct how calls will be routed to a system. To add a routing policy, select **Routing Policies** on the left panel menu and then click on the **New** button (not shown).

Under **General**:

- Enter an informative name in the **Name** field
- Under **SIP Entity as Destination**, click **Select**, and then select the appropriate SIP entity to which this routing policy applies
- Under **Time of Day**, click **Add**, and then select the time range

The following screen shows the routing policy for Communication Manager.

Home / Elements / Routing / Routing Policies

Routing Policy Details Help ?

Commit Cancel

**General**

\* Name:

Disabled: ☐

\* Retries:

Notes:

**SIP Entity as Destination**

Select

Name	FQDN or IP Address	Type	Notes
CMEVO	10.10.7.52	CM	

**Time of Day**

Add Remove View Gaps/Overlaps

1 Item | Refresh Filter: Enable

<input type="checkbox"/>	Ranking	1 ▲	Name	2 ▲	Mon	Tue	Wed	Thu	Fri	Sat	Sun	Start Time	End Time	Notes
<input type="checkbox"/>	0		24/7		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	00:00	23:59	Time Range 24/7

Select : All, None



The following screen shows the routing policy for the Session Border Controller.

Home / Elements / Routing / Routing Policies

Routing Policy Details Help ? Commit Cancel

**General**

\* Name:

Disabled: ☐

\* Retries:

Notes:

**SIP Entity as Destination**

Select

Name	FQDN or IP Address	Type	Notes
ASBCAE	10.10.7.180	Gateway	

**Time of Day**

Add Remove View Gaps/Overlaps

1 Item | Refresh Filter: Enable

<input type="checkbox"/>	Ranking	Name	Mon	Tue	Wed	Thu	Fri	Sat	Sun	Start Time	End Time	Notes
<input type="checkbox"/>	0	24/7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	00:00	23:59	Time Range 24/7

Select : All, None

## 6.8. Administer Dial Patterns

A dial pattern must be defined to direct calls to the appropriate telephony system. To configure a dial pattern select **Dial Patterns** on the left panel menu and then click on the **New** button (not shown).

Under **General**:

- In the **Pattern** field enter a dialled number or prefix to be matched
- In the **Min** field enter the minimum length of the dialled number
- In the **Max** field enter the maximum length of the dialled number
- In the **SIP Domain** field select **ALL** or alternatively one of those configured in **Section 6.2**

Under **Originating Locations and Routing Policies**, click **Add**. In the resulting screen (not shown), under **Originating Location** select **ALL** and under **Routing Policies** select one of the routing policies defined in **Section 6.6**. Click the **Select** button to save. The following screen shows an example dial pattern configured for the Avaya SBCE which will route the calls out to the Cable and Wireless SIP IP Trunking service.

Home / Elements / Routing / Dial Patterns

Dial Pattern Details Help ? Commit Cancel

**General**

\* Pattern: 0

\* Min: 9

\* Max: 11

Emergency Call: ☐

Emergency Priority: 1

Emergency Type:

SIP Domain: -ALL-

Notes:

**Originating Locations and Routing Policies**

Add Remove

1 Item | Refresh Filter: Enable

<input type="checkbox"/>	Originating Location Name <small>1 ▲</small>	Originating Location Notes	Routing Policy Name	Rank <small>2 ▲</small>	Routing Policy Disabled	Routing Policy Destination	Routing Policy Notes
<input type="checkbox"/>	-ALL-	Any Locations	to_ASBCAE	0	<input type="checkbox"/>	ASBCAE	

Select : All, None

The following screen shows the test dial pattern configured for Communication Manager. Note that the number format received from Cable and Wireless was national with no leading 0.

Home / Elements / Routing / Dial Patterns

Dial Pattern Details Help ?

Commit Cancel

General

\* Pattern: 1491

\* Min: 10

\* Max: 10

Emergency Call: ☐

Emergency Priority: 1

Emergency Type:

SIP Domain: -ALL-

Notes:

Originating Locations and Routing Policies

Add Remove

1 Item | Refresh Filter: Enable

<input type="checkbox"/>	Originating Location Name <small>1 ▲</small>	Originating Location Notes	Routing Policy Name	Rank <small>2 ▲</small>	Routing Policy Disabled	Routing Policy Destination	Routing Policy Notes
<input type="checkbox"/>	-ALL-	Any Locations	toCMEvo	0	<input type="checkbox"/>	CMEVO	

Select : All, None

## 6.9. Administer Application for Avaya Aura® Communication Manager

From the Home tab select **Session Manager** from the menu. In the resulting tab from the left panel menu select **Application Configuration → Applications** and click **New**.

- In the **Name** field enter a name for the application
- In the **SIP Entity** field select the SIP entity for the Communication Manager
- In the **CM System for SIP Entity** field select the SIP entity for the Communication Manager

Select **Commit** to save the configuration.

Home / Elements / Session Manager / Application Configuration / Applications Help ?

### Application Editor

Commit Cancel

Application

\*Name

\*SIP Entity

\*CM System for SIP Entity  Refresh [View/Add CM Systems](#)

Description

**Application Attributes (optional)**

Name	Value
Application Handle	<input type="text"/>
URI Parameters	<input type="text"/>

**Application Media Attributes**

Enable Media Filtering ☐

Audio	Video	Text	Match Type	If SDP Missing
<input type="text" value="YES"/>	<input type="text" value="YES"/>	<input type="text" value="YES"/>	<input type="text" value="NOT EXACT"/>	<input type="text" value="ALLOW"/>

## 6.10. Administer Application Sequence for Avaya Aura® Communication Manager

From the left panel, navigate to **Session Manager** → **Application Configuration** → **Application Sequences** and click on **New**.

- In the **Name** field enter a descriptive name
- Under **Available Applications**, click the + sign in front of the appropriate application instance. When the screen refreshes, the application should be displayed under the **Applications in this Sequence** heading.

Select **Commit**.

Home / Elements / Session Manager / Application Configuration / Application Sequences Help ?

### Application Sequence Editor

Commit Cancel

Application Sequence

\*Name

Description

Applications in this Sequence

Move First Move Last Remove

1 Item

<input type="checkbox"/>	Sequence Order (first to last)	Name	SIP Entity	Mandatory	Description
<input type="checkbox"/>	▲ ▼ ✕	<a href="#">cmapp</a>	CMEVO	<input checked="" type="checkbox"/>	

Select : All, None

Available Applications

1 Item Refresh Filter: Enable

Name	SIP Entity	Description
+ <a href="#">cmapp</a>	CMEVO	

## 6.11. Administer SIP Extensions

SIP extensions are registered with the Session Manager and use Communication Manager for their feature and configuration settings. From the Home tab, select **User Management** from the menu. Then select **Manage Users** and click **New** (not shown).

On the **Identity** tab:

- Enter the user's name in the **Last Name** and **First Name** fields
- In the **Login Name** field enter a unique system login name in the form of **user@domain** (e.g. **1308@avaya.com**) which is used to create the user's primary handle
- The **Authentication Type** should be **Basic**
- In the **Password/Confirm Password** fields enter an alphanumeric password

The screenshot shows the 'New User Profile' form in the 'Identity' tab. The form is titled 'New User Profile' and has a 'Help ?' link. It contains several input fields and a 'Commit & Continue' button. The 'Identity' tab is selected, and the 'Login Name' field is highlighted with a red box. The 'Authentication Type' is set to 'Basic'. The 'Password' and 'Confirm Password' fields are also highlighted with a red box. The 'Time Zone' is set to '(+1:0)GMT : Dublin, Edinburgh, Lisbon, London, Casablanca'.

Home / Users / User Management / Manage Users

Help ?

**New User Profile** Commit & Continue Commit Cancel

Identity \* Communication Profile \* Membership Contacts

Identity

\* Last Name: Handset

\* First Name: Flare

Middle Name:

Description:

\* Login Name: 1308@avaya.com

\* Authentication Type: Basic

\* Password: .....

\* Confirm Password: .....

Localized Display Name:

Endpoint Display Name:

Title:

Language Preference:

Time Zone: (+1:0)GMT : Dublin, Edinburgh, Lisbon, London, Casablanca

On the **Communication Profile** tab, enter a numeric **Communication Profile Password** and confirm it, then expand the **Communication Address** section and click **New**. For the **Type** field select **Avaya SIP** from the drop-down menu. In the **Fully Qualified Address** field, enter an extension number and select the relevant domain from the drop-down menu. Click the **Add** button.

Identity \*
Communication Profile \*
Membership
Contacts

Communication Profile

Communication Profile Password: .....
Confirm Password: .....

New
Delete
Done
Cancel

Name
Primary

Select : None

\* Name: Primary
Default : ☒

Communication Address

New
Edit
Delete

Type	Handle	Domain
No Records found		

Type: Avaya SIP

\* Fully Qualified Address: 1308 @ avaya.com

Add
Cancel

Expand the **Session Manager Profile** section.

- Make sure the **Session Manager** check box is checked
- Select the appropriate Session Manager instance from the drop-down menu in the **Primary Session Manager** field
- Select the appropriate application sequence from the drop-down menu in the **Origination Application Sequence** field configured in **Section 6.9**
- Select the appropriate application sequence from the drop-down menu in the **Termination Application Sequence** field configured in **Section 6.9**
- Select the appropriate location from the drop-down menu in the **Home Location** field

☒ **Session Manager Profile** ▼

**\* Primary Session Manager**

ASMDot7 ▼

**Secondary Session Manager**

(None) ▼

**Origination Application Sequence**

app\_seq ▼

**Termination Application Sequence**

app\_seq ▼

**Conference Factory Set**

(None) ▼

**Survivability Server**

(None) ▼

**\* Home Location**

SIPLab7 ▼

Primary	Secondary	Maximum
4	0	4

Primary	Secondary	Maximum



Expand the **Endpoint Profile** section.

- Select the Communication Manager SIP Entity from the **System** drop-down menu
- Select **Endpoint** from the drop-down menu for **Profile Type**
- Enter the extension in the **Extension** field
- Select the desired template from the **Template** drop-down menu
- For the **Port** field select **IP**
- Select the **Delete Endpoint on Unassign of Endpoint from User or on Delete User** check box
- Select **Commit** to save changes and the System Manager will add the Communication Manager user configuration automatically

The screenshot shows the 'CM Endpoint Profile' configuration form. It includes fields for System (CM Instance), Profile Type (Endpoint), Extension (1308), Template (DEFAULT\_9630SIP\_CM\_6\_2), Set Type (9630SIP), Security Code, Port (IP), Voice Mail Number, Preferred Handle (None), and checkboxes for 'Delete Endpoint on Unassign of Endpoint from User or on Delete User' and 'Override Endpoint Name'. A red box highlights the 'Delete Endpoint on Unassign of Endpoint from User or on Delete User' checkbox, which is checked. Another red box highlights the 'System' and 'Profile Type' dropdowns. A third red box highlights the 'Extension' and 'Template' dropdowns. A fourth red box highlights the 'Port' dropdown. A fifth red box highlights the 'Set Type' field. A sixth red box highlights the 'Security Code' field. A seventh red box highlights the 'Voice Mail Number' field. An eighth red box highlights the 'Preferred Handle' dropdown. A ninth red box highlights the 'Override Endpoint Name' checkbox, which is checked. A tenth red box highlights the 'Endpoint Editor' button. A mouse cursor is visible over the 'Port' dropdown.

CM Endpoint Profile

\* System CM Instance

\* Profile Type Endpoint

Use Existing Endpoints ☐

\* Extension 1308 Endpoint Editor

\* Template DEFAULT\_9630SIP\_CM\_6\_2

Set Type 9630SIP

Security Code

\* Port IP

Voice Mail Number

Preferred Handle (None)

Delete Endpoint on Unassign of Endpoint from User or on Delete User. ☒

Override Endpoint Name ☒

## 7. Configure Avaya Session Border Controller for Enterprise


This section describes the configuration of the Session Border Controller for Enterprise. At the time of writing the Avaya Session Border Controller for Enterprise was badged as the Sipera E-SBC (Enterprise Session Border Controller) developed for Unified Communications Security (UC-Sec). The Avaya Session Border Controller for Enterprise is administered using the UC-Sec Control Center.

### 7.1. Access Avaya Session Border Controller for Enterprise

Access the Session Border Controller using a web browser by entering the URL **https://<ip-address>**, where **<ip-address>** is the private IP address configured at installation. Select the UC-Sec Control Center.



Log in with the appropriate credentials.



The UC-Sec™ family of products from Sipera Systems delivers comprehensive VoIP security by adapting the best practices of internet security and by using unique, sophisticated techniques such as VoIP protocol misuse & anomaly detection, behavioral learning based anomaly detection and voice spam detection to protect VoIP networks.

[Visit the Sipera Systems website to learn more.](#)

**NOTICE TO USERS:** This system is for authorized use only. Unauthorized use of this system is strictly prohibited. Unauthorized or improper use of this system may result in civil and/or criminal penalties. Use of this system constitutes consent to security monitoring. All activity is logged with login info, host name and IP address.

## 7.2. Define Network Information

Network information is required on the Avaya SBCE to allocate IP addresses and masks to the interfaces. Note that only the **A1** and **B1** interfaces are used, typically the **A1** interface is used for the internal side and **B1** is used for external. Each side of the Avaya SBCE can have only one interface assigned.

To define the network information, navigate to **Device Specific Settings → Network Management** in the **UC-Sec Control Center** menu on the left hand side and click on **Add IP**.

Enter details in the blank box that appears at the end of the list

- Define the internal IP address with screening mask and assign to interface **A1**
- Select **Save** (not shown) to save the information
- Click on **Add IP**
- Define the external IP address with screening mask and assign to interface **B1**
- Select **Save** (not shown) to save the information
- Click on **System Management** in the main menu
- Select **Restart Application** indicated by an icon in the status bar

Device Specific Settings > Network Management: GSSCP\_07

UC-Sec Devices  
GSSCP\_07

Network Configuration Interface Configuration

Modifications or deletions of an IP address or its associated data require an application restart before taking effect. Application restarts can be issued from System Management.

A1 Netmask: 255.255.255.0 A2 Netmask: B1 Netmask: 255.255.255.0 B2 Netmask:

Add IP Save Changes Clear Changes

IP Address	Public IP	Gateway	Interface	
10.10.7.180		10.10.7.1	A1	X
192.168.37.2		192.168.37.1	B1	X

Select the **Interface Configuration** tab and click on **Toggle State** to enable the interfaces.

Device Specific Settings > Network Management: GSSCP\_07

UC-Sec Devices  
GSSCP\_07

Network Configuration Interface Configuration

Name	Administrative Status	
A1	Enabled	Toggle State
A2	Disabled	Toggle State
B1	Enabled	Toggle State
B2	Disabled	Toggle State

## 7.3. Define Interfaces

When the IP addresses and masks are assigned to the interfaces, these are then configured as signalling and media interfaces.

### 7.3.1. Signalling Interfaces

To define the signalling interfaces on the Avaya SBCE, navigate to **Device Specific Settings** → **Signaling Interface** in the **UC-Sec Control Center** menu on the left hand side. Details of transport protocol and ports for the internal and external SIP signalling are entered here

- Select **Add Signaling Interface** and enter details in the pop-up menu
- In the **Name** field enter a descriptive name for the internal signalling interface
- For **Signaling IP**, select an **internal** signalling interface IP address defined in **Section 7.2**
- Select **UDP** and **TCP** port numbers, **5060** is used for Cable and Wireless
- Select **Add Signaling Interface** and enter details in the pop-up menu
- In the **Name** field enter a descriptive name for the external signalling interface
- For **Signaling IP**, select an **external** signalling interface IP address defined in **Section 7.2**
- Select **UDP** and **TCP** port numbers, **5060** is used for Cable and Wireless

Device Specific Settings > Signaling Interface: GSSCP_07						
UC-Sec Devices		Signaling Interface				
GSSCP_07		Add Signaling Interface				
Name	Signaling IP	TCP Port	UDP Port	TLS Port	TLS Profile	
Int_Sig	10.10.7.180	5060	5060	---	None	 
Ext_Sig	192.168.37.2	5060	5060	---	None	 

### 7.3.2. Media Interfaces

To define the media interfaces on the Avaya SBCE, navigate to **Device Specific Settings** → **Media Interface** in the **UC-Sec Control Center** menu on the left hand side. Details of the RTP and SRTP port ranges for the internal and external media streams are entered here. The IP addresses for media can be the same as those used for signalling.

- Select **Add Media Interface** and enter details in the pop-up menu
- In the **Name** field enter a descriptive name for the internal media interface
- For **Media IP**, select an **internal** media interface IP address defined in **Section 7.2**
- Select **RTP port** ranges for the media path with the enterprise end-points
- Select **Add Media Interface** and enter details in the pop-up menu
- In the **Name** field enter a descriptive name for the external media interface
- For **Media IP**, select an **external** media interface IP address defined in **Section 7.2**
- Select **RTP port** ranges for the media path with the Cable and Wireless SBC

Device Specific Settings > Media Interface: GSSCP\_07

UC-Sec Devices  
GSSCP\_07

Media Interface

Modifying or deleting an existing media interface will require an application restart before taking effect. Application restarts can be issued from System Management.

Add Media Interface

Name	Media IP	Port Range		
Int_Med	10.10.7.180	35000 - 40000		
Ext_Med	192.168.37.2	35000 - 40000		

## 7.4. Define Server Interworking

Server interworking is defined for each server connected to the Avaya SBCE. In this case, the Cable and Wireless SBC is connected as the Trunk Server and the Session Manager is connected as the Call Server. To define server interworking on the Avaya SBCE, navigate to **Global Profiles → Server Interworking** in the **UC-Sec Control Center** menu on the left hand side. To define Server Interworking for the Cable and Wireless SBC, highlight the **avaya-ru** profile which is a factory setting appropriate for Avaya equipment and select **Clone Profile**. A pop-up menu is generated headed **Clone Profile** (not shown)

- In the **Clone Name** field enter a descriptive name for the Cable and Wireless and click **Finish** – in test **ToCW** was used
- Select **Edit** and enter details in the pop-up menu.
- Check the **T.38** box
- Change the **Hold Support** RFC to **RFC2543** then click **Next** and **Finish**

General	
Hold Support	<input type="radio"/> None <input checked="" type="radio"/> RFC2543 - c=0.0.0.0 <input type="radio"/> RFC3264 - a=sendonly
180 Handling	<input checked="" type="radio"/> None <input type="radio"/> SDP <input type="radio"/> No SDP
181 Handling	<input checked="" type="radio"/> None <input type="radio"/> SDP <input type="radio"/> No SDP
182 Handling	<input checked="" type="radio"/> None <input type="radio"/> SDP <input type="radio"/> No SDP
183 Handling	<input checked="" type="radio"/> None <input type="radio"/> SDP <input type="radio"/> No SDP
Refer Handling	<input type="checkbox"/>
3xx Handling	<input type="checkbox"/>
Diversion Header Support	<input type="checkbox"/>
Delayed SDP Handling	<input type="checkbox"/>
T.38 Support	<input checked="" type="checkbox"/>
URI Scheme	<input checked="" type="radio"/> SIP <input type="radio"/> TEL <input type="radio"/> ANY
Via Header Format	<input checked="" type="radio"/> RFC3261 <input type="radio"/> RFC2543

Next

To define Server Interworking for the Session Manager, highlight the previously defined profile for the Cable and Wireless SBC and select **Clone Profile**. A pop-up menu is generated headed **Clone Profile** (not shown)

- In the **Clone Name** field enter a descriptive name for server interworking profile for the Session Manager and click **Finish** – in test **ToASM** was used
- Select **Edit** and enter details in the pop-up menu
- Check the **T.38** box
- Select **Next** three times and **Finish**

## 7.5. Define Servers

Servers are defined for each server connected to the Avaya SBCE. In this case, the Cable and Wireless SBC is connected as the Trunk Server and the Session Manager is connected as the Call Server. To define the Session Manager, navigate to **Global Profiles → Server Configuration** in the **UC-Sec Control Center** menu on the left hand side. Click on **Add Profile** and enter details in the pop-up menu (not shown)

- In the **Profile Name** field enter a descriptive name for the Session Manager and click **Next**
- In the **Server Type** drop down menu, select **Call Server**
- In the **IP Addresses / Supported FQDNs** box, type the Session Manager SIP interface address which is the same as that defined on the Communication Manager in **Section 5.2**
- Check **TCP** in **Supported Transports**
- Define the **TCP** port for SIP signalling, **5060** is used for Cable and Wireless
- Click **Next** three times then select the **Interworking Profile** for the Session Manager defined in **Section 7.4** from the drop down menu

The **General** tab on the resultant screen shows the **IP addresses** and **TCP Port** entered.

Global Profiles > Server Configuration: ASM\_CallServer

Add Profile | Rename Profile | Clone Profile | Delete Profile

Profile: ASM\_CallServer, CandW

General | Authentication | Heartbeat | Advanced

**General**

Server Type	Call Server
IP Addresses / FQDNs	10.10.7.61
Supported Transports	TCP
TCP Port	5060

Edit

The **Advanced** tab on the resultant screen shows the **Interworking Profile** for the call server defined in **Section 7.4**.

Global Profiles > Server Configuration: ASM\_CallServer

Add Profile | Rename Profile | Clone Profile | Delete Profile

Profile: ASM\_CallServer, CandW

General | Authentication | Heartbeat | Advanced

**Advanced**

Enable DoS Protection	<input type="checkbox"/>
Enable Grooming	<input type="checkbox"/>
Interworking Profile	ToASM
Signaling Manipulation Script	None
TCP Connection Type	SUBID

Edit



To define the Cable and Wireless SBC as a Trunk Server, navigate to **Global Profiles → Server Configuration** in the **UC-Sec Control Center** menu on the left hand side. Click on **Add Profile** and enter details in the pop-up menu (not shown)

- In the **Profile Name** field enter a descriptive name for the Cable and Wireless SBC and click Next
- In the **Server Type** drop down menu, select **Trunk Server**
- In the **IP Addresses / Supported FQDNs** box, type the IP address of the Cable and Wireless SBC (not shown)
- Check **TCP** and **UDP** in **Supported Transports**
- Define the **TCP** and **UDP** ports for SIP signaling, **5060** is used for Cable and Wireless
- Click **Next** three times then select the **Interworking Profile** for the Cable and Wireless SBC defined in **Section 7.4** from the drop down menu

The **General** tab on the resultant screen shows the **IP addresses**, **TCP Port** and **UDP Port** entered.

Global Profiles > Server Configuration: CandW

Buttons: Add Profile, Rename Profile, Clone Profile, Delete Profile

Profile List: Profile, ASM\_CallServer, CandW

Tabs: General, Authentication, Heartbeat, Advanced

General	
Server Type	Trunk Server
IP Addresses / FQDNs	192.168.24.8
Supported Transports	TCP, UDP
TCP Port	5060
UDP Port	5060

Edit

The **Advanced** tab on the resultant screen shows the **Interworking Profile** for the trunk server defined in **Section 7.4**.

Global Profiles > Server Configuration: CandW

Buttons: Add Profile, Rename Profile, Clone Profile, Delete Profile

Profile List: Profile, ASM\_CallServer, CandW

Tabs: General, Authentication, Heartbeat, Advanced

Advanced	
Enable DoS Protection	<input type="checkbox"/>
Enable Grooming	<input type="checkbox"/>
Interworking Profile	ToCW
Signaling Manipulation Script	None
TCP Connection Type	SUBID
UDP Connection Type	SUBID

Edit



## 7.6. Define Routing

Routing information is required for routing to the Session Manager on the internal side and the Cable and Wireless SBC on the external side. The IP addresses and ports defined here will be used as the destination addresses for signalling. If no port is specified in the **Next Hop IP Address**, default 5060 is used. To define routing to the Communication Manager, navigate to **Global Profiles → Routing** in the **UC-Sec Control Center** menu on the left hand side. Click on **Add Profile** and enter details in the **Routing Profile** pop-up menu (not shown).

- In the **Profile Name** field enter a descriptive name for the Session Manager and click **Next**
- Enter the Session Manager SIP interface address and port in the **Next Hop Server 1** field
- Select **TCP** for the **Outgoing Transport**
- Click **Finish**

**Note:** Unless default port 5060 is used, the port must be included in the next hop IP address.

Priority	URI Group	Next Hop Server 1	Next Hop Server 2	Next Hop Priority	NAPTR	SRV	Next Hop in Dialog	Ignore Route Header	Outgoing Transport
1	*	10.10.8.56	---	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	TCP

To define routing to the Cable and Wireless SBC, navigate to **Global Profiles → Routing** in the **UC-Sec Control Center** menu on the left hand side. Click on **Add Profile** and enter details in the **Routing Profile** pop-up menu.

- In the **Profile Name** field enter a descriptive name for the Cable and Wireless SBC and click **Next**
- Enter the Cable and Wireless SBC IP address and port in the **Next Hop Server 1** field
- Check the **Next Hop in Dialog** box
- Select **UDP** for the **Outgoing Transport**
- Click **Finish**

Priority	URI Group	Next Hop Server 1	Next Hop Server 2	Next Hop Priority	NAPTR	SRV	Next Hop in Dialog	Ignore Route Header	Outgoing Transport
1	*	192.168.24.8	---	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	UDP

## 7.7. Topology Hiding

Topology hiding is used to hide local information such as private IP addresses and local domain names. The local information can be overwritten or next hop IP addresses can be used. As IP addressing was used in test instead of domain names, there was little requirement for topology hiding. IP addresses are translated to the Avaya SBCE external addresses using NAT. To define Topology Hiding for the Session Manager, navigate to **Global Profiles → Topology Hiding** in the **UC-Sec Control Center** menu on the left hand side. Click on **Add Profile** and enter details in the **Topology Hiding Profile** pop-up menu (not shown).

- In the **Profile Name** field enter a descriptive name for the Session Manager and click **Next**
- If the required Header is not shown, click on **Add Header**
- Select **Request-Line** as the required header from the **Header** drop down menu
- Select the required action from the **Required Action** drop down menu, **Next Hop** was used for test
- If the Via Header is not shown, click on **Add Header**
- Select **Via** as the required header from the **Header** drop down menu
- Leave the **Required Action** at the default value of **Auto**
- If the Record-Route Header is not shown, click on **Add Header**
- Select **Record-Route** as the required header from the **Header** drop down menu
- Leave the **Required Action** at the default value of **Auto**

**Note:** The use of **Next Hop** results in the IP address being inserted in the host portion of the Request-URI as opposed to a domain name. If a domain name is required, the action **Overwrite** must be used for the **Request-Line** header with the required domain names entered in the **Overwrite Value** field. Different domain names could be used for the enterprise and the Cable and Wireless network.

Header	Criteria	Replace Action	Overwrite Value
Record-Route	IP/Domain	Auto	---
Via	IP/Domain	Auto	---
Request-Line	IP/Domain	Next Hop	---

To define Topology Hiding for the Cable and Wireless SBC, navigate to **Global Profiles** → **Topology Hiding** in the **UC-Sec Control Center** menu on the left hand side. Click on **Add Profile** and enter details in the **Topology Hiding Profile** pop-up menu (not shown).

- In the **Profile Name** field enter a descriptive name for the Cable and Wireless SBC and click **Next**
- If the Request-Line Header is not shown, click on **Add Header**
- Select **Request-Line** as the required header from the **Header** drop down menu
- Select the required action from the **Replace Action** drop down menu, **Next Hop** was used for test
- If the Via Header is not shown, click on **Add Header**
- Select **Via** as the required header from the **Header** drop down menu
- Leave the **Required Action** at the default value of **Auto**
- If the Record-Route Header is not shown, click on **Add Header**
- Select **Record-Route** as the required header from the **Header** drop down menu
- Leave the **Required Action** at the default value of **Auto**

Header	Criteria	Replace Action	Overwrite Value
Record-Route	IP/Domain	Auto	---
Via	IP/Domain	Auto	---
Request-Line	IP/Domain	Next Hop	---

**Note:** Topology Hiding on the **Via** and **Record-Route** headers was used in test to replace the multiple entries for the enterprise equipment with a single entry for the SBC. This reduces the overall size of the SIP INVITE.

## 7.8. Signalling Rules

Signalling rules are a mechanism on the Avaya Session Border Controller for Enterprise to handle any unusual signalling scenarios that may be encountered for a particular Service Provider. In the case of Cable and Wireless, the network is sending regular OPTIONS messages to the Enterprise that are passed on to the Session Manager by the Avaya SBCE. The Session Manager is responding to these with a 404 "Route Not Found" which, although it doesn't cause call failures, makes signalling traces harder to read.

A signalling rule was implemented during test to respond to OPTIONS from the trunk server with a 200 “OK”, this prevents the OPTIONS from being passed on to the Session Manager. To define the signalling rule, navigate to **Domain Policies → Signaling Rules** in the **UC-Sec Control Center** menu on the left hand side. Click on **Add Rule** and enter details in the Signalling Rule pop-up box (not shown)

- In the **Rule Name** field enter a descriptive name for the OPTIONS handling signalling rule and click **Next** and **Next** again, then **Finish**
- Click on the **Requests** tab
- Click on **Add in Request Control** and enter details in the pop-up box (not shown)
- Select **OPTIONS** in the **Method Name** field
- Select **Block with** in the **In Dialog Action** field
- Define the response code as **200** and the text field as **OK**
- Select **Block with** in the **Out of Dialog Action** field
- Define the response code as **200** and the text field as **OK**

Row	Method Name	In Dialog Action	Out of Dialog Action	Proprietary	Direction
1	OPTIONS	Block with "200 OK"	Block with "200 OK"	No	IN

An End Point Policy Group is required to implement the signalling rule. To define this, navigate to **Domain Policies → End Point Policy Groups** in the **UC-Sec Control Center** menu on the left hand side. Click on **Add Group** and enter details in the Policy Group pop-up box (not shown)

- In the **Group Name** field enter a descriptive name for the Cable and Wireless Policy Group and click **Next**
- In the **Signaling** drop down menu, select the recently added signalling rule for the OPTIONS response
- All other values are left as default

Order	Application	Border	Media	Security	Signaling	Time of Day
1	default	default	default-low-med	default-low	OPTIONS-Response	default

## 7.9. Server Flows

Server Flows combine the previously defined profiles into an outgoing flow from the Session Manager to the Cable and Wireless SBC and an incoming flow from the Cable and Wireless SBC to the Session Manager. This configuration ties all the previously entered information together so that calls can be routed from the Session Manager to the Cable and Wireless SBC and vice versa. The information for all Server Flows is shown on a single screen on the Avaya SBCE.

Device Specific Settings > End Point Flows: GSSCP\_07

UC-Sec Devices

GSSCP\_07

Subscriber Flows

Server Flows

Add Flow

Hover over a row to see its description.

Server Configuration: ASM\_CallServer

Priority	Flow Name	URI Group	Transport	Remote Subnet	Received Interface	Signaling Interface	Media Interface	End Point Policy Group	Routing Profile	Topology Hiding Profile	File Transfer Profile			
1	Callserver	*	*	*	Ext_Sig	Int_Sig	Int_Med	default-low	CandW	ASM	None			

Server Configuration: CandW

Priority	Flow Name	URI Group	Transport	Remote Subnet	Received Interface	Signaling Interface	Media Interface	End Point Policy Group	Routing Profile	Topology Hiding Profile	File Transfer Profile			
1	Trunkserver	*	*	*	Int_Sig	Ext_Sig	Ext_Med	CandW-low	ASM_7	CandW	None			



To define an outgoing Server Flow, navigate to **Device Specific Settings → End Point Flows**.

- Click on the **Server Flows** tab
- Select **Add Flow** and enter details in the pop-up menu
- In the **Name** field enter a descriptive name for the outgoing server flow to the Cable and Wireless SBC
- In the **Received Interface** drop-down menu, select the internal SIP signalling interface defined in **Section 7.3**
- In the **Signaling Interface** drop-down menu, select the external SIP signalling interface defined in **Section 7.3**
- In the **Media Interface** drop-down menu, select the external media interface defined in **Section 7.3**
- In the **Routing Profile** drop-down menu, select the routing profile of the Session Manager defined in **Section 7.6**
- In the **Topology Hiding Profile** drop-down menu, select the topology hiding profile of the Cable and Wireless SBC defined in **Section 7.7** and click **Finish**

Server Configuration: CandW												
Priority	Flow Name	URI Group	Transport	Remote Subnet	Received Interface	Signaling Interface	Media Interface	End Point Policy Group	Routing Profile	Topology Hiding Profile	File Transfer Profile	
1	Trunkserver	*	*	*	Int_Sig	Ext_Sig	Ext_Med	CandW-low	ASM_7	CandW	None	  

An incoming Server Flow is defined as a reversal of the outgoing Server Flow

- Click on the **Server Flows** tab
- Select **Add Flow** and enter details in the pop-up menu
- In the **Name** field enter a descriptive name for the incoming server flow to the Session Manager
- In the **Received Interface** drop-down menu, select the external SIP signalling interface defined in **Section 7.3**
- In the **Signaling Interface** drop-down menu, select the internal SIP signalling defined in **Section 7.3**
- In the **Media Interface** drop-down menu, select the internal media interface defined in **Section 7.3**
- In the **End Point Policy Group** drop-down menu, select the policy group defined in **Section 7.8**
- In the **Routing Profile** drop-down menu, select the routing profile of the Cable and Wireless SBC defined in **Section 7.6**
- In the **Topology Hiding Profile** drop-down menu, select the topology hiding profile of the Session Manager defined in **Section 7.7** and click **Finish**

Server Configuration: ASM_CallServer												
Priority	Flow Name	URI Group	Transport	Remote Subnet	Received Interface	Signaling Interface	Media Interface	End Point Policy Group	Routing Profile	Topology Hiding Profile	File Transfer Profile	
1	Callserver	*	*	*	Ext_Sig	Int_Sig	Int_Med	default-low	CandW	ASM	None	  



## 8. Configure Cable and Wireless SIP IP Trunking

The configuration of the Cable and Wireless equipment used to support the SIP IP Trunking service is outside of the scope of these Application Notes and will not be covered. To obtain further information on Cable and Wireless equipment and system configuration please contact an authorised Cable and Wireless representative.

## 9. Verification Steps

This section provides steps that may be performed to verify that the solution is configured correctly.

1. From System Manager Home Tab, click on Session Manager and navigate to **Session Manager → System Status → SIP Entity Monitoring**. Select the relevant SIP Entity from the list and observe if the **Conn Status** and **Link Status** are showing as **up**.

Home / Elements / Session Manager / System Status / SIP Entity Monitoring							
SIP Entity, Entity Link Connection Status							
This page displays detailed connection status for all entity links from all Session Manager instances to a single SIP entity.							
All Entity Links to SIP Entity: ASBCAE							
Summary View							
1 Item   Refresh							
Filter: Enable							
Details	Session Manager Name	SIP Entity Resolved IP	Port	Proto.	Conn. Status	Reason Code	Link Status
► Show	ASMDotZ	10.10.7.180	5060	TCP	Up	200 OK	Up

2. From the Communication Manager SAT interface run the command **status trunk n** where **n** is a previously configured SIP trunk. Observe if all channels on the trunk group display **in-service/idle**.

status trunk 1			
TRUNK GROUP STATUS			
Member	Port	Service State	Mtce Connected Ports Busy
0001/001	T00001	in-service/idle	no
0001/002	T00002	in-service/idle	no
0001/003	T00003	in-service/idle	no
0001/004	T00004	in-service/idle	no
0001/005	T00005	in-service/idle	no
0001/006	T00006	in-service/idle	no
0001/007	T00007	in-service/idle	no
0001/008	T00008	in-service/idle	no
0001/009	T00009	in-service/idle	no
0001/010	T00010	in-service/idle	no

3. Verify that endpoints at the enterprise site can place calls to the PSTN and that the call remains active.
4. Verify that endpoints at the enterprise site can receive calls from the PSTN and that the call can remain active.
5. Verify that the user on the PSTN can end an active call by hanging up.

6. Verify that an endpoint at the enterprise site can end an active call by hanging up.

## 10. Conclusion

These Application Notes describe the configuration necessary to connect Avaya Aura® Communication Manager, Avaya Aura® Session Manager and Avaya Session Border Controller for Enterprise to Cable and Wireless SIP IP Trunking service. The service was successfully tested with a number of observations listed in **Section 2.2**.

## 11. Additional References

This section references the documentation relevant to these Application Notes. Additional Avaya product documentation is available at <http://support.avaya.com>.

- [1] *Installing and Configuring Avaya Aura® System Platform Release 6.2*, March 2012.
- [2] *Administering Avaya Aura® System Platform Release 6.2*, February 2012.
- [3] *Administering Avaya Aura® Communication Manager*, Release 6.2, February 2012.
- [4] *Avaya Aura® Communication Manager Feature Description and Implementation*, February 2012, Document Number 555-245-205.
- [5] *Implementing Avaya Aura® System Manager Release 6.2*, March 2012.
- [6] *Implementing Avaya Aura® Session Manager*, February 2012, Document Number 03-603473
- [7] *Administering Avaya Aura® Session Manager*, February 2012, Document Number 03-603324.
- [8] *Various Application Notes for the Avaya Session Border Controller for Enterprise*, March 2012
- [9] *RFC 3261 SIP: Session Initiation Protocol*, <http://www.ietf.org/>



---

**©2012 Avaya Inc. All Rights Reserved.**

Avaya and the Avaya Logo are trademarks of Avaya Inc. All trademarks identified by ® and ™ are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners. The information provided in these Application Notes is subject to change without notice. The configurations, technical data, and recommendations provided in these Application Notes are believed to be accurate and dependable, but are presented without express or implied warranty. Users are responsible for their application of any products specified in these Application Notes.

Please e-mail any questions or comments pertaining to these Application Notes along with the full title name and filename, located in the lower right corner, directly to the Avaya DevConnect Program at [devconnect@avaya.com](mailto:devconnect@avaya.com).