



## Avaya Solution & Interoperability Test Lab

---

# **Application Notes for PIVOT™ by Spectralink (87-Series) Wireless SIP Telephones and Avaya Aura® Communication Manager and Avaya Aura® Session Manager – Issue 1.0**

### **Abstract**

These Application Notes describe the procedures for configuring PIVOT™ by Spectralink (87-Series) Wireless SIP Telephones which were compliance tested with Avaya Aura® Communication Manager and Avaya Aura® Session Manager.

The overall objective of the interoperability compliance testing is to verify Pivot Telephones functionalities in an environment comprised of Avaya Aura® Communication Manager, Avaya Aura® Session Manager, and various Avaya 9600 Series IP Deskphones.

Information in these Application Notes has been obtained through DevConnect compliance testing and additional technical discussions. Testing was conducted via the DevConnect Program at the Avaya Solution and Interoperability Test Lab.

# 1. Introduction

These Application Notes describe the procedures for configuring Pivot Telephones which were compliance tested with Avaya Aura® Communication Manager and Avaya Aura® Session Manager. Pivot Telephones register to Session Manager via UDP.

Pivot (87-Series) expands the Spectralink 8000 Portfolio of Voice over Wi-Fi handsets to deliver enterprise-grade, on-site voice mobility with a user-friendly interface presented on an extensible application platform.

Based on the industry standard Android™ operating system, it is a WorkSmart solution - differentiated by its intuitive touchscreen design, HD voice quality, seamless Voice over Wi-Fi roaming without dropouts, durability, broad telephony and WLAN interoperability, and predictable return on investment.

PIVOT further enhances the customer value proposition with two enhanced standards-based application interfaces, an optional, high-performance integrated barcode scanner and an industrial-grade accelerometer. In partnership with the Spectralink applications development ecosystem, PIVOT enables new opportunities for end-user productivity solutions.

These Application Notes assume that Communication Manager and Session Manager are already installed and basic configuration steps have been performed. Only steps relevant to this compliance test will be described in this document. For further details on configuration steps not covered in this document, consult reference documents in [Section 10](#).

## 2. General Test Approach and Test Results

The general test approach was to place calls to and from Pivot and exercise basic telephone operations. The main objectives were to verify the following:

- Registration
- Codecs (G.711MU and G.729A)
- Inbound calls
- Outbound calls
- Hold/Resume
- Call termination (origination/destination)
- Three party conference (origination/destination)
- Avaya Feature Name Extension (FNE)
  - Call Park
  - Call Pickup
  - Call Forward (Unconditional, Busy/No answer)
- MWI
- Voicemail
- Serviceability

## 2.1. Interoperability Compliance Testing

The interoperability compliance test included features and serviceability. The focus of the interoperability compliance testing was primarily on verifying call establishment on Pivot. Pivot operations such as inbound calls, outbound calls, hold/resume, transfer, conference, Feature Name Extension (FNE), and Pivot interactions with Session Manager, Communication Manager, and Avaya SIP, H.323, and digital telephones were verified. The serviceability testing introduced failure scenarios to see if Pivot can recover from failures.

## 2.2. Test Results

The test objectives were verified. For serviceability testing, Pivot operated properly after recovering from failures such as cable disconnects, and resets of Pivot and Session Manager. Pivot successfully negotiated the codec that was used. The features tested worked as expected.

## 2.3. Support

Technical support on Pivot can be obtained through the following:

### North America

Phone: +1-800-775-5330

Email: [nolarma@spectralink.com](mailto:nolarma@spectralink.com)

Web: <http://support.spectralink.com>

### EMEA


Phone: +33-176774541

Email: [emeaom@spectralink.com](mailto:emeaom@spectralink.com)

Web: <http://support.spectralink.com>

### 3. Reference Configuration

**Figure 1** illustrates a sample configuration consisting of an Avaya S8300D Server, an Avaya G450 Media Gateway, a Session Manager, and Pivot. The solution described herein is also extensible to other Avaya Media Servers and Media Gateways. **Figure 1** demonstrates calls between the SIP-based Pivot and Avaya SIP, H.323, digital and analog telephones.



**Figure 1: Test Configuration of PIVOT™ by Spectralink**

## 4. Equipment and Software Validated

The following equipment and software were used for the test configuration.

Equipment		Software/Firmware
Avaya Aura® Communication Manager Avaya Aura® Communication Manager Messaging		R016x.03.0.124.0
Avaya Aura® System Manager		6.3.5.0
Avaya Aura® Session Manager		6.3.5
Avaya G650 Media Gateway		30.21.1
Avaya 9600 Series Deskphones		
	96x1 (SIP)	6.3.1
	96x1 (H.323)	6.3.1
	96x0 (SIP)	2.6.11
	96x0 (H.323)	3.2.1
Avaya 9608 Digital Phone		-
Avaya 6211 Analog Phone		-
PIVOT™ by Spectralink		JZO54K 1.0.0.4037
Spectralink Configuration Management System		1.0.2

## 5. Configure the Avaya Aura® Communication Manager

This section describes the procedure for setting up a SIP trunk between Communication Manager and Session Manager. The steps include setting up an IP codec set, an IP network region, IP node name, a signaling group, a trunk group, and a SIP station. Before a trunk can be configured, it is necessary to verify if there is enough capacity to setup an additional trunk. The highlights in the following screens indicate the values used during the compliance test. Default values may be used for all other fields.

These steps are performed from the Communication Manager System Access Terminal (SAT) interface. Pivot and other SIP telephones are configured as off-PBX telephones in Communication Manager.

### 5.1. Capacity Verification

Enter the **display system-parameters customer-options** command. Verify that there are sufficient **Maximum Off-PBX Telephones – OPS** licenses. If not, contact an authorized Avaya account representative to obtain additional licenses.

```
change system-parameters customer-options                               Page 1 of 11
                                OPTIONAL FEATURES

G3 Version: V16                                     Software Package: Enterprise
Location: 2                                         System ID (SID): 1
Platform: 28                                       Module ID (MID): 1

                                USED
                                Platform Maximum Ports: 6400 401
                                Maximum Stations: 2400 63
                                Maximum XMOBILE Stations: 2400 0
Maximum Off-PBX Telephones - EC500: 9600 0
Maximum Off-PBX Telephones - OPS: 9600 11
Maximum Off-PBX Telephones - PBFMC: 9600 0
Maximum Off-PBX Telephones - PVFMC: 9600 0
Maximum Off-PBX Telephones - SCCAN: 0 0
                                Maximum Survivable Processors: 313 1
```

On **Page 2** of the form, verify that the number of SIP trunks supported by the system is sufficient for the number of SIP trunks needed. If not, contact an authorized Avaya account representative to obtain additional licenses.

```

change system-parameters customer-options                               Page 2 of 11
                                OPTIONAL FEATURES

IP PORT CAPACITIES                                                    USED
    Maximum Administered H.323 Trunks: 4000 147
    Maximum Concurrently Registered IP Stations: 2400 4
    Maximum Administered Remote Office Trunks: 4000 0
Maximum Concurrently Registered Remote Office Stations: 2400 0
    Maximum Concurrently Registered IP eCons: 68 0
    Max Concur Registered Unauthenticated H.323 Stations: 100 0
    Maximum Video Capable Stations: 2400 0
    Maximum Video Capable IP Softphones: 2400 1
    Maximum Administered SIP Trunks: 4000 148
Maximum Administered Ad-hoc Video Conferencing Ports: 4000 0
    Maximum Number of DS1 Boards with Echo Cancellation: 80 0
    Maximum TN2501 VAL Boards: 10 0
    Maximum Media Gateway VAL Sources: 50 1
    Maximum TN2602 Boards with 80 VoIP Channels: 128 0
    Maximum TN2602 Boards with 320 VoIP Channels: 128 0
    Maximum Number of Expanded Meet-me Conference Ports: 300 0
  
```

## 5.2. IP Codec Set

This section describes the steps for administering a codec set in Communication Manager. This codec set is used in the IP network region for communications between Communication Manager and Session Manager. Enter the **change ip-codec-set <c>** command, where **c** is a number between **1** and **7**, inclusive. IP codec sets are used in **Section 5.3** for configuring IP network region to specify which codec sets may be used within and between network regions. For the compliance testing, G.711MU, G.729A were tested for verification.

```

change ip-codec-set 1                                               Page 1 of 2

                                IP Codec Set

Codec Set: 1

Audio      Silence      Frames      Packet
Codec      Suppression  Per Pkt    Size(ms)
1: G.711MU      n           2          20
2: G.729        n           2          20
3:
4:
5:
6:
7:
  
```

### 5.3. Configure IP Network Region

This section describes the steps for administering an IP network region in Communication Manager for communication between Communication Manager and Session Manager. Enter the **change ip-network-region <n>** command, where **n** is a number between **1** and **250** inclusive, and configure the following:

- **Authoritative Domain** – Enter the appropriate name for the Authoritative Domain. Set to the appropriate domain. During the compliance test, the authoritative domain is set to **avaya.com**. This should match the SIP Domain value on Session Manager, in **Section 6.1**.
- **Intra-region IP-IP Direct Audio** – Set to **yes** to allow direct IP-to-IP audio connectivity between endpoints registered to Communication Manager or Session Manager in the same IP network region. The default value for this field is **yes**.
- **Codec Set** – Set the codec set number as provisioned in **Section 5.2**.
- **Inter-region IP-IP Direct Audio** – Set to **yes** to allow direct IP-to-IP audio connectivity between endpoints registered to Communication Manager or Session Manager in different IP network regions. The default value for this field is **yes**.

```
change ip-network-region 1                                     Page 1 of 20
                                                              IP NETWORK REGION
Region: 1
Location: 1          Authoritative Domain: avaya.com
Name: Default       Stub Network Region: n
MEDIA PARAMETERS    Intra-region IP-IP Direct Audio: yes
                   Codec Set: 1                Inter-region IP-IP Direct Audio: yes
                   UDP Port Min: 2048           IP Audio Hairpinning? y
                   UDP Port Max: 65535
DIFFSERV/TOS PARAMETERS
Call Control PHB Value: 44
Audio PHB Value: 44
Video PHB Value: 26
802.1P/Q PARAMETERS
Call Control 802.1p Priority: 6
Audio 802.1p Priority: 6
Video 802.1p Priority: 5      AUDIO RESOURCE RESERVATION PARAMETERS
H.323 IP ENDPOINTS      RSVP Enabled? n
H.323 Link Bounce Recovery? y
Idle Traffic Interval (sec): 20
Keep-Alive Interval (sec): 5
Keep-Alive Count: 5
```

## 5.4. Configure IP Node Name

This section describes the steps for setting IP node name for Session Manager in Communication Manager. Enter the **change node-names ip** command, and add a node name for Session Manager along with its IP address.

```
change node-names ip                                     Page 1 of 2
                                                    IP NODE NAMES
      Name                IP Address
8730TR1                 10.64.10.74
AAEP                   10.64.101.26
SM_10_62              10.64.10.62
AuraSBC-Inside        10.64.10.112
AuraSM                 10.64.21.31
AvayaIQ                10.64.50.15
CM                     10.64.10.67
CMS                    10.64.10.85
CM_101_12             10.64.101.12
CRYSTAL_SM            10.64.60.19
CTLog                  10.64.10.56
Chung                  10.64.41.21
FAXPN1                10.64.22.16
FaxServer              10.64.10.170
GFI                    10.64.101.81
Gateway001            10.64.10.1
( 16 of 31 administered node-names were displayed )
Use 'list node-names' command to see all the administered node-names
Use 'change node-names ip xxx' to change a node-name 'xxx' or add a node-name
```

## 5.5. Configure SIP Signaling

This section describes the steps for administering a signaling group in Communication Manager for communication between Communication Manager and Session Manager. Enter the **add signaling-group <s>** command, where **s** is an available signaling group and configure the following:

- **Group Type** – Set to **sip**.
- **Transport Type** – Set to **tls**.
- **Near-end Node Name** - Set to **procr**.
- **Far-end Node Name** - Set to the Session Manager name configured in **Section 5.4**.
- **Far-end Network Region** - Set to the region configured in **Section 5.3**.
- **Near-end Listen Port** and **Far-end Listen Port** – Set to 5061.
- **Far-end Domain** - Set to **avaya.com**. This should match the SIP Domain value in **Section 6.1**.
- **Direct IP-IP Audio Connections** – Set to **y**, since Media Shuffling is enabled during the compliance test

```

add signaling-group 10                                     Page 1 of 2
                                                    SIGNALING GROUP

Group Number: 10                Group Type: sip
IMS Enabled? n                  Transport Method: tls
    Q-SIP? n
    IP Video? n                  Enforce SIPS URI for SRTP? y
Peer Detection Enabled? y Peer Server: SM
Prepend '+' to Outgoing Calling/Alerting/Diverting/Connected Public Numbers? y
Remove '+' from Incoming Called/Calling/Alerting/Diverting/Connected Numbers? n

Near-end Node Name: procr                Far-end Node Name: SM_10_62
Near-end Listen Port: 5061                Far-end Listen Port: 5061
                                           Far-end Network Region: 1

Far-end Domain: avaya.com

Incoming Dialog Loopbacks: eliminate                Bypass If IP Threshold Exceeded? n
DTMF over IP: rtp-payload                            RFC 3389 Comfort Noise? n
Session Establishment Timer(min): 3                Direct IP-IP Audio Connections? y
    Enable Layer 3 Test? y                            IP Audio Hairpinning? n
H.323 Station Outgoing Direct Media? n                Initial IP-IP Direct Media? n
                                           Alternate Route Timer(sec): 6

```

## 5.6. Configure SIP Trunk

This section describes the steps for administering a trunk group in Communication Manager for communication between Communication Manager and Session Manager. Enter the **add trunk-group <t>** command, where **t** is an unallocated trunk group and configure the following:

- **Group Type** – Set the Group Type field to **sip**.
- **Group Name** – Enter a descriptive name.
- **TAC (Trunk Access Code)** – Set to any available trunk access code.
- **Signaling Group** – Set to the Group Number field value configured in **Section 5.5**.
- **Number of Members** – Allowed value is between 0 and 255. Set to a value large enough to accommodate the number of SIP telephone extensions being used.

```

change trunk-group 10                                     Page 1 of 21
                                                    TRUNK GROUP

Group Number: 10                Group Type: sip                CDR Reports: y
Group Name: to_SM_10_62                COR: 1                TN: 1                TAC: *010
Direction: two-way                Outgoing Display? n
Dial Access? n                Night Service:
Queue Length: 0
Service Type: tie                Auth Code? n
                                           Member Assignment Method: auto
                                           Signaling Group: 10
                                           Number of Members: 10

```

## 6. Configure Avaya Aura® Session Manager

This section provides the procedures for configuring Session Manager as provisioned in the reference configuration. Session Manager is comprised of two functional components: the Session Manager server and the System Manager server. All SIP call provisioning for Session Manager is performed through the System Manager Web interface and is then downloaded into Session Manager.


The following sections assume that Session Manager and System Manager have been installed and that network connectivity exists between the two platforms.

In this section, the following topics are discussed:

- SIP Domains
- Locations
- SIP Entities
- Entity Links
- Time Ranges
- Routing Policy
- Dial Patterns
- User Management

## 6.1. Configure SIP Domain

Launch a web browser, enter <http://<IP address of System Manager>> in the URL, and log in with the appropriate credentials.




In the main menu, navigate to **Elements** → **Routing** → **Domains**, and click on the **New** button (not shown) to create a new SIP Domain. Enter the following values and use default values for remaining fields:

- **Name** – Enter the Authoritative Domain Name specified in **Section 5.3**, which is **avaya.com**.
- **Type** – Select **SIP**

Click **Commit** to save.

The following screen shows the Domains page used during the compliance test.



## 6.2. Configure Locations

Locations are used to identify logical and/or physical locations where SIP Entities reside, for purposes of bandwidth management or location-based routing.

From the main menu, navigate to **Elements → Routing → Locations**, and click on the **New** button (not shown) to create a new SIP endpoint location.

### General section

Enter the following values and use default values for remaining fields.

- Enter a descriptive Location name in the **Name** field (e.g. **Test Room 1**).
- Enter a description in the **Notes** field if desired.


### Location Pattern section

Click **Add** and enter the following values:

- Enter the IP address information for the **IP address Pattern** field (e.g. **10.64.10.\***).
- Enter a description in the **Notes** field if desired.

Repeat steps in the Location Pattern section if the Location has multiple IP segments. Modify the remaining values on the form, if necessary; otherwise, use all the default values. Click on the **Commit** button.

The following screen shows the Locations list used during the compliance test.



The screenshot displays the Avaya Aura System Manager 6.3 interface. The top navigation bar includes the Avaya logo, the text "Aura System Manager 6.3", and the user information "Last Logged on at March 7, 2014 2:47 PM" with links for "Help | About | Change Password | Log off admin". The main content area shows the "Routing" menu expanded to "Locations". The breadcrumb path is "Home / Elements / Routing / Locations". The "Location" section contains buttons for "New", "Edit", "Delete", "Duplicate", and "More Actions". Below this is a table with 3 items, filtered by "Filter: Enable". The table has columns for "Name" and "Notes". The items listed are "Test Room 1", "Test Room 2", and "Test Room 3". A "Select" dropdown is set to "All, None".

<input type="checkbox"/>	Name	Notes
<input type="checkbox"/>	Test Room 1	
<input type="checkbox"/>	Test Room 2	
<input type="checkbox"/>	Test Room 3	

### 6.3. Configure SIP Entities

A SIP Entity must be added for Session Manager and for each network component that has a SIP trunk provisioned to Session Manager. During the compliance test, the following SIP Entities were configured:

- Session Manager itself. This entity was created prior to the compliance test.
- Communication Manager. This entity was created prior to the compliance test.

Navigate to **Routing → SIP Entities**, and click on the **New** button (not shown) to create a new SIP entity. Provide the following information:

#### General section

Enter the following values and use default values for remaining fields.

- Enter a descriptive Entity name in the **Name** field.
- Enter IP address for signaling interface on each Communication Manager, Session Manager, or 3<sup>rd</sup> party device in the **FQDN or IP Address** field
- From the **Type** drop down menu select a type that best matches the SIP Entity.
  - For Communication Manager, select CM
  - For Session Manager, select Session Manager
- Enter a description in the **Notes** field if desired.
- Select the appropriate time zone.
- Accept the other default values.

#### SIP Link Monitoring section

- Accept the other default values.

Click on the **Commit** button to save each SIP entity.

The following screen shows some of the SIP Entities page used during the compliance test, i.e., **asm-tr1**, **cm-tr1** and **cmm-tr1**.

Repeat all the steps for each new entity.

AVAYA  
Aura® System Manager 6.3

Last Logged on at March 7, 2014 2:47 PM  
Help | About | Change Password | Log off admin

Home Routing x

Routing

- Domains
- Locations
- Adaptations
- SIP Entities**
- Entity Links
- Time Ranges
- Routing Policies
- Dial Patterns
- Regular Expressions
- Defaults

Home / Elements / Routing / SIP Entities [Help ?](#)

SIP Entities

New Edit Delete Duplicate More Actions ▾

8 Items [Refresh](#) Filter: Enable

<input type="checkbox"/>	Name	FQDN or IP Address	Type	Notes
<input type="checkbox"/>	<a href="#">aaep-tr1</a>	10.64.101.26	Voice Portal	Avaya Aura® Experience Portal - Test Room 1
<input type="checkbox"/>	<a href="#">asm-tr1</a>	10.64.10.62	Session Manager	Avaya Aura® Session Manager - Test Room 1
<input type="checkbox"/>	<a href="#">asm-tr2</a>	10.64.21.31	Session Manager	Avaya Aura® Session Manager - Test Room 2
<input type="checkbox"/>	<a href="#">cmm-tr1</a>	10.64.10.67	SIP Trunk	Avaya Aura® Communication Manager Messaging - Test Room 1
<input type="checkbox"/>	<a href="#">cm-tr1</a>	10.64.10.67	CM	Avaya Aura® Communication Manager - Test Room 1
<input type="checkbox"/>	<a href="#">ipo-500v2-tr1</a>	10.64.10.54	SIP Trunk	Avaya IP Office 500V2 - Test Room 1
<input type="checkbox"/>	<a href="#">mx-tr1</a>	10.64.10.160	SIP Trunk	Avaya Meeting Exchange
<input type="checkbox"/>	<a href="#">rauland-borg</a>	10.64.10.151	SIP Trunk	

Select : All, None

## 6.4. Configure Entity Links

Entity Links define the connections between the SIP Entities and Session Manager. In the compliance test, the following entity links are defined from Session Manager.

- Session Manager ↔ Communication Manager (Avaya S8300D Server). This entity link was created prior to the compliance test.

Navigate to **Routing** → **Entity Links**, and click on the **New** button (not shown) to create a new entity link. Provide the following information:

- Enter a descriptive name in the **Name** field.
- In the **SIP Entity 1** drop down menu, select the Session Manager SIP Entity shown in **Section 6.3** (e.g. **SM\_10\_62**).
- In the **Protocol** drop down menu, select the protocol to be used.
- In the **Port** field, enter the port to be used (e.g. **5060** or **5061**).
  - TLS – 5061
  - UDP or TCP – 5060
- In the **SIP Entity 2** drop down menu, select Communication Manager SIP entity
- In the **Port** field, enter the port to be used (e.g. **5060** or **5061**).
- Enter a description in the **Notes** field if desired.
- Accept the other default values.

Click on the **Commit** button to save each Entity Link definition.



Repeat the steps to define Entity Link using a different protocol.


## 6.5. Time Ranges

The Time Ranges form allows admission control criteria to be specified for Routing Policies (Section 6.6). In the reference configuration, no restrictions were used.

To add a Time Range, navigate to **Routing** → **Time Ranges**, and click on the **New** button (not shown). Provide the following information:

- Enter a descriptive Time Range name in the **Name** field (e.g. **24/7**).
- Check each day of the week.
- In the **Start Time** field, enter **00:00**.
- In the **End Time** field, enter **23:59**.
- Enter a description in the **Notes** field if desired.

Click the **Commit** button. The following screen shows the Time Range page used during the compliance test.



## 6.6. Configure Routing Policy

Routing Policies associate destination SIP Entities (**Section 6.3**) with Time of Day admission control parameters (**Section 6.5**) and Dial Patterns (**Section 6.7**). In the reference configuration, Routing Policies are defined for:

- Calls to/from Communication Manager.

To add a Routing Policy, navigate to **Routing → Routing Policy**, and click on the **New** button (not shown) on the right. Provide the following information:

### General section

- Enter a descriptive name in the **Name** field.
- Enter a description in the **Notes** field if desired.

### SIP Entity as Destination section

- Click the **Select** button.
- Select the SIP Entity that will be the destination for this call (not shown).
- Click the **Select** button and return to the Routing Policy Details form.

Time of Day section – Leave default values.

Click **Commit** to save Routing Policy definition. The following screen shows the Routing Policy used for the entity, **cm-tr1**, during the compliance test.

The screenshot displays the Avaya Aura System Manager 6.3 interface. The top navigation bar includes the Avaya logo, 'Aura System Manager 6.3', and user information: 'Last Logged on at March 7, 2014 2:47 PM' with links for 'Help | About | Change Password | Log off admin'. The main content area is titled 'Routing Policy Details' and includes 'Commit' and 'Cancel' buttons. The 'General' section contains fields for 'Name' (cm-tr1), 'Disabled' (checkbox), 'Retries' (0), and 'Notes'. The 'SIP Entity as Destination' section has a 'Select' button and a table with columns: Name, FQDN or IP Address, Type, and Notes. The table contains one entry: cm-tr1, 10.64.10.67, CM, Avaya Aura® Communication Manager - Test Room 1. The 'Time of Day' section includes 'Add', 'Remove', and 'View Gaps/Overlaps' buttons, a 'Filter: Enable' dropdown, and a table with columns: Ranking, Name, Mon, Tue, Wed, Thu, Fri, Sat, Sun, Start Time, End Time, and Notes. The table shows one item with Ranking 0, Name 24/7, and Start/End times of 00:00 and 23:59 respectively. A 'Select: All, None' option is at the bottom.

Name	FQDN or IP Address	Type	Notes
cm-tr1	10.64.10.67	CM	Avaya Aura® Communication Manager - Test Room 1

Ranking	Name	Mon	Tue	Wed	Thu	Fri	Sat	Sun	Start Time	End Time	Notes
0	24/7	☑	☑	☑	☑	☑	☑	☑	00:00	23:59	

## 6.7. Dial Patterns

Dial Patterns define digit strings to be matched for inbound and outbound calls. In addition, the domain in the request URI is also examined. In the compliance test, the following dial patterns are defined from Session Manager.

- 2555x and 2500x – SIP and H323 endpoints in Avaya S8300D Server

To add a Dial Pattern, select **Routing → Dial Patterns**, and click on the **New** button (not shown) on the right. During the compliance test, 5 digit dial plan was utilized. Provide the following information:

### General section

- Enter a unique pattern in the **Pattern** field (e.g. **250**).
- In the **Min** field enter the minimum number of digits (e.g. **5**).
- In the **Max** field enter the maximum number of digits (e.g. **5**).
- In the **SIP Domain** field drop down menu select the domain that will be contained in the Request URI *received* by Session Manager from Communication Manager.
- Enter a description in the **Notes** field if desired.

### Originating Locations and Routing Policies section

- Click on the **Add** button and a window will open (not shown).
- Click on the boxes for the appropriate Originating Locations, and Routing Policies (see **Section 6.6**) that pertain to this Dial Pattern.
  - Originating Location –Check the **Apply The Selected Routing Policies to All Originating Locations** box.
  - Routing Policies **cm-tr1**.
  - Click on the **Select** button and return to the Dial Pattern window.

Click the **Commit** button to save the new definition. The following screen shows the dial pattern used for the S8300D during the compliance test.

Home Routing x

- Routing
- Domains
- Locations
- Adaptations
- SIP Entities
- Entity Links
- Time Ranges
- Routing Policies
- Dial Patterns**
- Regular Expressions
- Defaults

Home / Elements / Routing / Dial Patterns

Help ?

Dial Pattern Details

Commit Cancel

General

\* Pattern: 250

\* Min: 5

\* Max: 5

Emergency Call:

Emergency Priority: 1

Emergency Type:

SIP Domain: -ALL-

Notes:

Originating Locations and Routing Policies

Add Remove

1 Item

Filter: Enable

<input type="checkbox"/>	Originating Location Name	Originating Location Notes	Routing Policy Name	Rank	Routing Policy Disabled	Routing Policy Destination	Routing Policy Notes
<input type="checkbox"/>	-ALL-		cm-tr1		<input type="checkbox"/>	cm-tr1	

Select : All, None

## 6.8. Configure SIP Users

During the compliance test, no special users were created for this solution. All users were created prior to the compliance test. However, the steps to configure a user are included.

Add new SIP users for each Spectralink 87-Series phone.

To add new SIP users, Navigate to **Home → Users → User Management → Manage Users**. Click **New (not shown)** and provide the following information:

- Identity section
  - **Last Name** – Enter last name of user.
  - **First Name** – Enter first name of user.
  
  - **Login Name** – Enter extension number@sip domain name. The domain name is defined in **Section 5.3**.
  - **Authentication Type** – Verify **Basic** is selected.
  - **SMGR Login Password** – Enter password to be used to log into System Manager.
  - **Confirm Password** – Repeat value entered above.
  - Enter **Localized Display Name**
  - Enter **Endpoint Display Name**
  - Select **English** as **Language Preference**
  - Set the appropriate **Time Zone**.

AVAYA  
Aura System Manager 6.3

Last Logged on at March 7, 2014 2:47 PM  
Help | About | Change Password | Log off admin

Home Routing x User Management x

Home / Users / User Management

User Management

- Manage Users
- Public Contacts
- Shared Addresses
- System Presence
- ACLs
- Communication
- Profile Password
- Policy

User Profile Edit: 25551@avaya.com

Commit & Continue Commit Cancel

Identity \* Communication Profile Membership Contacts

User Provisioning Rule

User Provisioning Rule: [v]

Identity

\* Last Name: SIP

Last Name (Latin Translation): SIP

\* First Name: Station 1

First Name (Latin Translation): Station 1

Middle Name: [ ]

Description: [ ]

Update Time : May 31, 2013 3:09:36

\* Login Name: 25551@avaya.com

\* Authentication Type: Basic

[Change Password](#)

Source: local

Localized Display Name: SIP Station 1

Endpoint Display Name: SIP, Station 1

Title: [ ]

Language Preference: English (United States)

- Communication Profile section

Provide the following information:

- **Communication Profile Password** – Enter a numeric value used to logon to SIP telephone.
- **Confirm Password** – Repeat numeric password

Verify there is a default entry identified as the **Primary** profile for the new SIP user. If an entry does not exist, select **New** and enter values for the following required attributes:

- **Name** – Enter **Primary**.
- **Default** – Enter

AVAYA  
Aura System Manager 6.3

Last Logged on at March 7, 2014 2:47 PM  
Help | About | Change Password | Log off admin

Home Routing **User Management**

**User Management**  
Manage Users  
Public Contacts  
Shared Addresses  
System Presence  
ACLs  
Communication  
Profile Password  
Policy

Home / Users / User Management

**User Profile Edit: 25551@avaya.com** Commit & Continue Cor

Identity \* **Communication Profile** Membership Contacts

**Communication Profile**

Communication Profile Password: [REDACTED] [Edit](#)

**Name**

Primary

Select : None

\* Name:

Default :

**Communication Address**

<input type="checkbox"/>	Type	Handle	Domain
<input type="checkbox"/>	Avaya SIP	25551	avaya.com

Select : All, None

- Communication Address sub-section  
Select **New** to define a **Communication Address** for the new SIP user, and provide the following information.
  - **Type** – Select **Avaya SIP** using drop-down menu.
  - **Fully Qualified Address** – Enter same extension number and domain used for Login Name, created previously.
 Click the **Add** button to save the Communication Address for the new SIP user.

**Communication Address**

<input checked="" type="checkbox"/>	Type	Handle	Domain
<input checked="" type="checkbox"/>	Avaya SIP	25551	avaya.com

Select : All, None

Type:

\* Fully Qualified Address:  @

- Session Manager Profile section
  - **Primary Session Manager** – Select one of the Session Managers.
  - **Secondary Session Manager** – Select (**None**) from drop-down menu.
  - **Origination Application Sequence** – Select Application Sequence defined (not shown) for Communication Manager.

- **Termination Application Sequence** – Select Application Sequence defined (not shown) for Communication Manager.
- **Survivability Server** – Select **(None)** from drop-down menu.
- **Home Location** – Select Location defined in **Section 6.2**.

☑ **Session Manager Profile** ▼

**SIP Registration**

\* Primary Session Manager

asm-tr1 ▼

Primary	Secondary	Maximum
11	0	11

Secondary Session Manager

(None) ▼

Survivability Server

(None) ▼

Max. Simultaneous Devices

1 ▼

Block New Registration When  
Maximum Registrations  
Active?

**Application Sequences**

Origination Sequence

cm-tr1 ▼

Termination Sequence

cm-tr1 ▼

**Call Routing Settings**

\* Home Location

Test Room 1 ▼

Conference Factory Set

(None) ▼

● Endpoint Profile section

- **System** – Select Managed Element defined in **System Manager** (not shown) for Communication Manager.
- **Use Existing Endpoints** - Leave unchecked to automatically create a new endpoint on Communication Manager when the new user is created. Or else, check the box if endpoint is already defined in Communication Manager.
- **Extension** - Enter same extension number used in this section.
- **Template** – Select template for type of SIP phone. For this particular extension, 9641SIP\_DEFAULT\_CM\_6\_3 was selected.
- **Security Code** – Enter numeric value used to logon to SIP telephone. (**Note:** this field must match the value entered for the Shared Communication Profile Password field.)
- **Voice Mail Number** – Enter **Pilot Number** for Avaya Modular Messaging if installed. Or else, leave field blank. This feature is not used during the compliance test.
- **Delete Station on Unassign of Endpoint** – Check the box to automatically delete station when Endpoint Profile is un-assigned from user.

**CM Endpoint Profile** ▼

\* System  ▼

\* Profile Type  ▼

Use Existing Endpoints

\* Extension

\* Template  ▼

Set Type

Security Code

\* Port

Voice Mail Number


Preferred Handle  ▼

Enhanced Callr-Info display for 1-line phones

## 7. Configure Pivot

Configuration for Pivot phones is done via Spectralink Configuration Management system (CMS). CMS can be reached via browser, <http://<CMS-IP-Address>>

Provide the login credentials and log in.



spectralink  | configuration manager v1.0.2 

Home

Home Applications ▾

### Initial Setup

<a href="#">Certificates</a>	Use the certificates menu to input certificates you would like to send to devices or use in wifi profiles.
<a href="#">Wireless profiles</a>	Select this menu option to configure wireless profiles to be sent to devices.
<a href="#">Over the air provisioning</a>	Select this option to learn how to use this server to update your device code.

### Device Management

<a href="#">Device list</a>	The device list displays up to the minute information on devices connected to the management system.
<a href="#">Configure device(s)</a>	Use this feature to configure the settings on your Spectralink 8700 devices
<a href="#">Phone groups</a>	Click this option to define groups of devices for easier configuration
<a href="#">Batch configure extensions</a>	This feature allows you to import a CSV file of SIP extension info to more easily configure multiple devices' SIP extensions
<a href="#">Reset device password(s)</a>	Use this feature to change the lock-screen password of a device that is currently active on the configuration management system.
<a href="#">Quick RMA replacement</a>	Use this feature to move the configuration from your replaced device to the new device.

Once the phones are connected to WiFi, CMS automatically detects them. To view all the phones that are detected by CMS, select **Device List**.

The screenshot shows the Spectralink Configuration Manager v1.0.2 interface. At the top, there is a header with the Spectralink logo and the text "configuration manager v1.0.2". Below the header is a breadcrumb trail: "Home / Device Management / Devices". A search bar contains the text "Select Device to change". Below this is a table with columns: Summary, Status, Battery, Log, Edit config., View configuration, and Groups. Two devices are listed, both with a status of "Inactive" and a battery level of "Temp". Each device has a "Configure" button. At the bottom, there is an "Action:" dropdown menu, a "Go" button, and the text "0 of 2 selected".

<input type="checkbox"/>	Summary	Status	Battery	Log	Edit config.	View configuration	Groups
<input type="checkbox"/>	8741 - 00:90:7a:11:bd:e4	Inactive	Temp		Configure		Temp
<input type="checkbox"/>	8741 - 00:90:7a:11:bd:6b	Inactive	Temp		Configure		Temp

Action:  Go 0 of 2 selected

Select **Configure**, to configure SIP Settings. On the **Configure Device** page, select **SIP Service**.

- Set **Enable /Disable Spectralink SIP** to **Enable**
- For **Server**, type in the SIP address of Session Manager
- For **Server Port**, type in the port number of Session Manager
- In the **Username** and **Password** field, type in the username and password that was created in **Section 6.8**.
- In the **Voice mail retrieval address** field, type in the address used for retrieving voice messages. In this case, Communication Manager Messaging was used.
- Ensure that **Audio codec priority** has **G.711u** and **G.729a** are selected.

spectralink  | configuration manager v1.0.2 Welcome, admin ▾ Recent Actions ▾

---

▲ SIP Service

Enable / Disable Spectralink SIP <i>Changing the SIP state will force a phone reboot</i>	Enable ▾	1 set at device level.
Server	10.64.10.62	10.64.10.62 set at device level.
Server Port	5060	5060 set at device level.
Extension number	25575	25575 set at device level.
Username	25575	25575 set at device level.
Password	..... Show Password <input type="checkbox"/>	Password set at device level.
Voice mail retrieval address	25990@10.64.10.62	25990@10.64.10.62 set at device level.
Audio DSCP <i>Value should be a decimal (no leading chars) or hex number (leading 0x)</i>		
Call Control DSCP <i>Value should be a decimal (no leading chars) or hex number (leading 0x)</i>		
Use SIP standard hold signaling	----- ▾	
Audio codec priority <i>Enable an audio codec by selecting the checkbox. Drag and drop codecs in the list to set the priority of a codec.</i>	G.722  <input type="checkbox"/> G.711u  <input checked="" type="checkbox"/> G.711a  <input type="checkbox"/> G.729a  <input checked="" type="checkbox"/>	Value set at device level.

## 8. Verification Steps

The following steps may be used to verify the configuration:

- Verify that Pivot successfully registers with Session Manager by following the **Session Manager → System Status → User Registrations** link on the System Manager Web Interface.
- Place calls to and from Spectralink 87-Series and verify that the calls are successfully established with two-way talk path.
- Using Spectralink CMS, navigate to **Home → Device Management → Devices**. When the phones are registered, the status will be displayed as **Active**, as shown in the screen capture below.

The screenshot shows the Spectralink Configuration Manager v1.0.2 interface. The breadcrumb navigation is Home / Device Management / Devices. Below the navigation is a search bar labeled 'Select Device to change'. The main content area is a table with the following columns: Summary, Status, Battery, Log, Edit config., View configuration, and Groups. There are two rows of device data:

Summary	Status	Battery	Log	Edit config.	View configuration	Groups
8741 - 00:90:7a:11:bd:e4	Active	100%	View Log	Configure	View Configuration	Temp
8741 - 00:90:7a:11:bd:6b	Active	99%	View Log	Configure	View Configuration	Temp

At the bottom of the table is an 'Action:' dropdown menu and a 'Go' button. The text '0 of 2 selected' is displayed next to the 'Go' button.

## 9. Conclusion

Pivot was compliance tested with Communication Manager (Version 6.3) and Session Manager (Version 6.3). Spectralink 87-Series (1.0.0.4037) functioned properly for feature and serviceability. During compliance testing, Pivot successfully registered with Session Manager, placed and received calls to and from SIP and non-SIP telephones, and executed other telephony features like three-way conference, transfers, hold, etc.

## 10. Additional References

The following Avaya product documentation can be found at <http://support.avaya.com>

[1] *Administering Avaya Aura® Communication Manager*, December 2013, Release 6.3, Document Number 03-300509.

[2] *Administering Avaya® Session Manager*, October 2013, Release 6.3, Issue 3

[3] *Administering Avaya® System Manager*, October 2013, Release 6.3, Issue 3

The following documentation was provided by Spectralink and can be found at <http://support.spectralink.com/>

[4] *Spectralink 87-Series Administration Guide*

[5] *PIVOT by Spectralink User Guide*

[6] *PIVOT by Spectralink Quick Start Guide*

---

**©2014 Avaya Inc. All Rights Reserved.**

Avaya and the Avaya Logo are trademarks of Avaya Inc. All trademarks identified by ® and ™ are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners. The information provided in these Application Notes is subject to change without notice. The configurations, technical data, and recommendations provided in these Application Notes are believed to be accurate and dependable, but are presented without express or implied warranty. Users are responsible for their application of any products specified in these Application Notes.

Please e-mail any questions or comments pertaining to these Application Notes along with the full title name and filename, located in the lower right corner, directly to the Avaya DevConnect Program at [devconnect@avaya.com](mailto:devconnect@avaya.com).