



## **Avaya Solution & Interoperability Test Lab**

---

# **Application Notes for Configuring Bell Canada SIP Trunking with Avaya IP Office 9.1 - Issue 1.0**

### **Abstract**

These Application Notes describe the procedures for configuring Bell Canada Session Initiation Protocol (SIP) Trunking with Avaya IP Office Release 9.1.

Bell Canada SIP Trunking provides PSTN access via a SIP trunk between the enterprise and the Bell Canada network as an alternative to legacy analog or digital trunks. This approach generally results in lower cost for the enterprise.

Readers should pay attention to section 2, in particular the scope of testing as outlined in Section 2.1 as well as the observations noted in Section 2.2, to ensure that their own use cases are adequately covered by this scope and results.

Bell Canada is a member of the Avaya DevConnect Service Provider program. Information in these Application Notes has been obtained through DevConnect compliance testing and additional technical discussions. Testing was conducted via the DevConnect Program at the Avaya Solution and Interoperability Test Lab.

# 1. Introduction

These Application Notes describe the procedures for configuring Session Initiation Protocol (SIP) Trunking between service provider Bell Canada and IP Office solution. In the sample configuration, IP Office solution consists of an IP Office 500v2 Release 9.1, Avaya Voicemail Pro, IP Office Softphone, and Avaya H.323, SIP, digital, and analog endpoints.

The Bell Canada SIP Trunking service referenced within these Application Notes is designed for business customers. The service enables local and long distance PSTN calling via standards-based SIP trunks as an alternative to legacy analog or digital trunks, without the need for additional TDM enterprise gateways and the associated maintenance costs.

The Bell Canada SIP Trunking service uses Digest Authentication for outbound calls from the enterprise, using challenge-response authentication for each call to the Bell Canada network based on a configured user name and password (provided by Bell Canada and configured in IP Office). This call authentication scheme as specified in SIP RFC 3261 provides security and integrity protection for SIP signaling.

## 2. General Test Approach and Test Results

The general test approach was to configure a simulated enterprise site using IP Office to connect to Bell Canada SIP Trunking service. This configuration (shown in **Figure 1**) was used to exercise the features and functionality tests listed in **Section 2.1**.

DevConnect Compliance Testing is conducted jointly by Avaya and DevConnect members. The jointly-defined test plan focuses on exercising APIs and/or standards-based interfaces pertinent to the interoperability of the tested products and their functionalities. DevConnect Compliance Testing is not intended to substitute full product performance or feature testing performed by DevConnect members, nor is it to be construed as an endorsement by Avaya of the suitability or completeness of a DevConnect member's solution.

### 2.1. Interoperability Compliance Testing

A simulated enterprise site with IP Office was connected to Bell Canada SIP Trunking service. To verify SIP trunking interoperability, the following features and functionality were exercised during the interoperability compliance test:

- Response to SIP OPTIONS queries.
- Incoming PSTN calls to various phone types. Phone types included H.323, SIP, digital, and analog telephones at the enterprise. All inbound PSTN calls were routed to the enterprise across the SIP trunk from the service provider.
- Outgoing PSTN calls from various phone types. Phone types included H.323, SIP, digital, and analog telephones at the enterprise. All outbound PSTN calls were routed from the enterprise across the SIP trunk to the service provider.
- Inbound and outbound PSTN calls to/from the IP Office Softphone.
- Inbound and outbound long holding time call stability.

- Various call types including: local, long distance, international, outbound toll-free, operator service and directory assistance.
- Codec G.711MU and G.729A.
- Caller number/ID presentation.
- Privacy requests (i.e., caller anonymity) and Caller ID restriction for inbound and outbound calls.
- DTMF transmission using RFC 2833.
- Voicemail navigation for inbound and outbound calls.
- Telephony features such as hold and resume, transfer, and conference.
- Use of SIP REFER for call transfer to PSTN.
- Fax G.711 Pass Through mode.
- Off-net call forwarding.
- Twinning to mobile phones on inbound calls.

## 2.2. Test Results

Bell Canada SIP Trunking passed compliance testing.

Items not supported or not tested included the following:

- Inbound toll-free is supported but was not tested as part of the compliance test.
- T.38 Fax is not supported.
- Call redirection (Blind/Consultative transfer) using REFER is not supported. See observation below.

Interoperability testing of Bell Canada SIP Trunking was completed with successful results for all test cases with the exception of the observations/limitations described below.

- **Call Redirection Off Net Blind Transfer Using REFER method** – When using REFER method for off net blind call transfer from PSTN1 to PSTN2, Bell responds 202 Accepted to IP Office's REFER message then returns 408 Request Timeout right after. According to Bell SIP trunk specification, Bell SIP trunk does not support REPLACE in the IP Office's Refer-To header. User will experience no ringback tone on PSTN1 and sometimes there is no speech path between PSTN1 and PSTN2. Due to this issue, the recommended setting on IP Office would be set to never use REFER method for call transfer but rather use re-INVITE. This setting is reflected on the IP Office SIP line setting in **section 5.4.2**.

## 2.3. Support

For technical support on the Avaya products described in these Application Notes visit <http://support.avaya.com>.


For technical support on Bell Canada SIP Trunking, contact Bell Canada at [http://www.bell.ca/enterprise/EntPrd\\_SIP\\_Trunking.page](http://www.bell.ca/enterprise/EntPrd_SIP_Trunking.page).

### 3. Reference Configuration

**Figure 1** below illustrates the test configuration. The test configuration shows an enterprise site connected to Bell Canada SIP Trunking service through the public IP network. For confidentiality and privacy purposes, actual public IP addresses used in this testing have been masked out and replaced with fictitious IP addresses throughout the document.

Located at the enterprise site is an IP Office 500v2 with the MOD DGTL STA16 expansion which provides connections for 16 digital stations to the PSTN, the extension PHONE 8 card which provides connections for 8 analog stations to the PSTN as well as 64-channel VCM (Voice Compression Module) for supporting VoIP codecs. The LAN port of IP Office is connected to the enterprise LAN while the WAN port is connected to the public IP network. Endpoints include an Avaya 9600 Series IP Telephone (with H.323 firmware), an Avaya 9508 Digital Telephone, an Avaya Symphony 2000 Analog Telephone and IP Office Softphone. A separate Windows XP PC runs IP Office Manager to configure and administer IP Office.

Mobility Twinning is configured for some IP Office users so that calls to these user phones will also ring and can be answered at the configured mobile phones.



**Figure 1: Test Configuration for IP Office with Bell Canada SIP Trunking Service**

For the purposes of the compliance test, IP Office users dialed a short code of 9 + N digits to send digits across the SIP trunk to Bell Canada. The short code of 9 was stripped off by IP Office but the remaining N digits were sent unaltered to Bell Canada. For calls within the North American Numbering Plan (NANP), the user would dial 11 (1 + 10) digits. Thus for these NANP calls, IP Office would send 11 digits in the Request URI and the To field of an outbound SIP INVITE message. It was configured to send 10 digits in the From field. For inbound calls, Bell Canada SIP Trunking sent 10 digits in the Request URI and the To field of inbound SIP INVITE messages.

Bell Canada uses the phone number in the From header of a SIP INVITE message to authenticate the calling party. Thus, a call will be rejected by the network unless the From header contains a number known to Bell Canada. This is especially important for calls inbound from the PSTN which are redirected back to the PSTN by call forwarding or twinning. For call forwarding, IP Office sends the number of the forwarding phone in the From header. This is a number known to Bell Canada. As a result, the call display on the destination phone shows the forwarding party not the original caller. For twinning, this behavior can be slightly altered through configuration. See **Sections 5.3** and **5.4** for details.

Note that the calling party authentication using the phone number by Bell Canada, as mentioned above, is in addition to the Digest Authentication by Bell Canada during call setup SIP signaling exchanges using a user name and password as configured in IP Office for all calls from the enterprise to Bell Canada.

## 4. Equipment and Software Validated

The following equipment and software/firmware were used for the sample configuration provided:

| Avaya Telephony Components                  |                                     |
|---|-------------------------------------|
| Equipment/Software                          | Release/Version                     |
| Avaya IP Office 500 V2                      | 9.1.300.120                         |
| Avaya IP Office Manager                     | 9.1.300.120                         |
| Avaya Voicemail Pro for IP Office           | 9.1.300.120                         |
| Avaya 11x0 IP Telephone (SIP)               | SIP11x0e04.03.12.00                 |
| Avaya 9630G IP Telephone (H.323)            | Avaya one-X® Deskphone Edition S3.2 |
| Avaya Communicator for Windows              | 2.0.3.30                            |
| Avaya Digital Telephone (9508)              | 0.45                                |
| Avaya Symphony 2000 Analog Telephone        | N/A                                 |
| Bell Canada SIP Trunking Service Components |                                     |
| Equipment/Software                          | Release/Version                     |
| Oracle ACME Packet Net-Net 4500             | SC 7.2.0 MR-5                       |
| BroadSoft Broadworks                        | r.20                                |
| Legacy Nortel CS2K Media Gateway            | CVM17                               |

**Note:** Compliance Testing is applicable when the tested solution is deployed with a standalone IP Office 500 V2 and also when deployed with all configurations of IP Office Server Edition without T.38 Fax Service.

## 5. Configure IP Office


This section describes IP Office configuration to support connectivity to Bell Canada SIP Trunking service. IP Office is configured through IP Office Manager PC application. From a PC running IP Office Manager application, select **Start → Programs → IP Office → Manager** to launch the application. Navigate to **File → Open Configuration**, select the proper IP Office system from the pop-up window, and log in with the appropriate credentials. A management window will appear similar to the one shown in the next section. The appearance of the IP Office Manager can be customized using the **View** menu. In the screens presented in this section, the View menu was configured to show the Navigation pane on the left side, the Group pane in the center, and the Details pane on the right side. These panes will be referenced throughout IP Office configuration. Proper licensing as well as standard feature configurations that are not directly related to the interface with the service provider (such as LAN interface to the enterprise site and IP Office Softphone support) is assumed to be already in place.

### 5.1. LAN Settings

In the sample configuration, the **DevCon IPO2** was used as the system name and the WAN port was used to connect IP Office to the public network. The LAN1 settings correspond to the WAN port on IP Office.


To access the LAN settings, first navigate to **System (1) → DevCon IPO2** in the Navigation and Group Panes and then navigate to the **LAN2 → LAN Settings** tab in the Details Pane.

- Set the **IP Address** field to the IP address assigned to the IP Office WAN port.
- Set the **IP Mask** field to the mask used on the public network.
- All other parameters should be set according to customer requirements.
- Click **OK**.



Select the **VoIP** tab as shown in the following screen.


- The **H323 Gatekeeper Enable** box is checked to allow the use of Avaya IP Telephones using the H.323 protocol, such the 9600-Series IP Telephones used in the sample configuration.
- The **SIP Trunks Enable** box must be checked to enable the configuration of SIP trunks to Bell Canada.
- The **SIP Registrar Enable** box is checked to allow IP Office Softphone usage.
- The **Layer 4 Protocol**, check the **UDP** box and set **UDP Port** to **5060**.
- All other parameters should be set according to customer requirements.
- Click **OK**.





On the **Network Topology** tab in the Details Pane, configure the following parameters:

- Select the **Firewall/NAT Type** from the pull-down menu that matches the network configuration. No firewall or network address translation (NAT) device was used in the compliance test as shown in **Figure 1**, so the parameter was set to **Open Internet**. With this configuration, **STUN** will not be used.
- Set **Binding Refresh Time (seconds)** to **60**. This value is used as one input to determine the frequency at which IP Office will send SIP OPTIONS messages to the service provider.
- Set **Public IP Address** to the IP address of IP Office WAN port. **Public Port** is set to **5060**.
- All other parameters should be set according to customer requirements.
- Click **OK**.




In the compliance test, the LAN1 interface was used to connect IP Office to the enterprise site IP network. The LAN1 interface configuration is not directly relevant to the interface with Bell Canada SIP Trunking service, and therefore is not described in these Application Notes.

## 5.2. System Telephony Settings

Navigate to the **Telephony** → **Telephony** Tab in the Details Pane.


- Choose the **Companding Law** typical for the enterprise location. For North America, **ULAW** is used.
- Uncheck the **Inhibit Off-Switch Forward/Transfer** box to allow call forwarding and call transfer to the PSTN via the service provider across the SIP trunk.
- Click **OK**.



## 5.3. Twinning Calling Party Settings

When using twinning, the calling party number displayed on the twinned phone is controlled by two parameters. These parameters only affects twinning and do not impact the messaging or operation of other redirected calls such as forwarded calls. The first parameter is the **Send original calling party information for Mobile Twinning** box on the **System** → **Twinning** tab. The second parameter is the **Send Caller ID** parameter on the **SIP Line** form (shown in Section 5.4).

- For the compliance testing, the **Send original calling party information for Mobile Twinning** as shown below was unchecked. This setting allows **Send Caller ID** parameter that was set to **P Asserted ID** in Section 5.4.2 to be used.
- Click **OK**.



## 5.4. Administer SIP Line

A SIP line is needed to establish the SIP connection between IP Office and Bell Canada SIP Trunking service. The recommended method for configuring a SIP Line is to use the template associated with these Application Notes. The template is an .xml file that can be used by IP Office Manager to create a SIP Line. Follow the steps in **Section 5.4.1** to create the SIP Line from the template.

Some items relevant to a specific customer environment are not included in the template or may need to be updated after the SIP Line is created. Examples include the following:

- IP addresses.
- SIP Credentials (if applicable).
- SIP URI entries.
- Setting of the **Use Network Topology Info** field on the Transport tab.

Therefore, it is important that the SIP Line configuration be reviewed and updated if necessary after the SIP Line is created via the template. The resulting SIP Line data can be verified against the manual configuration shown in **Sections 5.4.2**.


Also, the following SIP Line settings are not supported on Basic Edition:

- SIP Line – Originator number for forwarded and twinning calls.
- Transport – Second Explicit DNS Server.
- SIP Credentials – Registration Required.

Alternatively, a SIP Line can be created manually. To do so right-click **Line** in the Navigation Pane and select **New → SIP Line**, then follow the steps outlined in **Sections 5.4.2**.


### 5.4.1. Create SIP line from Template

1. Copy the template file to the computer where IP Office Manager is installed. Rename the template file to **AF\_Bell Canada\_SIPTrunk.xml**. The file name is important in locating the proper template file in **Step 5**.
2. Verify that template options are enabled in IP Office Manager. In IP Office Manager, navigate to **File → Preferences**. In the IP Office Manager Preferences window that appears, select the Visual Preferences tab. Verify that the box is checked next to **Enable Template Options**. Click **OK**.




3. Import the template into IP Office Manager.

From IP Office Manager, select **Tools → Import Templates in Manager**. This action will copy the template file into the IP Office template directory and make the template available in the IP Office Manager pull-down menus in **Step 5**. The default template location is **C:\Program Files\Avaya\IP Office\Manager\Templates**.



In the pop-up window (not shown) that appears, select the directory where the template file was copied in **Step 1**. After the import is complete, a final import status pop-up window (not shown) will appear stating success or failure. Click **OK** (not shown) to continue. If preferred, this step may be skipped if the template file is copied directly to the IP Office template directory.

4. To create the SIP Trunk from the template, right-click on **Line** in the Navigation Pane, then navigate to **New → New SIP Trunk From Template**.



5. In the subsequent Template Type Selection pop-up window, check **Display All** box. From the **Service Provider** pull-down menu and the file name **AF\_Bell Canada\_SIPTrunk.xml** created in **Step 1**. Click **Create new SIP Trunk** to finish creating the trunk.



6. Once the SIP Line is created, verify the configuration of the SIP Line with the configuration shown in **Sections 5.4.2**.

### 5.4.2. Create SIP Line Manually

To create a SIP line, begin by navigating to **Line** in the left Navigation Pane, then right-click in the Group Pane and select **New → SIP Line**. On the **SIP Line** tab in the Details Pane, configure the parameters as shown below:

- Set **ITSP Domain Name** to the enterprise domain so that IP Office uses this domain as the host portion of SIP URI in SIP headers such as the From header.
- Set **Send Caller ID** to **P Asserted ID Header**.
- Check the **In Service** box.
- Check the **Check OOS** box. With this option selected, IP Office will use the SIP OPTIONS method to periodically check the SIP Line.
- **Incoming Supervised REFER** was set to **Never** as Bell does not support REFER method the way IP Office does.
- **Outgoing Supervised REFER** was set to **Never** as Bell does not support REFER method the way IP Office does.
- Other parameters are set as default values.
- Click **OK**.

The screenshot shows the 'SIP Line - Line 19' configuration window in IP Office. The left pane shows the 'Line' group selected. The main pane has tabs for 'SIP Line', 'Transport', 'SIP URI', 'VoIP', 'T38 Fax', 'SIP Credentials', 'SIP Advanced', and 'Engineering'. The 'SIP Line' tab is active. The configuration fields are as follows:

| Field                      | Value                               |
|----------------------------|-------------------------------------|
| Line Number                | 19                                  |
| ITSP Domain Name           | Vendor7.lab.internetsupport.ca      |
| URI Type                   | SIP                                 |
| Location                   | Cloud                               |
| Prefix                     |                                     |
| National Prefix            |                                     |
| International Prefix       |                                     |
| Country Code               |                                     |
| Name Priority              | System Default                      |
| Description                |                                     |
| In Service                 | <input checked="" type="checkbox"/> |
| Check OOS                  | <input checked="" type="checkbox"/> |
| Session Timers             |                                     |
| Refresh Method             | Auto                                |
| Timer (seconds)            | On Demand                           |
| Forwarding and Twinning    |                                     |
| Originator number          |                                     |
| Send Caller ID             | P Asserted ID                       |
| Redirect and Transfer      |                                     |
| Incoming Supervised REFER  | Never                               |
| Outgoing Supervised REFER  | Never                               |
| Send 302 Moved Temporarily | <input type="checkbox"/>            |
| Outgoing Blind REFER       | <input type="checkbox"/>            |

At the bottom right, there are buttons for 'OK', 'Cancel', and 'Help'. The 'OK' button is highlighted with a red box.



Select the **Transport** tab and enter the following information.


- The **ITSP Proxy Address** is set to the provided IP Address of Bell SIP trunk.
- **Layer 4 Protocol** is set to **UDP**.
- **Send Port** is set to the port number of IP Office, **5060**.
- **Use Network Topology Info** parameter is set to **LAN 2**. This associates the SIP Line with the parameters in the **System → LAN2 → Network Topology** tab.
- Other parameters retain default values in the screen below.
- Click **OK**.

The screenshot shows the 'SIP Line - Line 19\*' configuration window. The 'Transport' tab is selected. The 'ITSP Proxy Address' field is set to '192.168.195.200'. The 'Layer 4 Protocol' is set to 'UDP'. The 'Send Port' is set to '5060'. The 'Use Network Topology Info' is set to 'LAN 2'. The 'Listen Port' is set to '5060'. The 'Explicit DNS Server(s)' field is set to '0 . 0 . 0 . 0'. The 'Calls Route via Registrar' checkbox is checked. The 'Separate Registrar' field is empty. The 'OK' button is highlighted with a red box.

| IP Offices    | Line        | SIP Line | Transport | SIP URI | VoIP | T38 Fax | SIP Credentials | SIP Advanced | Engineering |
|---------------|-------------|----------|-----------|---------|------|---------|-----------------|--------------|-------------|
| BOOTP (9)     | Line Number |          |           |         |      |         |                 |              |             |
| Operator (3)  | 1           |          |           |         |      |         |                 |              |             |
| DevCon IPO 2  | 2           |          |           |         |      |         |                 |              |             |
| System (1)    | 17          |          |           |         |      |         |                 |              |             |
| Line (10)     | 18          |          |           |         |      |         |                 |              |             |
| Control Un    | 19          |          |           |         |      |         |                 |              |             |
| Extension (4) | 20          |          |           |         |      |         |                 |              |             |
| User (44)     | 21          |          |           |         |      |         |                 |              |             |
| Group (7)     | 22          |          |           |         |      |         |                 |              |             |
| Short Code    | 23          |          |           |         |      |         |                 |              |             |
| Service (0)   | 24          |          |           |         |      |         |                 |              |             |
| RAS (1)       |             |          |           |         |      |         |                 |              |             |
| Incoming C    |             |          |           |         |      |         |                 |              |             |
| WAN Port (    |             |          |           |         |      |         |                 |              |             |
| Directory (C  |             |          |           |         |      |         |                 |              |             |
| Time Profil   |             |          |           |         |      |         |                 |              |             |
| Firewall Prc  |             |          |           |         |      |         |                 |              |             |
| IP Route (2)  |             |          |           |         |      |         |                 |              |             |
| Account Cc    |             |          |           |         |      |         |                 |              |             |
| License (42)  |             |          |           |         |      |         |                 |              |             |

A SIP Credentials entry must be created for Digest Authentication used by Bell Canada SIP trunking service to authenticate calls from the enterprise to the PSTN. To create a SIP Credentials entry, first select the **SIP Credentials** tab. Click the **Add** button and the **New Channel** area will appear at the bottom of the pane. To edit an existing entry, click an entry in the list at the top, and click the **Edit...** button. In the bottom of the screen, the Edit Channel area will be opened. In the example screen below, a previously configured entry is edited. The entry was created with the parameters shown below:

- Set **User name**, **Authentication Name** and **Contact** to the value provided by the service provider.
- Set **Password** and **Confirmed Password** to the value provided by the service provider.
- The **Expiry (mins)** is set to **60**.
- Uncheck the **Registration required** option. Bell Canada does not require registration for Digest Authentication.
- Click **OK**.





A SIP URI entry must be created to match each incoming number that IP Office will accept on this line. Select the **SIP URI** tab, click the **Add** button and then **New Channel** area will appear at the bottom of the pane. To edit an existing entry, click an entry in the list at the top, and click the **Edit...** button. In the example screen below, a previously configured entry is edited. For the compliance test, a single SIP URI entry was created that matched any DID number assigned to an IP Office user. The entry was created with the parameters shown below:

- **Via** field is pre-populated by IP Office.
- Set **Local URI**, **Contact** and **Display Name** to **Internal Data**. This setting allows calls on this line which SIP URI matches the number set in the **SIP** tab of any **User** as shown in **Section 5.6**.
- **PAI** field is set to **None**.
- For **Registration**, select the account credentials previously configured on the line's **SIP Credentials** tab.
- Associate this line with an incoming line group in the **Incoming Group** field. This line group number will be used in defining incoming call routes for this line. Similarly, associate the line to an outgoing line group using the **Outgoing Group** field. For the compliance test, a new incoming and outgoing group **19** was defined that only contains this line (line 19).
- Set **Max Calls per Channel** to the number of simultaneous SIP calls that are allowed using this SIP URI pattern.
- Click **OK**.

The screenshot displays the IP Office configuration interface. On the left, the 'IP Offices' tree shows 'Line (10)' selected. The main window is titled 'SIP Line - Line 19\*'. The 'SIP URI' tab is active, showing a table with two channels. Channel 1 is selected, and the 'Edit...' button is highlighted. The 'Edit Channel' dialog is open, showing the following fields:

| Channel | Groups | Via          | Local URI  | Contact | Display Name | PAI  | Credential     |
|---------|--------|--------------|------------|---------|--------------|------|----------------|
| 1       | 19 19  | 10.10.98.113 |            |         |              | None | 1: VEND7_613XX |
| 2       | 19 19  | 10.10.98.113 | 613XXX6516 |         |              | None | 1: VEND7_613XX |

The 'Edit Channel' dialog shows the following values:

|                       |                         |
|-----------------------|-------------------------|
| Via                   | 10.10.98.113            |
| Local URI             | Use Internal Data       |
| Contact               | Use Internal Data       |
| Display Name          | Use Internal Data       |
| PAI                   | None                    |
| Registration          | 1: VEND7_613XXX6509_01A |
| Incoming Group        | 19                      |
| Outgoing Group        | 19                      |
| Max Calls per Channel | 10                      |

SIP URI entry **Channel 2** was similarly created for incoming calls appropriately to pre-define DID numbers, which is provided by service provider, to access to Feature Name Extension 00 (FNE00). The Short Codes for FNE00 was defined in **Section 5.5** to provide Dial Tone and Mobile Callback for mobility extension.

The **Channel 2**, as shown in the screenshot below, was configured with following parameters.

- **Via** field is pre-populated by IP Office.
- Set the **Local URI** to pre-define DID number appropriately for **Channel 2**.
- Set **Contact** and **Display Name** to **Internal Data**. This setting allows calls on this line which SIP URI matches the number set in the **SIP** tab of any **User** as shown in **Section 5.6**.
- **PAI** field is set to **None**.
- For **Registration**, select the account credentials previously configured on the line's **SIP Credentials** tab.
- Associate **Incoming Group** and **Outgoing Group** to SIP Line 19.
- Set the **Max Calls per Channel** field to **10**.
- Other parameters retain default values.
- Click **OK**.

**SIP Line - Line 19\***

| Channel | Groups | Via          | Local URI  | Contact | Display Name | PAI  | Credential     |
|---------|--------|--------------|------------|---------|--------------|------|----------------|
| 1       | 19 19  | 10.10.98.113 |            |         |              | None | 1: VEND7_613XX |
| 2       | 19 19  | 10.10.98.113 | 613XXX6516 |         |              | None | 1: VEND7_613XX |

**Edit Channel**

Via: 10.10.98.113

Local URI: 613XXX6516

Contact: Use Internal Data

Display Name: Use Internal Data

PAI: None

Registration: 1: VEND7\_613XXX6509\_01A

Incoming Group: 19


Outgoing Group: 19

Max Calls per Channel: 10

Buttons: Add..., Remove, Edit..., OK, Cancel

Select the **VoIP** tab to set the Voice over Internet Protocol parameters of the SIP line. Set the parameters as shown below:


- The **Codec Selection** can be selected by choosing **Custom** from the pull-down menu, allowing an explicit ordered list of codecs to be specified.
- Selecting **G.711 ULAW 64K** and **G.729(a) 8K CS-ACELP** codecs cause IP Office to include these codes, supported by the Bell Canada SIP Trunking service, in the Session Description Protocol (SDP) offer, in that order.
- Set **Fax Transport Support** to **G711** from the pull-down menu (T.38 faxing is not currently supported by Bell Canada).
- Set the **DTMF Support** field to **RFC2833** from the pull-down menu. This directs IP Office to send DTMF tones using RTP events messages as defined in RFC2833.
- Uncheck the **VoIP Silence Suppression** box. By unchecking the **VoIP Silence Suppression** box, calls can be established with the G.729 codec but without silence suppression.
- Check the **Re-invite Supported** box.
- Check the **PRACK/100rel Supported** box.
- Default values may be used for all other parameters.
- Click **OK**.



## 5.5. Short Code

Define a short code to route outbound traffic to the SIP line. To create a short code, select **Short Code** in the left Navigation Pane, then right-click in the Group Pane and select **New**. On the **Short Code** tab in the Details Pane, configure the parameters for the new short code to be created. The screen below shows the details of the previously administered “9N;” short code used in the test configuration.

- In the **Code** field, enter the dial string which will trigger this short code, followed by a semi-colon. In this case, **9N;**, this short code will be invoked when the user dials 9 followed by any number.
- Set **Feature** to **Dial**. This is the action that the short code will perform.
- Set **Telephone Number** to the value shown in the capture bellow. This field is used to construct the Request URI and To headers in the outgoing SIP INVITE message. The value **N** represents the number dialed by the user. The host part following the “@” is the domain of the service provider network.
- Set the **Line Group Id** to the outgoing line group number defined on the **SIP URI** tab on the **SIP Line** in **Section 5.4**. This short code will use this line group when placing the outbound call.
- Others parameters are at default values.
- Click **OK**.



For incoming calls from mobility extension to FNE features hosted by IP Office to provide **Dial Tone** functionality, Short Code **FNE00** was created. The **FNE00** was configured with the following parameters.

- In the **Code** field, enter the FNE feature code as **FNE00** for **Dial Tone**.
- Set the **Feature** field to **FNE Service**.
- Set the **Telephone Number** field to **00** for **FNE00**.
- Set the **Line Group ID** field to **0**.
- Retain default values for other fields.
- Click **OK**.

The screenshot displays the IP Office configuration interface. On the left, the 'Short Code' list is visible, with 'FNE00' selected. The main configuration window, titled 'FNE00: FNE Service\*', shows the following fields:

| Field                    | Value                    |
|--------------------------|--------------------------|
| Code                     | FNE00                    |
| Feature                  | FNE Service              |
| Telephone Number         | 00                       |
| Line Group ID            | 0                        |
| Locale                   | [Default]                |
| Force Account Code       | <input type="checkbox"/> |
| Force Authorization Code | <input type="checkbox"/> |

The 'OK' button is highlighted in the bottom right corner of the configuration window.

## 5.6. User

Configure the SIP parameters for each user that will be placing and receiving calls via the SIP line defined in **Section 5.4**. To configure these settings, first select **User** in the left Navigation Pane, then select the name of the user to be modified in the center Group Pane. In the example below, the name of the user is “H323-29225”. Select the **SIP** tab in the Details Pane.

The values entered for the **SIP Name** and **Contact** fields are used as the user part of the SIP URI in the From header for outgoing SIP trunk calls. They also allow matching of the SIP URI for incoming calls without having to enter this number as an explicit SIP URI for the SIP line (**Section 5.4**). The example below shows the settings for user H323-29225.

- The **SIP Name** and **Contact** are set to one of the DID numbers assigned to the enterprise from service provider.
- The **SIP Display Name (Alias)** parameter can optionally be configured with a descriptive name.
- If all calls involving this user and a SIP Line should be considered private, then the **Anonymous** box may be checked to withhold the user’s information from the network.
- Click **OK**.

The screenshot displays the Avaya User Configuration interface. On the left, the 'IP Offices' pane shows a tree structure with 'User (44)' selected. The center pane lists users, with 'Extn29225' highlighted. The right pane, titled 'Extn29225: 29225\*', shows the 'SIP' tab selected. The 'SIP' tab contains the following fields:

| Field                    | Value      |
|--------------------------|------------|
| SIP Name                 | 613XXX6509 |
| SIP Display Name (Alias) | H323-29225 |
| Contact                  | 613XXX6509 |

Below these fields is an 'Anonymous' checkbox, which is currently unchecked. At the bottom right of the interface are 'OK', 'Cancel', and 'Help' buttons.

One of the H.323 IP Phones at the enterprise site uses the Mobile Twinning feature. The following screen shows the **Mobility** tab for User H323-29225.

- The **Mobility Features** and **Mobile Twinning** boxes are checked.
- The **Twinned Mobile Number** field is configured with the number to dial to reach the twinned mobile telephone, in this case **916139675281**.
- Other options can be set according to customer requirements.
- Click **OK**.

The screenshot displays the Avaya User Management Interface. On the left, a tree view shows the hierarchy of system components, with 'User (44)' and 'Extn29225' highlighted. The main panel shows the 'Extn29225: 29225\*' configuration page. The 'Mobility' tab is selected, and the 'Internal Twinning' section is expanded. The 'Twinned Mobile Number' field is set to '96139675281'. The 'OK' button is highlighted.

| IP Offices             | User      |
|------------------------|-----------|
| BOOTP (9)              | Extn29213 |
| Operator (3)           | Extn29214 |
| DevCon IPO 2           | Extn29215 |
| System (1)             | Extn29216 |
| Line (10)              | Extn29217 |
| Control Unit (4)       | Extn29218 |
| Extension (42)         | Extn29219 |
| User (44)              | Extn29220 |
| Group (7)              | Extn29221 |
| Short Code (66)        | Extn29222 |
| Service (0)            | Extn29223 |
| RAS (1)                | Extn29224 |
| Incoming Call Route    | Extn29225 |
| WAN Port (0)           | Extn29226 |
| Directory (0)          | Extn29227 |
| Time Profile (0)       | Extn29228 |
| Firewall Profile (1)   | Extn29229 |
| IP Route (2)           | Extn29230 |
| Account Code (0)       | Extn29231 |
| License (42)           | Extn29232 |
| Tunnel (0)             | Extn29233 |
| User Rights (8)        | Extn29234 |
| Auto Attendant (0)     | Extn29235 |
| ARS (2)                | Extn29236 |
| Location (0)           | Extn29237 |
| Authorization Code (0) | Extn29238 |
|                        | Extn29239 |
|                        | Extn29240 |
|                        | Extn29241 |
|                        | Extn29242 |
|                        | IVR 29228 |
|                        | IVR 29229 |
|                        | IVR 29230 |
|                        | IVR 29231 |
|                        | IVR 29232 |
|                        | NoUser    |

**Extn29225: 29225\***

User Voicemail DND Short Codes Source Numbers Telephony Forwarding Dial In Voice Recording

Web Self-Administration

Button Programming Menu Programming **Mobility** Group Membership Announcements SIP Personal Directory

☐ Internal Twinning

Twinned Handset <None>

Maximum Number of Calls 1

☐ Twin Bridge Appearances

☐ Twin Coverage Appearances

☐ Twin Line Appearances

☒ Mobility Features

☒ Mobile Twinning

Twinned Mobile Number (including dial access code) 96139675281

Twining Time Profile <None>

Mobile Dial Delay (secs) 2

Mobile Answer Guard (secs) 0

☐ Hunt group calls eligible for mobile twinning

☐ Forwarded calls eligible for mobile twinning

☐ Twin When Logged Out

☐ one-X Mobile Client

☒ Mobile Call Control

☐ Mobile Callback

OK Cancel Help



## 5.7. Incoming Call Route

An incoming call route maps an inbound DID number on a specific line to an internal extension. This procedure should be repeated for each DID number provided by the service provider. To create an incoming call route, select **Incoming Call Route** in the left Navigation Pane, then right-click in the center Group Pane and select **New**. On the **Standard** tab of the Details Pane, enter the parameters as shown below:

- Set the **Bearer Capacity** to *Any Voice*.
- Set the **Line Group Id** to the incoming line group of the SIP line defined in **Section 5.4**.
- Set the **Incoming Number** to the incoming number on which this route should match.
- Default values can be used for all other fields.
- Click **OK**.

The screenshot shows the 'Incoming Call Route' configuration window for line 19 613XXX6509. The 'Standard' tab is active. The 'Line Group ID' is set to 19. The 'Incoming Number' is set to 613XXX6509. The 'Bearer Capacity' is set to 'Any Voice'. The 'Incoming Sub Address' is empty. The 'Incoming CLI' is empty. The 'Locale' is set to '1 - Low'. The 'Priority' is set to '1 - Low'. The 'Tag' is empty. The 'Hold Music Source' is set to 'System Source'. The 'Ring Tone Override' is set to 'None'. The 'OK' button is highlighted.

On the **Destinations** tab, select the destination extension from the pull-down menu of the **Destination** field. In this example, incoming calls to **613XXX6509** on line 19 are routed to extension **29225**. Click **OK**.

The screenshot shows the 'Incoming Call Route' configuration window for line 19 613XXX6509, with the 'Destinations' tab active. The 'Destination' field is set to '29225 Extn29225'. The 'Fallback Extension' is empty. The 'OK' button is highlighted.

## 5.8. Save Configuration

Navigate to **File** → **Save Configuration** in the menu bar at the top of the screen to save the configuration performed in the preceding sections.



## 6. Bell Canada SIP Trunking Configuration

Bell Canada is responsible for the configuration of Bell Canada SIP Trunking service. The customer will need to provide the IP address used to reach the IP Office at the enterprise. Bell Canada will provide the customer the necessary information to configure the IP Office SIP connection to Bell Canada. The provided information from Bell Canada includes:

- IP address of the Bell Canada SIP proxy.
- Supported codecs.
- DID numbers.
- IP addresses and port numbers used for signaling or media through any security devices.

## 7. Verification Steps

The following steps may be used to verify the configuration:

- Use IP Office System Status application to verify the state of the SIP connection. Launch the application from **Start → Programs → IP Office → System Status** on the PC where IP Office Manager was installed. Select the SIP line of interest from the left pane. On the **Status** tab in the right pane, verify that the **Current State** is *Idle* for each channel (assuming no active calls at present time).

**AVAYA IP Office System Status**

Help Snapshot LogOff Exit About

**System**  
Alarms (29)  
Extensions (28)  
Trunks (10)  
Line:1  
Line:2  
Line:17  
Line:18  
▶ Line:19  
Line:20  
Line:21  
Line:22  
Line:23  
Line:24  
Active Calls  
Resources  
Voicemail  
IP Networking  
Locations

**Status** Utilization Summary Alarms Registration

**SIP Trunk Summary**

Line Service State: In Service  
Peer Domain Name: Vendor7.lab.internetvoice.ca  
Resolved Address: 192.168.195.200  
Line Number: 19  
Number of Administered Channels: 20  
Number of Channels in Use: 0  
Administered Compression: G711 Mu, G729 A  
Enable Faststart: Off  
Silence Suppression: Off  
Media Stream: RTP  
Layer 4 Protocol: UDP  
SIP Trunk Channel Licenses: Unlimited  
SIP Trunk Channel Licenses in Use: 0  
SIP Device Features:


0%

| Channel Number | U... | Call Ref | Current State | Time in State | Remote Media A... | Co... | Conne... | Caller ID or Dial... | Other Party on Call | Direction of Call | Round Trip D... | Receive Jitter | Receive Packe... | Transmit Jitter | Transmit Packe... |
|----------------|------|----------|---------------|---------------|-------------------|-------|----------|----------------------|---------------------|-------------------|-----------------|----------------|------------------|-----------------|-------------------|
| 1              |      |          | Idle          | 1 day ...     |                   |       |          |                      |                     |                   |                 |                |                  |                 |                   |
| 2              |      |          | Idle          | 1 day ...     |                   |       |          |                      |                     |                   |                 |                |                  |                 |                   |
| 3              |      |          | Idle          | 1 day ...     |                   |       |          |                      |                     |                   |                 |                |                  |                 |                   |
| 4              |      |          | Idle          | 1 day ...     |                   |       |          |                      |                     |                   |                 |                |                  |                 |                   |
| 5              |      |          | Idle          | 1 day ...     |                   |       |          |                      |                     |                   |                 |                |                  |                 |                   |

Trace Trace All Pause Ping Call Details Graceful Shutdown Force Out of Service Print... Save As...

5:05:28 PM Online

- Select the **Alarms** tab and verify that no alarms are active on the SIP line.



- Verify that a phone connected to PSTN can successfully place a call to IP Office with two-way audio.
- Verify that a phone connected to IP Office can successfully place a call to the PSTN with two-way audio.
- Using a network sniffing tool e.g. Wireshark to monitor the SIP signalling between the enterprise and Bell. The sniffer traces are captured at the public interface of IP Office.

## 8. Conclusion

The Bell Canada SIP Trunking passed compliance testing with all observations noted in **Section 2.2**. These Application Notes describe the procedures required to configure the SIP connection between Avaya IP Office 500 V2 R9.1 and the Bell Canada SIP Trunking service as shown in **Figure 1**.

## 9. Additional References

- [1] *Administering Avaya IP Office™ Platform with Manager*, Release 9.1, Issue 10.19, August 2015
- [2] *Administering Avaya IP Office™ Platform with Web Manager*, Release 9.1.2, Issue 2.10, August 2015
- [3] *IP Office 9.0.3, Administering Voicemail Pro, Document number 15-601063*, Issue 9.0c, 24 April 2014
- [4] *IP Office Embedded Voicemail User Guide (IP Office Mode)*, Document number 15-604067, Issue 13a, 13 February 2014
- [5] *Avaya IP Office™ Platform Release 9.1, Product Update Document (Offer Definition)*, Update Number:2.7, July 16, 2015

Product documentation for Avaya products may be found at <http://support.avaya.com>. Additional IP Office documentation can be found at:  
<http://marketingtools.avaya.com/knowledgebase/>

Product documentation for Bell Canada SIP Trunking is available from Bell Canada.

---

**©2015 Avaya Inc. All Rights Reserved.**

Avaya and the Avaya Logo are trademarks of Avaya Inc. All trademarks identified by ® and ™ are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners. The information provided in these Application Notes is subject to change without notice. The configurations, technical data, and recommendations provided in these Application Notes are believed to be accurate and dependable, but are presented without express or implied warranty. Users are responsible for their application of any products specified in these Application Notes.

Please e-mail any questions or comments pertaining to these Application Notes along with the full title name and filename, located in the lower right corner, directly to the Avaya DevConnect Program at [devconnect@avaya.com](mailto:devconnect@avaya.com).